



NEO
GRIP

Instructions


Fitting the NeoGrip:

1




Remove one of the joy-cons and put the SWITCH into the NeoGrip.

2



Gently insert the joy-con.


3



Slide in the holder


Removing the NeoGrip:

1



Remove one of the joy-cons

2



Slide off the holder

3




Remove the SWITCH

Switching Grips:




Slide grip downwards to remove and upwards to install.



Please ensure the slider is fitted correctly.


Switching to fit regular SWITCH:

1




Remove the screws

2



Slide off the spacer.

3



Install the screws.