




SPIRIT HD

POCKET GUIDE

EN





Volume Down

Media

Mobile / Intercom

Volume Up

LED Indicator




Number of Taps




Press & Hold


Getting Started




On / Off



Phone Pairing




LED Red & Blue 








Cardo Connect App




Download




Register




Choose Language





Software Update





General




Volume Up



Volume Down



Mute




Voice Assistant



Siri




Google Assistant



Phone Call




Answer



x1
Tap




Ignore



x1
Tap



End Call





x1
Tap

Phone Call




Speed Dial

Set Number





Call Speed Dial





Radio




Set Presets



Start Scan




Stop Scan




Radio





On




Off



Next





Previous




Music





Play




Pause



Next




Previous




Bluetooth Intercom



Pairing



Pair to Rider A




LED Red




Call / End Intercom

Rider A



Bluetooth Intercom




Share




Share Music

x1
Tap




Share Phone Call

x1
Tap




GPS Pairing

1 Step 1




LED Red & Blue 


2 Step 2



LED Red & Green 

3 Step 3





Cardosystems.com

Cardosystems.com/update

Cardosystems.com/support

