

## Instructions for use

Product Name: Acrylic transparent Bluetooth headset

Model: HHWL-C02

FCC ID: 2BCYM-C02

When the product leaves the factory, the left and right earphones have been paired successfully by default. Press when connecting to the phone for the first time.

Follow the steps below: 1. Take out the earphones and turn them on automatically. Wait for about 3 seconds and then the left and right earphones will automatically connect to each other.

2. Turn on Bluetooth on your phone, search for "TWS", and click to link. paired into After the connection is complete. you will hear a beep from the headset and your phone will display a successful link

3. The next time you use it, after the headset is powered on and paired, it will automatically link back to the linked phone.  
phone (the Bluetooth function of the phone must be turned on).Ifyou cannot connect to your mobile phone, please  
Manually operate and headset link from the phone's Bluetooth menu. Operation method

The product is fully charged when leaving the factory

1. L. R and the four power grids indicate the power of the left and right earphones. When the headphones are placed, the number of charging compartments

The code screen lights up.

2. When charging the charging case, the charging digital screen lights up, and the number displayed is the charging case.

Battery, the battery is fully charged, and OK is displayed.

3. Charging case: When the power of the charging case is low, please use the USB-C charging cable.

Connect the charging box to start charging.Charging precautions

Use a charger with an output voltage of DC5V. USB port of PC computer or charger with USB port output (must choose a charger from a regular manufacturer). The headset wil automatically

As the power consumption of the earphones increases, it is recommended to charge the earphones once amonth.

1. When there is an incoming call, click once to answer the call/click again to hang up the call.

To reject a call, press and hold for 2 seconds

2. Listen to music and click to pause/play.

3. Listen to music and click 2 times continuously to play the next song.

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.