



# Designer 1.7 L Kettle



Model Number

**JK-115C-WH / JK-115C-GR / JK-115C-O**

# Quick Start Guide

Please read the full instruction manual thoroughly before use. It contains comprehensive usage instructions and important safety advice. This quick start guide only contains basic instructions.




## Step 1

Open the lid and fill the kettle with water. Do not fill above the MAX or below the MIN line.



## Step 2

Position the kettle on the power base and ensure the lid is closed.



## Step 3

Plug the kettle base into the power outlet and press the power switch down.



## Step 4

The kettle will turn off automatically when the water has boiled.

## CAUTION!

Take care when pouring boiling water to avoid scalding. Do not open the lid while the water in the kettle is hot. If refilling after boiling water, pull the lid straight up and move it out of the steam as soon as it separates from the kettle.



For more information  
please visit [www.stirlingappliances.com.au](http://www.stirlingappliances.com.au)  
or call 1300 112 534

Model Number	JK-115C-WH JK-115C-GR JK-115C-O
Product Code	709609
Warranty	1 Year
QSG-Version	1.0