



EQUIPMENT COMPATIBILITY GUIDE

EDITION
03/2024

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U8015BL WHEELED MIDI CONTROLLER CASE 21" 36 (W) x 56 (H) x 10.5 (D) cm 14.2 x 22 x 4.1 inch	PIONEER DDJ-FLX4 48.2 (W) x 27.3 (H) x 5.9 (D) cm 18.9 x 10.7 x 2.3 inch	PIONEER DDJ-REV1 52.6 (W) x 25.6 (H) x 5.9 (D) cm 20.7 x 10.1 x 2.3 inch	PIONEER DJM-S11 45.2 (W) x 26.7 (H) x 10.8 (D) cm 17.8 x 10.5 x 4.3 inch	ALPHATHETA OMNIS-DUO NEW 50.0 (W) x 30.7 (H) x 7.1 (D) cm 19.7 x 12.1 x 2.8 inch	NUMARK MIXTRACK PLATINUM FX 53.6(W) x 24.6 (H) x 5.1 (D) cm 21.1 x 9.7 x 2.0 inch
	DENON PRIME GO 41.1(W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	NI TRAKTOR S3 54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch	NI TRAKTOR S4 MK3 54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch	NI TRAKTOR S2 MK3 48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch	17" laptop and small gears
U8301BL CONTROLLER HARDCASE MEDIUM BLACK MK2 47 (W) x 34 (H) x 7.8 (D) cm 18.5 x 13.4 x 3.1 inch	DENON PRIME GO 41.1(W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	PIONEER DDJ-200 37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch	RELOOP READY 32.5 (W) x 22.0 (H) x 4.8 (D) cm 12.8 x 8.7 x 1.9 inch	AKAI APC64 37.1(W) x 27.2 (H) x 3.5 (D) cm 14.6 x 10.7 x 1.4 inch	AKAI MPC LIVE II 41.2(W) x 24.4 (H) x 4.6 (D) cm 16.2 x 9.6 x 1.8 inch
	NUMARK PARTY MIX LIVE 32.5(W) x 25.6 (H) x 6.6 (D) cm 12.8 x 10.1 x 2.6 inch	ROLAND SH-4D 36.0 (W) x 19.5 (H) x 6.6 (D) cm 14.2 x 7.7 x 2.6 inch	NOVATION LAUNCHKEY 25 MK3 46.3 (W) x 25.8 (H) x 7.7 (D) cm 18.2 x 10.1 x 3.1 inch	SSL UF8 NEW 43.1 (W) x 26.6 (H) x 6.3 (D) cm 16.9 x 10.5 x 2.5 inch	M-AUDIO OXYGEN PRO MINI 40.1 (W) x 19.0 (H) x 6.0 (D) cm 15.8 x 7.5 x 2.4 inch
U8302BL CONTROLLER HARDCASE LARGE BLACK MK2 59.3 (W) x 35.3 (H) x 8.4 (D) cm 23.3 x 13.9 x 3.3 inch	PIONEER DDJ-FLX4 48.2 (W) x 27.3 (H) x 5.9 (D) cm 18.9 x 10.7 x 2.3 inch	PIONEER DDJ-REV1 52.6 (W) x 25.6 (H) x 5.9 (D) cm 20.7 x 10.1 x 2.3 inch	ALPHATHETA OMNIS-DUO NEW 50.0 (W) x 30.7 (H) x 7.1 (D) cm 19.7 x 12.1 x 2.8 inch	NUMARK MIXSTREAM PRO+ 56.6 (W) x 28.4 (H) x 7.4 (D) cm 22.3 x 11.2 x 2.9 inch	NUMARK MIXTRACK PLATINUM FX 53.6(W) x 24.6 (H) x 5.1 (D) cm 21.1 x 9.7 x 2.0 inch
	NI TRAKTOR S3 54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch	NI TRAKTOR S4 MK3 54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch	NI TRAKTOR S2 MK3 48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch	NOVATION FLKEY 37 55.5 (W) x 25.8 (H) x 7.7 (D) cm 21.8 x 10.2 x 3.0 inch	KORG KINGKORG NEO NEW 56.5 (W) x 33.8 (H) x 9.2 (D) cm 22.2 x 13.3 x 3.6 inch
U8303BL CONTROLLER HARDCASE EXTRA LARGE BLACK MK2 71.5 (W) x 41.5 (H) x 10.0 (D) cm 28.2 x 16.3 x 3.9 inch	PIONEER DDJ-FLX6 67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	PIONEER DDJ-800 63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch	PIONEER XDJ-RR 62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch	PIONEER DDJ-1000SRT 70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch	NUMARK NS4FX 59.7 (W) x 27.4 (D) x 6.1 (D) cm 23.5 x 10.8 x 2.4 inch
	DENON SC LIVE 2 65.3 (W) x 39.1 (H) x 9.9 (D) cm 25.7 x 15.4 x 3.9 inch	DENON MC7000 66.4 (W) x 37.8 (H) x 6.8 (D) cm 26.1 x 14.9 x 2.7 inch	RELOOP MIXON 8 PRO 65.7 (W) x 39.1 (H) x 6.8 (D) cm 25.8 x 15.4 x 2.7 inch	AKAI MPC KEY 37 NEW 58.2 (W) x 31.4 (H) x 10.4 (D) cm 22.9 x 12.4 x 4.1 inch	NUMARK NS6II 60 (W) x 33 (D) x 6.7 (D) cm 23.6 x 13 x 2.6 inch

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U8304BL PIONEER DDJ-REV5 2XL MK2  91.1 (W) x 48 (H) x 8.5 (D) cm 35.9 x 18.9 x 3.4 inch	PIONEER DDJ-REV5  73.6 (W) x 37.7 (H) x 7.3 (D) cm 28.9 x 14.8 x 2.8 inch	PIONEER DDJ-FLX10  71.6 (W) x 40.1 (H) x 7.4 (D) cm 28.2 x 15.8 x 2.9 inch	PIONEER DDJ-REV7  73.2 (W) x 38.2 (H) x 8.2 (D) cm 28.8 x 15.0 x 3.2 inch	PIONEER DDJ-RZ  87 (W) x 42 (H) x 9.84 (D) cm 34.3 x 16.5 x 3.9 inch	PIONEER DDJ-SZ2  87 (W) x 42 (H) x 9.8 (D) cm 34.3 x 16.5 x 3.9 inch
	PIONEER XDJ-RX3  72.8 (W) x 47.0 (H) x 11.8 (D) cm 28.6 x 18.5 x 4.6 inch	DENON SC LIVE 4  71.9 (W) x 40.4 (H) x 9.9 (D) cm 28.3 x 15.9 x 3.9 inch	RANE FOUR  78.2 (W) x 40.4 (H) x 10.7 (D) cm 30.8 x 15.9 x 4.2 inch		
U8305BL PIONEER DDJ-FLX10/ DENON MCX8000/ RELOOP MIXON 8 PRO HARDCASE  76.2 (W) x 45.7 (H) x 12.1 (D) cm 30 x 18 x 4.7 inch	PIONEER DDJ-REV5  73.6 (W) x 37.7 (H) x 7.3 (D) cm 28.9 x 14.8 x 2.8 inch	PIONEER DDJ-FLX10  71.6 (W) x 40.1 (H) x 7.4 (D) cm 28.2 x 15.8 x 2.9 inch	PIONEER DDJ-FLX6  67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	PIONEER DDJ-1000SRT  70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch	RELOOP MIXON 8 PRO  65.7 (W) x 39.1 (H) x 6.8 (D) cm 25.8 x 15.4 x 2.7 inch
	DENON MCX8000  72.8 (W) x 43.3 (H) x 7 (D) cm 28.6 x 17 x 2.7 inch	HERCULES DJCONTROL IMPULSE T7  65.2 (W) x 35.0 (H) x 9.0 (D) cm 25.7 x 13.8 x 3.5 inch	ROLAND DJ-808  66.8 (W) x 42.7 (H) x 8.4 (D) cm 26.3 x 16.8 x 3.3 inch		
U8306BL 49 KEYBOARD HARDCASE  88.0 (W) x 31.0 (H) x 11.0 (D) cm 34.6 x 11.8 x 4.3 inch	NI KOMplete KONTROL A49  82 (W) x 25.7 (H) x 8.9 (D) cm 32.3 x 10.1 x 3.5 inch	NOVATION FLKEY 49  78.9 (W) x 25.8 (H) x 7.7 (D) cm 31.1 x 10.1 x 3.1 inch	NOVATION LAUNCHKEY 49 MK3  78.9 (W) x 25.8 (H) x 7.7 (D) cm 31.1 x 10.1 x 3.1 inch	AKAI MPK249  73.7 (W) x 29.8 (H) x 9.2 (D) cm 29 x 12.3 x 3.4 inch	KORG KEYSTAGE-49  81.4 (W) x 23.4 (H) x 8.2 (D) cm 32.0 x 9.2 x 3.2 inch
	ROLAND GO:PIANO  87.7 (W) x 27.1 (H) x 8.2 (D) cm 34.5 x 10.7 x 3.2 inch	M - AUDIO OXYGEN 49 MKV  81.4 (W) x 24.3 (H) x 9.4 (D) cm 32.0 x 9.5 x 3.7 inch	M - AUDIO KEYSTATION 49 MK3  82.2 (W) x 18.9 (H) x 6.8 (D) cm 32.3 x 7.4 x 2.7 inch	ARTURIA KEYLAB ESSENTIAL 49 MK3  79.0 (W) x 24.0 (H) x 7.0 (D) cm 31.1 x 9.4 x 2.7 inch	ALESIS V49 MKII  81.2 (W) x 24.4 (H) x 9.4 (D) cm 32.0 x 9.6 x 3.7 inch
U8307BL 61 KEYBOARD HARDCASE  106.0 (W) x 42.0 (H) x 13.8 (D) cm 41.7 x 16.5 x 5.4 inch	NI KONTROL S49 MK3  80.2 (W) x 32.3 (H) x 8.6 (D) cm 31.5 x 12.7 x 3.4 inch	NI KONTROL S61 MK3  96.7 (W) x 32.3 (H) x 8.6 (D) cm 38.1 x 12.7 x 3.4 inch	NI KOMplete KONTROL A61  98.4 (W) x 25.7 (H) x 8.9 (D) cm 38.7 x 10.1 x 3.5 inch	AKAI MPC KEY 61  98.6 (W) x 31.3 (H) x 9.7 (D) cm 38.8 x 12.3 x 3.8 inch	ARTURIA KEYLAB ESSENTIAL 61 MK3  89.0 (W) x 24.0 (H) x 7.0 (D) cm 35.0 x 9.4 x 2.7 inch
	NOVATION FLKEY 61  95.2 (W) x 25.8 (H) x 7.7 (D) cm 37.5 x 10.1 x 3.1 inch	NOVATION 61SL MKIII  98.1 (W) x 30 (H) x 10 (D) cm 38.6 x 11.8 x 3.9 inch	KORG EK-50 CSA (61 KEYS)  99.4 (W) x 39.2 (H) x 13.2 (D) cm 39.1 x 15.4 x 5.2 inch	KORG OPSIX SE (61 KEYS)  101.4 (W) x 34.4 (H) x 10.8 (D) cm 39.9 x 13.5 x 4.2 inch	KORG WAVESTATE SE (61 KEYS)  101.4 (W) x 34.4 (H) x 11.0 (D) cm 39.9 x 13.5 x 4.3 inch

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U8308BL TURNTABLE HARDCASE  46 (W) x 37.5 (H) x 17 (D) cm 18.1 x 14.7 x 6.7 inch	PIONEER CDJ-3000  45.3 (W) x 32.9 (H) x 11.8 (D) cm 17.8 x 12.9 x 4.6 inch	PIONEER PLX-CRSS12  45.3 (W) x 35.3 (H) x 15.9 (D) cm 17.8 x 13.8 x 6.3 inch	PIONEER PLX-1000  45.3 (W) x 35.3 (H) x 15.9 (D) cm 17.8 x 13.8 x 6.3 inch	RELOOP RP-8000 MK2  45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch	STANTON STR8. 150 M2  45 (W) x 35.3 (H) x 14.6 (D) cm 17.7 x 13.9 x 5.7 inch
	DENON SC6000 PRIME  46.3 (W) x 32.0 (H) x 15.1 (D) cm 18.2 x 12.6 x 5.9 inch	DENON VL12 PRIME  45.1 (W) x 35.5 (H) x 15 (D) cm 17.7 x 13.9 x 5.9 inch	TECHNICS SL-1210GR2  45.3 (W) x 37.2 (H) x 17.3 (D) cm 17.8 x 14.6 x 6.8 inch	TECHNICS SL-1200GR2  45.3 (W) x 35.3 (H) x 17.3 (D) cm 17.8 x 13.9 x 6.8 inch	TECHNICS SL-1500C  45.3 (W) x 37.2 (H) x 16.9 (D) cm 17.8 x 14.6 x 6.6 inch
U8443BL CDJ/ DJM/ BATTLE MIXER HARDCASE MK2  42.0 (W) x 35.0 (H) x 13.5 (D) cm 16.5 x 13.8 x 5.3 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER DJM-S7  39.7 (W) x 26.7 (H) x 10.8 (D) cm 15.6 x 10.5 x 4.2 inch	PIONEER DJS-1000  42.2 (W) x 32 (H) x 11 (D) cm 16.6 x 12.5 x 4.3 inch	PIONEER DJM-900NXS2  41.4 (W) x 33.3 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch	SSL SIX NEW  31.0 (W) x 27.0 (H) x 12.0 (D) cm 12.2 x 10.6 x 4.7 inch
	RELOOP RMX-95  38.7 (W) x 32.2 (H) x 10.8 (D) cm 15.2 x 12.7 x 4.2 inch	RELOOP RMX-44 BT  38.0 (W) x 32.0 (H) x 10.7 (D) cm 14.9 x 12.6 x 4.2 inch	RELOOP ELITE  41.4 (W) x 29 (H) x 10.8 (D) cm 16.3 x 11.4 x 4.3 inch	DENON SC5000 PRIME  32 (W) x 41.9 (H) x 13.5 (D) cm 12.6 x 16.5 x 5.3 inch	ECLER WARM4  37.2 (W) x 34.0 (H) x 10.1 (D) cm 14.6 x 13.4 x 3.9 inch
U7101BL MIDI CONTROLLER SLEEVE MEDIUM  53 (W) x 34 (H) x 9 (D) cm 20.8 x 13.4 x 3.5 inch	PIONEER DDJ-FLX4  48.2 (W) x 27.3 (H) x 5.9 (D) cm 18.9 x 10.7 x 2.3 inch	PIONEER DDJ-REV1  52.6 (W) x 25.6 (H) x 5.9 (D) cm 20.7 x 10.1 x 2.3 inch	ALPHATHETA OMNIS-DUO NEW  50.0 (W) x 30.7 (H) x 7.1 (D) cm 19.7 x 12.1 x 2.8 inch	NI TRAKTOR S2 MK3  48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch	NOVATION AFX STATION  46.0 (W) x 27.6 (H) x 8.0 (D) cm 18.1 x 10.9 x 3.1 inch
	DENON PRIME GO  41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	NUMARK MIXSTREAM PRO+  56.6 (W) x 28.4 (H) x 7.4 (D) cm 22.3 x 11.2 x 2.9 inch	NUMARK MIXTRACK PLATINUM FX  53.6 (W) x 24.6 (H) x 5.1 (D) cm 21.1 x 9.7 x 2.0 inch	ROLAND DJ-707M  47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch	KORG MICROKORG NEW  54.2 (W) x 23.8 (H) x 6.5 (D) cm 21.3 x 9.4 x 2.6 inch
U7102BL MIDI CONTROLLER SLEEVE LARGE  70 (W) x 40 (H) x 11 (D) cm 27.6 x 15.7 x 4.3 inch	DENON SC LIVE 2  65.3 (W) x 39.1 (H) x 9.9 (D) cm 25.7 x 15.4 x 3.9 inch	PIONEER DDJ-FLX6  67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	PIONEER DDJ-800  63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch	PIONEER XDJ-RR  62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch	KORG KINGKORG NEO NEW  56.5 (W) x 33.8 (H) x 9.2 (D) cm 22.2 x 13.3 x 3.6 inch
	NI TRAKTOR S3  54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch	NI TRAKTOR S4 MK3  54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch	NUMARK NS4FX  59.7 (W) x 27.4 (D) x 6.1 (D) cm 23.5 x 10.8 x 2.4 inch	AKAI MPC KEY 37 NEW  58.2 (W) x 31.4 (H) x 10.4 (D) cm 22.9 x 12.4 x 4.1 inch	HERCULES DJCONTROL IMPULSE T7  65.2 (W) x 35.0 (H) x 9.0 (D) cm 25.7 x 13.8 x 3.5 inch

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U7103BL MIDI CONTROLLER SLEEVE EXTRA LARGE  89.2 (W) x 46.2 (H) x 10.5 (D) cm 35.1 x 18.2 x 4.1 inch	PIONEER DDJ-REV5  73.6 (W) x 37.7 (H) x 7.3 (D) cm 28.9 x 14.8 x 2.8 inch	PIONEER DDJ-FLX10  71.6 (W) x 40.1 (H) x 7.4 (D) cm 28.2 x 15.8 x 2.9 inch	PIONEER DDJ-REV7  73.2 (W) x 38.2 (H) x 8.2 (D) cm 28.8 x 15.0 x 3.2 inch	PIONEER XDJ-RX3  72.8 (W) x 47.0 (H) x 11.8 (D) cm 28.6 x 18.5 x 4.6 inch	PIONEER XDJ-XZ  87.8 (W) x 46.6 (H) x 11.8 (D) cm 34.5 x 18.3 x 4.6 inch
	DENON SC LIVE 4  71.9 (W) x 40.4 (H) x 9.9 (D) cm 28.3 x 15.9 x 3.9 inch	DENON MCX8000  72.8 (W) x 43.3 (H) x 7 (D) cm 28.6 x 17 x 2.7 inch	RANE FOUR  78.2 (W) x 40.4 (H) x 10.7 (D) cm 30.8 x 15.9 x 4.2 inch		
U7202BL MIDI CONTROLLER BACKPACK LARGE BLACK  70 (W) x 40 (H) x 10 (D) cm 27.6 x 15.7 x 3.9 inch	DENON SC LIVE 2  65.3 (W) x 39.1 (H) x 9.9 (D) cm 25.7 x 15.4 x 3.9 inch	PIONEER DDJ-FLX6  67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	PIONEER DDJ-800  63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch	PIONEER XDJ-RR  62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch	PIONEER DDJ-1000SRT  70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch
	NUMARK NS4FX  59.7 (W) x 27.4 (D) x 6.1 (D) cm 23.5 x 10.8 x 2.4 inch	RANE ONE  67.4 (W) x 34.5 (H) x 12.4 (D) cm 26.5 x 13.6 x 4.8 inch	KORG KINGKORG NEO  56.5 (W) x 33.8 (H) x 9.2 (D) cm 22.2 x 13.3 x 3.6 inch	DENON MC7000  66.4 (W) x 37.8 (H) x 6.8 (D) cm 26.1 x 14.9 x 2.7 inch	 18.4" laptop and small gears
U7203BL MIDI CONTROLLER BACKPACK EXTRA LARGE BLACK  73.3 (W) x 50.1 (H) x 10.2 (D) cm 28.9 x 19.7 x 4 inch	PIONEER DDJ-REV5  73.6 (W) x 37.7 (H) x 7.3 (D) cm 28.9 x 14.8 x 2.8 inch	PIONEER DDJ-FLX10  71.6 (W) x 40.1 (H) x 7.4 (D) cm 28.2 x 15.8 x 2.9 inch	PIONEER DDJ-REV7  73.2 (W) x 38.2 (H) x 8.2 (D) cm 28.8 x 15.0 x 3.2 inch	PIONEER XDJ-RX3  72.8 (W) x 47.0 (H) x 11.8 (D) cm 28.6 x 18.5 x 4.6 inch	ROLAND DJ-808  66.8 (W) x 42.7 (H) x 8.4 (D) cm 26.3 x 16.8 x 3.3 inch
	DENON SC LIVE 4  71.9 (W) x 40.4 (H) x 9.9 (D) cm 28.3 x 15.9 x 3.9 inch	DENON PRIME 4+  72.9 (W) x 49.7 (H) x 10.4 (D) cm 28.7 x 19.5 x 4.1 inch	DENON MCX8000  72.8 (W) x 43.3 (H) x 7 (D) cm 28.6 x 17 x 2.7 inch		 18.4" laptop and small gears
U9022BL/OR PRODUCER BAG LARGE BLACK, ORANGE INSIDE  32 (W) x 46.5 (H) x 15 (D) cm 12.6 x 18.3 x 5.9 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER DJM-S11  45.2 (W) x 26.7 (H) x 10.8 (D) cm 17.8 x 10.5 x 4.3 inch	PIONEER DDJ-XP2  33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch	PIONEER DDJ-200  37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch	DENON PRIME GO  41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch
	RELOOP RMX-95  38.7 (W) x 32.2 (H) x 10.8 (D) cm 15.2 x 12.7 x 4.2 inch	AKAI MPC LIVE II  41.2 (W) x 24.4 (H) x 4.6 (D) cm 16.2 x 9.6 x 1.8 inch	RANE SEVENTY-TWO MKII  44.5 (W) x 28 (H) x 9 (D) cm 17.5 x 11 x 3.5 inch	RELOOP BUDDY  32.5 (W) x 22.0 (H) x 4.8 (D) cm 12.8 x 8.7 x 1.9 inch	 18.4" laptop and small gears

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U9024BL/OR PRODUCER BACKPACK TROLLEY BLACK ORANGE INSIDE  35 (W) x 45.5 (H) x 15.5 (D) cm 13.8 x 17.9 x 6.1 inch	PIONEER CDJ-3000  45.3 (W) x 32.9 (H) x 11.8 (D) cm 17.8 x 12.9 x 4.6 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER DJM-S11  45.2 (W) x 26.7 (H) x 10.8 (D) cm 17.8 x 10.5 x 4.3 inch	PIONEER DDJ-200  37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch	ECLER WARM4  37.2 (W) x 34.0 (H) x 10.1 (D) cm 14.6 x 13.4 x 3.9 inch
	ABLETON PUSH 3  38.0 (W) x 31.8 (H) x 4.5 (D) cm 14.9 x 12.5 x 1.8 inch	AKAI MPC LIVE II  41.2 (W) x 24.4 (H) x 4.6 (D) cm 16.2 x 9.6 x 1.8 inch	DENON PRIME GO  41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	RELOOP RMX-95  38.7 (W) x 32.2 (H) x 10.8 (D) cm 15.2 x 12.7 x 4.2 inch	 18.4" laptop and small gears
U9101BL/OR DIGI BACKPACK BLACK, ORANGE INSIDE  30 (W) x 42 (H) x 13 (D) cm 11.8 x 16.5 x 5.1 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER DDJ-XP2  33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch	PIONEER DDJ-200  37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch	NUMARK PARTY MIX LIVE  32.5 (W) x 25.6 (H) x 6.6 (D) cm 12.8 x 10.1 x 2.6 inch	NUMARK PTO1 SCRATCH  30.2 (W) x 30.2 (H) x 10.2 (D) cm 11.9 x 11.9 x 4 inch
	AKAI APC64  37.1 (W) x 27.2 (H) x 3.5 (D) cm 14.6 x 10.7 x 1.4 inch	AKAI MPC ONE+  27.2 (W) x 27.2 (H) x 5.3 (D) cm 10.7 x 10.7 x 2.1 inch	AKAI MPC LIVE II  41.2 (W) x 24.4 (H) x 4.6 (D) cm 16.2 x 9.6 x 1.8 inch	RELOOP READY  32.5 (W) x 22.0 (H) x 4.8 (D) cm 12.8 x 8.7 x 1.9 inch	 15.4" laptop and small gears
U9102BL/OR BACKPACK BLACK, ORANGE INSIDE  33 (W) x 40 (H) x 14 (D) cm 13 x 15.7 x 5.5 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER DDJ-XP2  33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch	PIONEER DDJ-200  37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch	NUMARK PARTY MIX LIVE  32.5 (W) x 25.6 (H) x 6.6 (D) cm 12.8 x 10.1 x 2.6 inch	NUMARK PTO1 SCRATCH  30.2 (W) x 30.2 (H) x 10.2 (D) cm 11.9 x 11.9 x 4 inch
	AKAI APC64  37.1 (W) x 27.2 (H) x 3.5 (D) cm 14.6 x 10.7 x 1.4 inch	AKAI MPC ONE+  27.2 (W) x 27.2 (H) x 5.3 (D) cm 10.7 x 10.7 x 2.1 inch	AKAI MPC LIVE II  41.2 (W) x 24.4 (H) x 4.6 (D) cm 16.2 x 9.6 x 1.8 inch	RELOOP READY  32.5 (W) x 22.0 (H) x 4.8 (D) cm 12.8 x 8.7 x 1.9 inch	 15.4" laptop and small gears
U9103BL/OR MIDI CONTROLLER BACKPACK SMALL MK2 BLACK/ORANGE  56.5 (W) x 35.5 (H) x 12 (D) cm 22.2 x 13.9 x 4.7 inch	PIONEER DDJ-REV1  52.6 (W) x 25.6 (H) x 5.9 (D) cm 20.7 x 10.1 x 2.3 inch	ALPHATHETA OMNIS-DUO NEW  50.0 (W) x 30.7 (H) x 7.1 (D) cm 19.7 x 12.1 x 2.8 inch	DENON PRIME GO  41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	KORG MICROKORG NEW  54.2 (W) x 23.8 (H) x 6.5 (D) cm 21.3 x 9.4 x 2.6 inch	KORG KINGKORG NEO NEW  56.5 (W) x 33.8 (H) x 9.2 (D) cm 22.2 x 13.3 x 3.6 inch
	NI TRAKTOR S3  54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch	NI TRAKTOR S4 MK3  54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch	NI TRAKTOR S2 MK3  48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch	NUMARK MIXTRACK PLATINUM FX  53.6 (W) x 24.6 (H) x 5.1 (D) cm 21.1 x 9.7 x 2.0 inch	 17" laptop and small gears

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U9104BL/OR MIDI CONTROLLER BACKPACK LARGE MK2 BLACK/ORANGE  68.5 (W) x 39 (H) x 13 (D) cm 26.9 x 15.4 x 5.1 inch	PIONEER DDJ-FLX6  67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	PIONEER DDJ-800  63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch	PIONEER XDJ-RR  62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch	NUMARK NS6II  60 (W) x 33 (D) x 6.7 (D) cm 23.6 x 13 x 2.6 inch	RANE ONE  67.4 (W) x 34.5 (H) x 12.4 (D) cm 26.5 x 13.6 x 4.8 inch
	DENON SC LIVE 2  65.3 (W) x 39.1 (H) x 9.9 (D) cm 25.7 x 15.4 x 3.9 inch	DENON MC7000  66.4 (W) x 37.8 (H) x 6.8 (D) cm 26.1 x 14.9 x 2.7 inch	RELOOP MIXON 8 PRO  65.7 (W) x 39.1 (H) x 6.8 (D) cm 25.8 x 15.4 x 2.7 inch	AKAI MPC KEY 37  58.2 (W) x 31.4 (H) x 10.4 (D) cm 22.9 x 12.4 x 4.1 inch	 18.4" laptop and small gears
U9108BL/OR BACKPACK SLIM BLACK, ORANGE INSIDE  33 (W) x 40 (H) x 14 (D) cm 13 x 15.7 x 5.5 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER DJM-S7  39.7 (W) x 26.7 (H) x 10.8 (D) cm 15.6 x 10.5 x 4.3 inch	PIONEER DDJ-XP2  33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch	PIONEER DDJ-200  37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch	RELOOP READY  32.5 (W) x 22.0 (H) x 4.8 (D) cm 12.8 x 8.7 x 1.9 inch
	AKAI APC64  37.1 (W) x 27.2 (H) x 3.5 (D) cm 14.6 x 10.7 x 1.4 inch	AKAI MPC ONE+  27.2 (W) x 27.2 (H) x 5.3 (D) cm 10.7 x 10.7 x 2.1 inch	NUMARK PARTY MIX LIVE  32.5 (W) x 25.6 (H) x 6.6 (D) cm 12.8 x 10.1 x 2.6 inch	NUMARK PT01 SCRATCH  30.2 (W) x 30.2 (H) x 10.2 (D) cm 11.9 x 11.9 x 4 inch	 15.4" laptop and small gears
U91014BL3 / U92014SL FLIGHT CASE MULTI FORMAT XXL PLUS (LAPTOP SHELF)  73 (W) x 42 (H) x 5.3 (D) cm 28.7 x 16.5 x 2.1 inch	PIONEER DDJ-REV7  73.2 (W) x 38.2 (H) x 8.2 (D) cm 28.8 x 15.0 x 3.2 inch	PIONEER DDJ-REV5  73.6 (W) x 37.7 (H) x 7.3 (D) cm 28.9 x 14.8 x 2.8 inch	PIONEER DDJ-800  63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch	PIONEER XDJ-RR  62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch	PIONEER DDJ-1000SRT  70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch
	PIONEER DDJ-FLX10  71.6 (W) x 40.1 (H) x 7.4 (D) cm 28.2 x 15.8 x 2.9 inch	PIONEER DDJ-FLX6  67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	DENON SC LIVE 2  65.3 (W) x 39.1 (H) x 9.9 (D) cm 25.7 x 15.4 x 3.9 inch	DENON SC LIVE 4  71.9 (W) x 40.4 (H) x 9.9 (D) cm 28.3 x 15.9 x 3.9 inch	 18.4" laptop and small gears
U91019BL3 / U92019SL FLIGHT CASE MULTI FORMAT XL PLUS (LAPTOP SHELF)  55.5 (W) x 33.7 (H) x 4.5 (D) cm 21.8 x 13.3 x 1.8 inch	PIONEER DDJ-FLX4  48.2 (W) x 27.3 (H) x 5.9 (D) cm 18.9 x 10.7 x 2.3 inch	PIONEER DDJ-REV1  52.6 (W) x 25.6 (H) x 5.9 (D) cm 20.7 x 10.1 x 2.3 inch	ALPHATHETA OMNIS-DUO  50.0 (W) x 30.7 (H) x 7.1 (D) cm 19.7 x 12.1 x 2.8 inch	DENON PRIME GO  41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	DENON MC4000  50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch
	NUMARK MIXTRACK PLATINUM FX  53.6 (W) x 24.6 (H) x 5.1 (D) cm 21.1 x 9.7 x 2.0 inch	NI TRAKTOR S3  54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch	NI TRAKTOR S4 MK3  54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch	NI TRAKTOR S2 MK3  48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch	 18.4" laptop and small gears

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U91021BL3 / U92021SL3 FLIGHT CASE MULTI FORMAT CDJ/ MIXER MK3  33.5 (W) x 50.9 (D) x 7.8 (D) cm 13.2 x 20.0 x 3.1 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER CDJ-3000  45.3 (W) x 32.9 (H) x 11.8 (D) cm 17.8 x 12.9 x 4.6 inch	PIONEER DJM-S11  45.2 (W) x 26.7 (H) x 10.8 (D) cm 17.8 x 10.5 x 4.3 inch	PIONEER DJM-900NXS2  41.4 (W) x 33.3 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch	PIONEER CDJ-2000NXS2  41.4 (W) x 32 (H) x 11.3 (D) cm 15.9 x 12.5 x 4.4 inch
	DENON SC6000 PRIME  46.3 (W) x 32 (H) x 15.1 (D) cm 18.2 x 12.6 x 5.9 inch	DENON X1850 PRIME  44.8 (W) x 30.9 (H) x 11 (D) cm 17.6 x 12.2 x 4.3 inch	DENON SC5000 PRIME  32 (W) x 41.9 (H) x 13.5 (D) cm 12.6 x 16.5 x 5.3 inch	RELOOP RMX-95  38.7 (W) x 32.2 (H) x 10.8 (D) cm 15.2 x 12.7 x 4.2 inch	RANE SEVENTY-TWO MKII  44.5 (W) x 28.5 (H) x 10.5 (D) cm 17.5 x 11.2 x 4.1 inch
U91030BL2 / U92030SL / U91029BL2 / U92029SL FLIGHT CASE MULTI FORMAT TURNTABLE / PLUS (TROLLEY & WHEELS)  45.5 (W) x 36.5 (H) x 8.4 (D) cm 17.9 x 14.4 x 3.3 inch	RELOOP RP-8000 MK2  45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch	RELOOP RP-7000 MK2  45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch	AUDIOTECHNICALP120XUSB  45.2 (W) x 35.2 (H) x 14.2 (D) cm 17.8 x 13.8 x 5.6 inch	TECHNICS SL-1210GR2  45.3 (W) x 37.2 (H) x 17.3 (D) cm 17.8 x 14.6 x 6.8 inch	TECHNICS SL-1200GR2  45.3 (W) x 35.3 (H) x 17.3 (D) cm 17.8 x 13.9 x 6.8 inch
	PIONEER PLX-CRSS12  45.3 (W) x 35.3 (H) x 15.9 (D) cm 17.8 x 13.8 x 6.3 inch	PIONEER PLX-1000  45.3 (W) x 35.3 (H) x 15.9 (D) cm 17.8 x 13.8 x 6.3 inch	DENON VL12 PRIME  45.1 (W) x 35.5 (H) x 15 (D) cm 17.7 x 13.9 x 5.9 inch	STANTON STR8. 150 M2  45 (W) x 35.3 (H) x 14.6 (D) cm 17.7 x 13.9 x 5.7 inch	GEMINI TT-4000  42.8 (W) x 34.9 (H) x 9.0 (D) cm 16.8 x 13.7 x 3.5 inch
U91054BL / U92054SL FLIGHT CASE MULTI FORMAT XXL PLUS (LAPTOP SHELF + TROLLEY + WHEELS)  73 (W) x 42 (H) x 5.3 (D) cm 28.7 x 16.5 x 21 inch	PIONEER DDJ-REV5  73.6 (W) x 37.7 (H) x 7.3 (D) cm 28.9 x 14.8 x 2.8 inch	PIONEER DDJ-REV7  73.2 (W) x 38.2 (H) x 8.2 (D) cm 28.8 x 15.0 x 3.2 inch	PIONEER DDJ-FLX10  71.6 (W) x 40.1 (H) x 7.4 (D) cm 28.2 x 15.8 x 2.9 inch	PIONEER DDJ-FLX6  67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	PIONEER DDJ-800  63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch
	DENON SC LIVE 2  65.3 (W) x 39.1 (H) x 9.9 (D) cm 25.7 x 15.4 x 3.9 inch	DENON SC LIVE 4  71.9 (W) x 40.4 (H) x 9.9 (D) cm 28.3 x 15.9 x 3.9 inch	RELOOP MIXON 8 PRO  65.7 (W) x 39.1 (H) x 6.8 (D) cm 25.8 x 15.4 x 2.7 inch	KORG KINGKORG NEO  56.5 (W) x 33.8 (H) x 9.2 (D) cm 22.2 x 13.3 x 3.6 inch	18.4"  18.4" laptop and small gears
U91059BL / U92059SL FLIGHT CASE MULTI FORMAT XL PLUS (LAPTOP SHELF + TROLLEY + WHEELS)  55.5 (W) x 33.7 (H) x 4.5 (D) cm 21.8 x 13.3 x 1.8 inch	PIONEER DDJ-FLX4  48.2 (W) x 27.3 (H) x 5.9 (D) cm 18.9 x 10.7 x 2.3 inch	PIONEER DDJ-REV1  52.6 (W) x 25.6 (H) x 5.9 (D) cm 20.7 x 10.1 x 2.3 inch	DENON PRIME GO  41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	DENON MC4000  50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch	KORG MICROKORG  54.2 (W) x 23.8 (H) x 6.5 (D) cm 21.3 x 9.4 x 2.6 inch
	NUMARK MIXTRACK PLATINUM FX  53.6 (W) x 24.6 (H) x 5.1 (D) cm 21.1 x 9.7 x 2.0 inch	NI TRAKTOR S3  54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch	NI TRAKTOR S4 MK3  54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch	NI TRAKTOR S2 MK3  48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch	18.4"  18.4" laptop and small gears

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U91070BL FLIGHT CASE MULTI FORMAT 3XL PLUS (WHEELS)  99.0 (W) x 64.6 (D) x 24.4 (D) cm 38.9 x 25.4 x 9.6 inch	PIONEER XDJ-XZ  87.8 (W) x 46.6 (H) x 11.8 (D) cm 34.5 x 18.3 x 4.6 inch	PIONEER XDJ-RX3  72.8 (W) x 47.0 (H) x 11.8 (D) cm 28.6 x 18.5 x 4.6 inch	PIONEER DDJ-RZX  94.5 (W) x 54.7 (H) x 12.0 (D) cm 37.2 x 21.5 x 4.7 inch	PIONEER DDJ-SZ2  87.0 (W) x 42.0 (H) x 9.8 (D) cm 34.3 x 16.5 x 3.9 inch	PIONEER DDJ-RZ  87.0 (W) x 42.0 (H) x 9.8 (D) cm 34.3 x 16.5 x 3.9 inch
	RANE FOUR  78.2 (W) x 40.4 (H) x 10.7 (D) cm 30.8 x 15.9 x 4.2 inch	NUMARK NS7III  75.4 (W) x 46.2 (H) x 12.1 (D) cm 29.7 x 18.2 x 4.8 inch			
U93010 PICK FOAM FLIGHT CASE MULTI FORMAT S  39.1 (W) x 31.1 (D) x 18.5 (D) cm 15.4 x 12.2 x 7.3 inch	PIONEER DJM-S5  36.4 (W) x 24.5 (H) x 10.8 (D) cm 14.3 x 9.6 x 4.2 inch	PIONEER DDJ-XP2  33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch	PIONEER DDJ-200  37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch	AKAI MPC STUDIO  30.5 (W) x 17.1 (H) x 3.7 (D) cm 12.0 x 6.7 x 1.4 inch	AKAI MPK MINI MK3  31.8 (W) x 18.1 (H) x 4.4 (D) cm 12.5 x 7.1 x 1.7 inch
	NUMARK PARTY MIX LIVE  32.5 (W) x 25.6 (H) x 6.6 (D) cm 12.8 x 10.1 x 2.6 inch	NUMARK PT01 SCRATCH  30.2 (W) x 30.2 (H) x 10.2 (D) cm 11.9 x 11.9 x 4 inch	RELOOP READY  32.5 (W) x 22.0 (H) x 4.8 (D) cm 12.8 x 8.7 x 1.9 inch	NOVATION LAUNCHKEY MINI MKIII  33 (W) x 17.2 (H) x 3.1 (D) cm 12.9 x 6.7 x 1.2 inch	ROLAND SH-4D  36.0 (W) x 19.5 (H) x 6.6 (D) cm 14.2 x 7.7 x 2.6 inch
U93011 PICK FOAM FLIGHT CASE MULTI FORMAT M  47 (W) x 40.5 (H) x 14 (D) cm 18.5 x 15.9 x 5.5 inch	PIONEER CDJ-3000  45.3 (W) x 32.9 (H) x 11.8 (D) cm 17.8 x 12.9 x 4.6 inch	DENON PRIME GO  41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch	DENON SC6000 PRIME  46.3 (W) x 32 (H) x 15.1 (D) cm 18.2 x 12.6 x 5.9 inch	DENON X1850 PRIME  44.8 (W) x 30.9 (H) x 11 (D) cm 17.6 x 12.2 x 4.3 inch	DENON SC5000 PRIME  32 (W) x 41.9 (H) x 13.5 (D) cm 12.6 x 16.5 x 5.3 inch
	PIONEER DJM-S11  45.2 (W) x 26.7 (H) x 10.8 (D) cm 17.8 x 10.5 x 4.3 inch	AKAI MPC LIVE II  41.2 (W) x 24.4 (H) x 4.6 (D) cm 16.2 x 9.6 x 1.8 inch	RELOOP RMX-95  38.7 (W) x 32.2 (H) x 10.8 (D) cm 15.2 x 12.7 x 4.2 inch	RANE SEVENTY-TWO MKII  44.5 (W) x 28 (H) x 9 (D) cm 17.5 x 11 x 3.5 inch	RANE TWELVE MKII  41.3 (W) x 36.8 (H) x 9 (D) cm 16.2 x 14.5 x 3.5 inch
U93012 PICK FOAM FLIGHT CASE MULTI FORMAT L  53.5 (W) x 46.5 (H) x 14 (D) cm 21.1 x 18.3 x 5.5 inch	PIONEER DJM-A9  40.7 (W) x 45.8 (H) x 10.8 (D) cm 16.0 x 18.0 x 4.3 inch	PIONEER DDJ-FLX4  48.2 (W) x 27.3 (H) x 5.9 (D) cm 18.9 x 10.7 x 2.3 inch	PIONEER DDJ-REV1  52.6 (W) x 25.6 (H) x 5.9 (D) cm 20.7 x 10.1 x 2.3 inch	ALPHATHETA OMNIS-DUO NEW  50.0 (W) x 30.7 (H) x 7.1 (D) cm 19.7 x 12.1 x 2.8 inch	AKAI MPC X SE  50.5 (W) x 42.5 (H) x 8.8 (D) cm 19.9 x 16.7 x 3.4 inch
	NI TRAKTOR S2 MK3  48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch	NI KOMplete A25  48.8 (W) x 25.7 (H) x 8.9 (D) cm 19.2 x 10.1 x 3.5 inch	DENON MC4000  50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch	ROLAND DJ-707M  47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch	TASCAM MODEL 16 NEW  46.3 (W) x 43.0 (H) x 11.3 (D) cm 18.2 x 16.9 x 4.4 inch

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U93013 PICK FOAM FLIGHT CASE MULTI FORMAT XL  66.7 (W) x 44.2 (H) x 12 (D) cm 26.2 x 17.4 x 4.7 inch	PIONEER DDJ-800  63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch	PIONEER XDJ-RR  62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch	NUMARK MIXSTREAM PRO GO  56.6 (W) x 28.4 (H) x 7.4 (D) cm 22.3 x 11.2 x 2.9 inch	AKAI MPC KEY 37  58.2 (W) x 31.4 (H) x 10.4 (D) cm 22.9 x 12.4 x 4.1 inch	KORG KINGKORG NEO  56.5 (W) x 33.8 (H) x 9.2 (D) cm 22.2 x 13.3 x 3.6 inch
	DENON SC LIVE 2  65.3 (W) x 39.1 (H) x 9.9 (D) cm 25.7 x 15.4 x 3.9 inch	DENON MC7000  66.4 (W) x 37.8 (H) x 6.8 (D) cm 26.1 x 14.9 x 2.7 inch	NI TRAKTOR S3  54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch	NI TRAKTOR S4 MK3  54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch	RELOOP MIXON 8 PRO  65.7 (W) x 39.1 (H) x 6.8 (D) cm 25.8 x 15.4 x 2.7 inch
U93014 PICK FOAM FLIGHT CASE MULTI FORMAT 2XL MK2  80.1 (W) x 51.6 (H) x 17.6 (D) cm 31.5 x 20.3 x 6.9 inch	PIONEER DDJ-FLX10  71.6 (W) x 40.1 (H) x 7.4 (D) cm 28.2 x 15.8 x 2.9 inch	PIONEER DDJ-REV7  73.2 (W) x 38.2 (H) x 8.2 (D) cm 28.8 x 15.0 x 3.2 inch	PIONEER DDJ-FLX6  67.6 (W) x 34.6 (H) x 6.9 (D) cm 26.6 x 13.6 x 2.7 inch	PIONEER DDJ-1000SRT  70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch	PIONEER XDJ-RX3  72.8 (W) x 47.0 (H) x 11.8 (D) cm 28.6 x 18.5 x 4.6 inch
	PIONEER DDJ-REV5  73.6 (W) x 37.7 (H) x 7.3 (D) cm 28.9 x 14.8 x 2.8 inch	DENON SC LIVE 4  71.9 (W) x 40.4 (H) x 9.9 (D) cm 28.3 x 15.9 x 3.9 inch	DENON MCX8000  72.8 (W) x 43.3 (H) x 7 (D) cm 28.6 x 17 x 2.7 inch	RANE FOUR  78.2 (W) x 40.4 (H) x 10.7 (D) cm 30.8 x 15.9 x 4.2 inch	RANE ONE  67.4 (W) x 34.5 (H) x 12.4 (D) cm 26.5 x 13.6 x 4.8 inch
U93015 PICK FOAM FLIGHT CASE MULTI FORMAT 3XL MK2  92.8 (W) x 51.6 (H) x 12.0 (D) cm 36.5 x 20.3 x 4.7 inch	PIONEER XDJ-RX3  72.8 (W) x 47.0 (H) x 11.8 (D) cm 28.6 x 18.5 x 4.6 inch	PIONEER XDJ-XZ  87.8 (W) x 46.6 (H) x 11.8 (D) cm 34.5 x 18.3 x 4.6 inch	PIONEER DDJ-SZ2  87.0 (W) x 42.0 (H) x 9.8 (D) cm 34.3 x 16.5 x 3.9 inch	PIONEER DDJ-RZ  87.0 (W) x 42.0 (H) x 9.8 (D) cm 34.3 x 16.5 x 3.9 inch	DENON PRIME 4+  72.9 (W) x 49.7 (H) x 10.4 (D) cm 28.7 x 19.5 x 4.1 inch
	NI KOMplete KONTROL S49 MK2  84 (W) x 29.7 (H) x 8.4 (D) cm 33.1 x 11.7 x 3.3 inch	NI KOMplete KONTROL A49  82 (W) x 25.7 (H) x 8.9 (D) cm 32.3 x 10.1 x 3.5 inch	M-AUDIO OXYGEN 49 MKV  81.4 (W) x 24.3 (H) x 9.4 (D) cm 32.0 x 9.5 x 3.7 inch	M-AUDIO OXYGEN PRO 49  80.0 (W) x 26.4 (H) x 8.4 (D) cm 31.5 x 10.4 x 3.3 inch	AKAI MPK261  90.5 (W) x 29.8 (H) x 9.2 (D) cm 35.63 x 12.3 x 3.4 inch
U93016 PICK FOAM FLIGHT CASE MULTI FORMAT TURNTABLE  48 (W) x 41.3 (H) x 20 (D) cm 18.9 x 16.2 x 7.9 inch	RELOOP RP-8000 MK2  45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch	RELOOP RP-7000 MK2  45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch	AUDIOTECHNICAL P120XUSB  45.2 (W) x 35.2 (H) x 14.2 (D) cm 17.8 x 13.8 x 5.6 inch	TECHNICS SL-1210GR2  45.3 (W) x 37.2 (H) x 17.3 (D) cm 17.8 x 14.6 x 6.8 inch	TECHNICS SL-1200GR2  45.3 (W) x 35.3 (H) x 17.3 (D) cm 17.8 x 13.9 x 6.8 inch
	PIONEER PLX-CRSS12  45.3 (W) x 35.3 (H) x 15.9 (D) cm 17.8 x 13.8 x 6.3 inch	PIONEER PLX-1000  45.3 (W) x 35.3 (H) x 15.9 (D) cm 17.8 x 13.8 x 6.3 inch	DENON VL12 PRIME  45.1 (W) x 35.5 (H) x 15 (D) cm 17.7 x 13.9 x 5.9 inch	STANTON STR8. 150 M2  45 (W) x 35.3 (H) x 14.6 (D) cm 17.7 x 13.9 x 5.7 inch	GEMINI TT-4000  42.8 (W) x 34.9 (H) x 9.0 (D) cm 16.8 x 13.7 x 3.5 inch

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U9121BL CD PLAYER/MIXER BAG LARGE BLACK MK2  33.5 (W) x 45 (H) x 12.5 (D) cm 13.2 x 17.7 x 4.9 inch	PIONEER CDJ-3000  45.3 (W) x 32.9 (H) x 11.8 (D) cm 17.8 x 12.9 x 4.6 inch	PIONEER DJM-S7  39.7 (W) x 26.7 (H) x 10.8 (D) cm 15.6 x 10.5 x 4.3 inch	PIONEER XDJ-1000MK2  30.5 (W) x 38.3 (H) x 11 (D) cm 12 x 15.1 x 4.3 inch	PIONEER DJM-900NXS  41.4 (W) x 33.3 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch	PIONEER CDJ-2000NXS  41.4 (W) x 32 (H) x 11.3 (D) cm 15.9 x 12.5 x 4.4 inch
	DENON X1850 PRIME  44.8 (W) x 30.9 (H) x 11 (D) cm 17.6 x 12.2 x 4.3 inch	DENON SC5000 PRIME  32 (W) x 41.9 (H) x 13.5 (D) cm 12.6 x 16.5 x 5.3 inch	RANE SEVENTY-TWO MKII  44.5 (W) x 28 (H) x 9 (D) cm 17.5 x 11 x 3.5 inch	RELOOP RMX-95  38.7 (W) x 32.2 (H) x 10.8 (D) cm 15.2 x 12.7 x 4.2 inch	RELOOP ELITE  41.4 (W) x 29 (H) x 10.8 (D) cm 16.3 x 11.4 x 4.3 inch
U9880 DIGI TROLLEY TO GO  31 (W) x 39 (H) x 19 (D) cm 12.2 x 15.4 x 7.5 inch	AKAI APC64  37.1 (W) x 27.2 (H) x 3.5 (D) cm 14.6 x 10.7 x 1.4 inch	AKAI MPC ONE+  27.2 (W) x 27.2 (H) x 5.3 (D) cm 10.7 x 10.7 x 2.1 inch	AKAI MPC STUDIO  30.5 (W) x 17.1 (H) x 3.7 (D) cm 12.0 x 6.7 x 1.4 inch	PIONEER DDJ-XP2  33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch	PIONEER DDJ-200  37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch
	RELOOP RMX-95  38.7 (W) x 32.2 (H) x 10.8 (D) cm 15.2 x 12.7 x 4.2 inch	NOVATION AFX STATION  46.0 (W) x 27.6 (H) x 8.0 (D) cm 18.1 x 10.9 x 3.1 inch	NUMARK PARTY MIX LIVE  32.5 (W) x 25.6 (H) x 6.6 (D) cm 12.8 x 10.1 x 2.6 inch	ROLAND SH-4D  36.0 (W) x 19.5 (H) x 6.6 (D) cm 14.2 x 7.7 x 2.6 inch	 15.4" laptop and small gears
U9870 TROLLEY TO GO BLACK  33 (W) x 33 (H) x 16 (D) cm 13 x 13 x 6.3 inch	50 RECORDS  or 40 12" CD SLEEVE 	1 CD WALLET 280  or 2 CD WALLET 128 	AUDIO INTERFACE FOCUSRITE SCARLETT 2I2 or KORG VOLCA SERIES 	FOLDABLE DJ HEADPHONE 	CABLES 
	60 RECORDS  or 50 12" CD SLEEVE 	1 CD WALLET 280  or 2 CD WALLET 128 	AUDIO INTERFACE Universal Audio Apollo Solo or NI Komplete Audio 6 MK2 	FOLDABLE DJ HEADPHONE 	CABLES 
U9981 SLINGBAG TROLLEY DELUXE  33 (W) x 33 (H) x 20 (D) cm 13 x 13 x 7.9 inch					

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
U9630 SLINGBAG  33 (W) x 33 (H) x 16 (D) cm 13 x 13 x 6.3 inch	50 RECORDS  or 40 12" CD SLEEVE 	1 CD WALLET 280  or 2 CD WALLET 128 	AUDIO INTERFACE Universal Audio Apollo Solo  or NI Komplete Audio 6 MK2 	FOLDABLE DJ HEADPHONE 	CABLES 
U9450 COURIER BAG  37.5 (W) x 30 (H) x 13 (D) cm 14.8 x 11.8 x 5.1 inch	40 RECORDS 	AUDIO INTERFACE FOCUSRITE SCARLETT 2i2  or KORG VOLCA SERIES 	CABLES 		
U9500 STARTER BAG BLACK/WHITE LOGO  32.5 (W) x 33 (H) x 17.5 (D) cm 12.8 x 13 x 6.9 inch	50 RECORDS 				
U93017 RECORD CASE 80 VINYL  33 (W) x 34 (H) x 27.5 (D) cm 12.9 x 13.4 x 10.8 inch	80 RECORDS 				