

TO PLAY WITH TRADITIONAL TEE:



— NOTE

Simply remove the White Arm (E) / Blue Hanging Tee (F) (these will be locked together) from the Adjustable Tee Tubing (C).





Take the Traditional Tee Topper (H) and assemble to the top of the Adjustable Tee Tubing (C).

YOU ARE NOW READY TO PLAY WITH YOUR TRADITIONAL TEE!

Made In China Franklin Sports Inc. Stoughton, MA 02072





franklin®

AGES 3+

USA 2-IN-1 GROW-WITH-MET BATTING TEE

ITEM NUMBER: **64219X**





CUSTOMER SERVICE COMMITMENT

Thank you for purchasing this Franklin® product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

parts@franklinsports.com

Visit our website at: franklinsports.com/instructions

If possible, please include product part number and parts description so we can best assist you.

WE'RE HERE FOR YOU!

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.


WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.

Thank you for your continued support, and welcome to the #FranklinFamily!

1

Franklin[®] ITEM#: 64219X

PARTS LIST




Franklin* ITEM#: 64219X


2


ASSEMBLY INSTRUCTIONS


- GENERAL NOTE -

- · Remove all components from packaging.
- Sort all components using the parts list and confirm that all parts are included.














NOTE -Slide the Adjustable Tee Tubing (C) through the Self-Stick Sleeve (D). Once this is done, attach the Adjustable Tee Tubing (C) to the base as shown.

PARTS-Attach the White Arm (E) to the tee as shown.


*Franklin** ITEM#: 64219X













NOTE Turn the Blue

Hanging Tee (F) to its front, and then slide the Blue Cap (G) over as shown.

Caution: Make sure this piece is assembled correctly. Failure to assemble correctly will result in a blue piece that is not properly locked into place on the White Arm (E). If your blue piece seems like it isn't locking into place securely, then this step has been assembled incorrectly. Take a look at the images to the left to understand which side is the front and which side is the back.

Once the Blue Cap (G) has been assembled to the Blue Hanging Tee (F), this can be attached and locked to the White Arm (E) The Blue Hanging Tee and Blue Cap should click & lock into place if assembled correctly. If you find that this Blue Hanging Tee comes off of the White Arm easily, then the pieces have been assembled incorrectly.





Your Traditional Tee Topper (H) can fasten to the back of the Self-Stick Sleeve (D) when playing with this Hanging Tee version so that you don't have to worry about losing pieces!

YOU ARE NOW READY TO PLAY WITH YOUR HANGING TEE!

Flip for more ways to play!

