

FACEDEEP 3 IRT

ANVIZ
POWERING A SMARTER WORLD

CAUTION

Temperature Measurement

1. Warm up the device for at least **20 minutes** after power-on to enable the device to reach thermal equilibrium.
2. Maintain an ambient temperature at between **15°C to 32°C (59°F to 89.6°F)**. Recommend to enable the "Low Temp. Access" option if the ambient temperature below 15°C (59°F).

Installation

1. Please install the device at the best height of approximately **1.4 meters (55.12 inches)** from the top of the device to the ground.
2. Avoid backlight and direct sunlight.

Anviz Global Inc.

41656 Christy Street Fremont, Fremont, CA, 94538

Toll-free: 1-855-268-4948 | sales@anziv.com | www.anviz.com

©2021 Anviz Global Inc. Anviz and identifying product names and numbers herein are registered trademarks of Anviz Global Inc. All non-Anviz brands and product names are trademarks or registered trademarks of their respective companies. Product appearance, build status and/or specifications are subject to change without notice.