


How to configure the wireless network name (SSID) and wireless password on DWR-U2100 via GUI and D-Link Mobile Connect

WebGUI

- 1 From the device you want to connect to (smartphones, laptops, or computers). Connect your DWR-U2100 to the Wi-Fi or USB type C cable
 - The SSID will appear as D-Link2G-XXXX or D-Link5G-XXXX
 - The default Wi-Fi password is printed on the label at the back of the device
- 2 Once connected, open a web browser and type in the URL bar <https://192.168.0.1> and hit enter.
- 3 You will be prompted to enter the username and password to access the router's settings.
 - **Username:** admin
 - **Password:** (printed on the device label)



Note: If you have changed the password and cannot remember it, you will need to perform a hard reset on the router

- 4 Once logged in, navigate to the **My Wi-Fi** tab, and then **Basic**. Under the 2.4G and 5G wireless fields, you can modify/create a new **SSID (Wireless name)** and **Password (Wireless password)** then hit **Save** to confirm the settings.


D-Link® Technical Support Setup Procedure

The screenshot shows the D-Link DWR-U2100 web interface. At the top, there's a blue header with the D-Link logo and the model number DWR-U2100. Below the header, there's a navigation bar with tabs: Home, My Wi-Fi (highlighted with a red box and number 1), Mobile, Lan, Clients, and More. On the left side, there's a sidebar with tabs: Basic (highlighted with a red box and number 2), Access Control, and WPS. The main content area is divided into two sections: 2.4G and 5G. Each section has a toggle for OFF/ON, a Wi-Fi Hide toggle, and a red box highlighting the Name, Security, and Password fields (numbered 3 for 2.4G and 4 for 5G). Below these fields are dropdown menus for Channel, BandWidth, and Maximum Connected. At the bottom of the 5G section, there's a red box highlighting the Save button (numbered 5).

Band	OFF/ON	Wi-Fi Hide	Name	Security	Password	Channel	BandWidth	Maximum Connected
2.4G	<input type="checkbox"/>	<input type="checkbox"/>	DLink2G-B5B3	WPA2-PSK	*****	auto	40MHz	8
5G	<input type="checkbox"/>	<input type="checkbox"/>	DLink5G-B5B3	WPA2-PSK	*****	auto	80MHz	32

D-Link Mobile Connect App


- 1 Download and install the **D-Link Mobile Connect** app from your mobile device (App Store for iOS or Google Play Store for Android)



- 2 Ensure the DWR-U2100 is powered on. On your mobile device, go to **Wi-Fi Settings** and connect to its default Wi-Fi network
 - The default SSID will appear as **D-Link2G-XXXX** or **D-Link5G-XXXX**
 - Wi-Fi password is printed on the label at the back of the device.
- 3 Once connected, launch the D-Link Mobile Connect App.


D-Link® Technical Support Setup Procedure

- 4 You will be prompted to enter the username and password to access the router's settings.
- **Username:** admin
 - **Password:** (printed on the device label)



*Note: Please check the box below indicating "I have read and agreed to the User Agreement" then tap **Login**.*

- 5 Tap **Wi-Fi Settings** from the home screen



- 6 In the 2.4G and 5G Wi-Fi Settings, you have the option to change both the network name and password for your Wi-Fi.
- 7 After making the changes, press **Confirm** to save and apply.
- 8 Once you've configured the Wi-Fi settings, wait for the changes to take effect. The router may need a moment to update its settings.
- 9 After the settings are applied, you can connect your devices to the newly configured Wi-Fi networks using the updated SSID and password.

---END---