

BUG ZAPPER

User Manual



TABLE OF CONTENTS

- 1.INTRODUCTION
- 2.ATTENTION
- 3.WHERE AND HOW To USE
- 4.TECHNICAL INFORMATION
- 5.TROUBLESHOOTING

1. INTRODUCTION

Thanks for purchasing Our Bug Zapper. Please check the condition of the device before use. If the device is damaged, do not use it.

The device is environmentally safe and hygienic, smoke-free and non-toxic. It does not include pesticides. The built-in lamp is harmless to people, pets or plants.

The highly efficient fitting tube emits special ultraviolet waves and attracts insects, insects fly into ultraviolet light and get an electric shock when they come in contact with an electrified grid. The device is highly efficient and energy-saving. It is designed for continuous use and is ready to provide you with a long mosquito-free pastime for many years.

For optimal performance, please read this manual carefully before use.

If you have any questions about the Bug Zapper, please contact us via your order, we will provide 24-hours service for you and solve the problem.

2. ATTENTION

- Do not use it in flammable and explosive locales, or similar.
- Check the local voltage codes before installing.
- Do not intend to touch internal high voltage grids because electric shock danger. Never put metal objects inside the net during use.
- Hang or place the appliance out of the reach of children.
- Never remove any fixed part of the appliance to make internal adjustments to avoid electric shock.
- If the lamp starters or other parts of appliance are damaged, the manufacturer, its service agent or similarly qualified person must replace it in order to avoid a hazard.
- Clean metal grid frequent intervals. Unplug the appliance before cleaning. Use suitable brush to clean the high voltage grids and throw away the insects debris from the collection every week. Do not wash with water.
- Avoid rough shaking that could damage the tube or its components.

3.WHERE AND HOW TO USE

OUTDOOR

The product can be used in the courtyard, garden, camping, night fishing, etc. The product has an energy-saving design and soft lighting; It should not be used in high light conditions, otherwise, it will affect the destruction of mosquitoes.


24 hours intelligent light control

Turn on the switch and the mosquito control lamp will turn off automatically during the day and turn on automatically at night. Turn off the switch and turn on the mosquito control lamp for 24 hours.



NOTICE FOR INDOOR USE: Hang or place the device out of the reach of children !!!

Suggested suspension height:



1. Hang the insect killer at a height of 6 to 8 feet above the ground, at a distance of 1 feet from the wall.
2. Place the unit 10 feet away from the area intended for human activity.
3. Position the insect killer between the source of insects(woods, lowlands, etc) and the area to be protected.
4. Plug cord into a compatible extension cord designed for outdoor use. The bulbs will emit a bluish glow within a few seconds.

To increase the killing rate, please clean mosquitoes stuck in the grid. Before cleaning, please keep the power off, open the base, use soft brush to clean it.

IP4 Waterproof
Unique waterproof design, it can be used inside and outside!

4.TECHNICAL INFORMATION

Light source: 18w UV tube
High voltage metal grid: 3800-4200V
Waterproof grade: IP4

5.TROUBLESHOOTING

Caution: unplug unit before servicing

Problem	Possible Cause	Correction
A.The light is off and there is no high voltage on the grid	1.There is no electricity. 2.The lamp is not installed correctly 3.The starter is faulty. 4.The bulb burnt out.	1.Check fuse or circuit breaker. Check extension cord. 2.Check all sockets for proper fit and alignment. 3.Starter replacement by manufacturer is required.
B.The light is on, but there is no high voltage on the grid.	1.Shorted grids. 2.The transformer is defective.	1.Examine the grid and clean it using an brush. 2.Replacement by manufacturer is required.
C.Intermittent or continuous sparking between grid rods.	1.The gap between grid rods is too small. 2.The grid is clogged dead insects.	1.Unplug the unit and adjust grids by bending them back into alignment. 2.Clean the grid using an brush.
D.The light is on, but no longer attracts insects.	1.The invisible power of black light is reduced due to the age of the lamp.	1.Replace the bulb. Replacement by manufacturer is required.