


Full Stainless Steel Ice Crusher

Instruction manual

Please read the introduction before using it



Whenever you have any problem, please don't hesitate to contact us,

we will resolve all your problem ASAP.

Brief Introduction

The full stainless ice crusher is main used for crushing big ice into small ice, it's usually applied to cold drinks series. This product make of full stainless iron, it has many advantages, just like non-rusty, safety, health and so on. It adopts vacuum double layer stainless technique, so the cold energy wouldn't waste.

Precautions before use

- ◆ Please read the specification carefully and know its structure, function ,main condition and safe operation requirement before you use it ,so that you can make the best of this equipment to raise your efficiency .
- ◆ After opening the carton, clean with a wet towel and check if the blade is firmly installed.
- ◆ Make sure that the power supply is the same as the power outlet, and the power outlet is safe. Install the switch protection before use.

1. Main parameter:

Model	ZY-SB114
Dimension	16X9.4X16.5inches/410X240X420mm
Net weight	19.84lbs/9kg
Heating power	200W
Power supply	110V-60Hz
Speed	1400R/M

Continuous running time	≤30min
The diameter of the bowl	7.9inches/201mm
The depth of the bowl	2.7inches/70mm
Shaving/Crushing capacity	440LB(200kg)per hour
Certification	CE

2. contents

- 1 x Ice shaver
- 1 x Stainless Steel bowl
- 1 x User Manual

3. Operating instructions

- 1). Check the power line and plug to insure the circuit contact in good condition and avoid creep age, then close the switch and plug in the ice crusher.
- 2). Open the cover of ice crusher ,and put in some ice in the right amounts ,then cover it.
- 3).Press the switch to start the ice crusher ,depress the handle to push the ice to edge of ice crusher.
- 4).We recommend that you use ice with the diameter 4-5cm.

<NOTE>

When using,the outlet of the ice cannot be jammed, otherwise the cutter head may get stuck and the motor may be burnt out. If the above mentioned conditions appear, please cut off the power and raise the handle immediately, find out the reasons.

4. Cleaning

- ▲ Turn off the power switch and pull plugs.
- ▲ Please clean the water in the hopper after using.
- ▲ Please only use cloth scrub the hopper, but not water cleaning.
- ▲ Do not touch the blade when cleaning to avoid scratching your fingers.
- ▲ Place the machine in the dry place.

<NOTE>

The machine can not be cleaned by detergents, avoiding the corrosion of chemical substances to machine. It also can not be directly washed with water, with avoidance any damage to electrical components as well as machine.

5. Attention

- ▲ Children are forbidden to use this machine. Regardless of any circumstance, do not touch the steel plate when working.
- ▲ You must use a ground socket; keep cable away from the heat; do not connect the cable and electrical sockets to water or other liquids;
- ▲ Do not use the damaged cables, power plugs and sockets.
- ▲ To be put on a flat place, the ice should be put into evenly, otherwise it would cause the fuselage vibration.
- ▲ In the course of the use, do not allow the fingers into the ice inside.
- ▲ Continuous running of the machine should be not more than 30 minutes with the following 10 minutes interval for motor cooling.
- ▲ To avoid jamming, do not force to operate the unit with excessive pressure.
- ▲ Do not shave fruits and vegetables.
- ▲ After use, there would be a little ice left in the hopper. This is normal.
- ▲ Please clean the rest water in the ice tank after using.

▲ Do not arbitrarily dismantle motor, when cleaning or repairing machine, you should first turn off the power switch and pull plugs.

▲ It can not keep running empty.


6. Electrical date

L-----3X0.75 copper conductor

K-----15A/110V switch

Fu-----5A fuse

M ----- motor



7. Recipes

1) Mung bean flavor

We should boiling the mung bean with right amount of sugar water, Stew with warm fire until the mung bean began to Crisp rotten, Turn off the fire. And then stir the mung beans with condensed milk which you can buy from supermarkets.

<NOTE> a few soup of red bean will make it better in color when shaving ice and beans together.

2) Peanut flavor

Fire the peanuts with oil to crisp, this will increase the sweetness of peanuts, Wrap the peanuts with paper or towels inside to suck the oil. put the cooked peanuts into the plastic bag, crusher it with a rolling pin. Put the smoothies into the bowl and sprinkle with peanuts.

<NOTE>In order to increase the viscosity of the ingredients, you can also add a few spoonful of peanut butter before stirring.

3) Fruit flavor

Fruit flavored ice has no special methods, fruit like: pineapple, mango, watermelon, banana, kiwi you can just simply cut it into small pieces, mix some condensed milk and sugar on it.

<NOTE>If you want to save money, you can also mix kiwi with concentrated kiwi fruit juice.

Warranty Card

Maintenance Records

Date	Troubles	Replacements	Charge	Client signature	Staff signature

Remarks					