

# Magcubic User Manuals

[magcubicvision.com](http://magcubicvision.com)  
[support@magcubicvision.com](mailto:support@magcubicvision.com)



## MAGCUBIC HY300 Portable Projector User Manual

### MAGCUBIC HY300 Portable Projector



## Contents

1	Attention
2	Structure Description
3	Remote Component and Functions
4	Power ON/OFF
5	launcher Ui
6	Wi-Fi
7	BT Setting
8	Image Mode
9	Color Temperature
10	OSD Language
11	Home Background
12	Projector Mode
13	Factory Restore
14	Keystone
15	Media Player
16	HDMI Signal
17	Wired Screen
18	Wireless Screen
19	DLNA
20	iOS Cast
21	Safety instructions
22	Disclaim
23	Attention:
24	Documents / Resources
24.1	References
25	Related P




## Attention

Please read this manual carefully before use and keep it for future reference.


1. The projector is non dustproof or waterproof.
2. In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
3. Please use the original power adapter. The projector should work under specified rated power supply.
4. When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
5. Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
6. Regularly clean projector vents, or dust may cause cooling malfunction.
7. Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
8. Please handle with care during daily use.
9. Please cut off the power if the projector is out of use for long time.
10. Non-professionals are forbidden to disassemble the projector for testing and maintenance.

## Structure Description

This manual is for reference only. It is subject to change without prior notice. Hotcake reserves the right of final interpretation.




#### Remote Component and Functions




## Power ON/OFF

**Power On** Long press Power button on projector for 3 seconds. **Power Off** When the projector is power-on, press and hold the power button on the projector or the remote control for 3s to power off.



## Focus Adjustment

When projector is on, adjust sharpness by focus wheel on the back of projector.



## launcher Ui



## Wi-Fi

**Wifi Setting** > To choose the network and type the password that you want to connect to.




## BT Setting

**BT setting, BT"ON"**, click Refresh Device and choose objective device to pair




## Image Mode

Setting – Picture Settings – Image Mode > To select different mode according to your application scenario. Four modes are available < Standard, Dynamic, Mild, User >.



## Color Temperature

Setting – Picture Settings – Color Temperature > To select different mode according to your application scenario. Three modes are available < Cold, Standard, Warm >.



## OSD Language

Setting – System Settings – OSD Lang > To choose your language.




## Home Background

Setting – System Settings – Home Background > Choose the Home Background you want < Blue, Dark blue, White, Grey >




## Projector Mode

Setting – System Settings – Flip > To select different mode according to your application scenario. Four modes are available < Front Table, Front Ceiling, Back Table, Back Ceiling >.



## Factory Restore


Setting – System Settings – Factory Restore > To reset system. The user data will be cleared.



## Keystone


Setting – Keystone > To choose auto keystone and manual keystone.





## Media Player

Insert the U disk and click the USB icon on the homepage to read the local video & music & photo & Book.



## HDMI Signal

Connect projector and external sourcing device by HDMI cable. Enter HDMI on the homepage, the signal from the sourcing device will be transmitted to projector and cast out.



## Wired Screen

### iOS connect by Cables

1. Connect your iPhone to the projector via the original iPhone charging cable. (Cable has a USB port and Lighting Port)
2. Please click "Trust" when the iPhone shows a pop-up window.
3. Enter device password.



## Wireless Screen

(The Android Mobile/Pad must be on the same network as the projector device.)



1. Open the settings menu on your Android Mobile/Pad.
2. Access your display settings or screen mirroring.
3. Select the device name.




## DLNA

(The phone/Pad must be on the same network as the projector device.)

1. Open the video playing app.



2. Click the TV icon and select the device name.



## iOS Cast

### iOS Cast AP

Connect with iOS Phone via screen mirroring:

1. Open WIFI and find the device name from your phone. Then input the password on your phone.
2. Click Airplay/Screen mirroring on your phone and connect the projector.

## iOS Cast

(The phone/Pad must be on the same network as the projector device.)

1. Open your iPhone Control Centre and select Screen Mirroring.
2. Click the device name



## Safety instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) ,etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are noncovered to avoid projector overheating.
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

## Disclaimer

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims. This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.

Thanks for purchasing!

Need help?

Please send email in close item name to our Brand Support Team ( [magcubic@163.com](mailto:magcubic@163.com)) in order to get better experience and prompt reply and further assistance.




### Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.

---

## Documents / Resources

	<a href="#">MAGCUBIC HY300 Portable Projector</a> [pdf] User Manual HY300, HY300 Portable Projector, Portable Projector, Projector
---	---

## References

- [User Manual](#)