




OPERATION



Volume Control Switch:

Push the switch to "85dB" to control the volume below 85dB. Push the switch to "94dB" to disable volume control and recover normal volume under noisy environment.



MFB (Multi-function Button)

Gently press: Answer / Hang Up / Play / Pause

Double press: Next Track
Press for 3 times: Previous Track

Note: If you need to share music, insert a headphone audio cable into the jack.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

All Seenda products come with a 12-months warranty policy, please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience.

Our email: support@seenda.com
Our website: www.seenda.com

- 2 -