
Godox



SL150IIIBi SL200IIIBi

双色温LED摄影灯

Bi-color LED Video Light

使用手册

Instruction Manual

Safety Instructions and Attentions

First of all, as the most basic principle: This product is a professional lighting set equipment and should be used by professional lighting engineers or under the guidance of professionals. Basic safety attentions must always be followed during use, as follows:

- 1. Before use, please read and understand these instructions and attentions.
- 2. Professional lighting is prohibited for children. When children are near, parents or accompanying persons must supervise closely to prevent children from personal injury due to collision with lamps or private use of lamps.
- 3.This lighting product is not ordinary lighting product and cannot be used for general lighting. Anyone who has suffered eye damage or has sensitive eyes should avoid using this product.
- 4. When the lamp is on, it must be used with care. Do not touch high-temperature parts, such as LED lamp beads, to avoid burns.
- 5. When the lamp is on, it is forbidden to look directly at the lamp beads under any circumstances. Strong light should be used under the guidance of professional lighting engineers. Avoid prolonged exposure to strong light under any circumstances. If eye discomfort, please turn off the lamp in time, suspend use, and see a doctor immediately.
- 6.If the lamp bead is damaged or deformed by heat, stop using this equipment, and contact the manufacturer, service agent or qualified maintenance personnel to replace the lamp bead in time to avoid accidents.
- 7.This product is only suitable for use in -10 $^{\circ}$ C to 40 $^{\circ}$ C operating environment and normal humidity environment.
- 8.Do not use damaged equipment or accessories, and wait for professional maintenance personnel to check and repair to confirm being normal before use. 9.During using, if the casing of this product is broken due to being dropped, squeezed or subjected to strong impact, please do not use it, so as to avoid electric shock injury due to contact with internal electronic components.
- 10.If an extension cord is required, please use an extension cord with a current rating greater than or equal to that of the equipment. If an extension cord is rated less than the equipment, overheating may result.
- 11. Some products have long power cords, please place the power cords properly and keep them in a safe place. Avoid contacting the power cord with overheating surfaces, avoid improper placement that could cause pulling damage, or trip on-site personnel. Please use the certified power cord from the original manufacturer. If the product is damaged by using a non-certified power cord, it will not be repaired by our factory.
- 12.Be sure to unplug equipment from the power outlet before cleaning and repairing. When not in use, do not pull the power cord to unplug the equipment. For normal power-off, please hold both ends of the plug of the equipment with

your hands and pull the plug out of power outlet. This equipment needs to be connected to a grounded outlet.

13.This equipment is not waterproof, please keep it dry and do not immerse it in water or other liquids. The equipment should be installed in a dry and ventilated place, and avoid using it in rainy, humid, dusty or overheated environments. Do not place any objects on the lamp or let liquid flow into the lamp to avoid accidents.

14.Do not disassemble the product without permission. If the product fails, it must be checked and repaired by authorized maintenance personnel.

15.Before storing, make sure that the equipment has cooled down completely. For storage, unplug the power cord from the equipment. The equipment should be placed in the carrying case or in a ventilated dry place.

16.Do not place equipment near flammable and volatile solvents such as alcohol and gasoline.

17.Do not use accessories that are not recommended by our factory to avoid fire, electric shock or personal injury.

18. When cleaning, do not wipe it with a damp cloth, please use a dry cloth or a soft cloth to wipe the dirt of the equipment.

19.Please take off the protective cover before using.

20.This product complies with ROHS, CE and FCC certification, please refer to the relevant national standards for use and operation.

21.The safety instructions are formulated according to the strict testing of the factory, and the design and specifications of the equipment are subject to change without prior notice. For latest product information, please check the GODOX website and view latest electronic instruction.

22. Some products have built-in lithium batteries. Please use specified chargers, and use them within a proper range of the specified voltage and temperature according to the correct operating instructions.

23. Some products are battery powered. Do not use any batteries, power sources or accessories not specified in the instructions for such products. Keep batteries and other accessories out of the reach of children and infants. In the instance that a child or infant swallows a battery or accessory, immediate emergency medical attention is required. If the battery leaks, becomes discolored, deformed, emits smoke, or emits an abnormal odor, remove it immediately. Be careful during removal to avoid burns. Continued use could result in fire, electric shock, or burns. Do not use any deformed or modified batteries. Do not disassemble or modify this product or battery. Do not heat or solder the battery. Keep the battery away from fire or water. Do not incorrectly insert the positive and negative ends of batteries, or mix old and new batteries or batteries of different types together.

24.One-year warranty period, accessories such as consumable batteries, adapters, power cords, etc. are not covered by this warranty.

25.If it is found that the equipment is repaired without authorization, the one-year warranty period will be cancelled and relevant fees will be charged for maintenance.

26.Machine failures caused by non-standard operation are not covered by the warranty.

keep these instructions!

Forward

Thank you for purchasing !

SL 150IIIBi and SL 200IIIBi are the upgraded series bi-color LED video lights, with super high CRI, adjustable CCT, 9 FX modes, 2.4GHz & Bluetooth APP control and one key silent mode, making them suitable for studio shooting, interview lighting, still life shooting, video shooting, etc.

Main Features:

- With 9 FX modes to simulate various of shooting scenes.
- Warm and cold color temperature adjustable from 2800K to 6500K.
- One key silent mode suitable for highly sensitive recording environments.
- Support 2.4GHz wireless/Bluetooth APP control.
- With stable light source and 0% to 100% precise brightness adjustment.
- With optional remote control RC-A6 to support 16 groups and 32 channels wireless control
- With U-type bracket to adjust different angles easily.
- Standard Bowens-mount enables to install various of accessories.

Warning

- △ Always keep this product dry. Do not use in rain or in damp conditions.
- △ Do not disassemble. Should repairs become necessary, this product must be sent to an authorized maintenance center.
- △ Keep out of reach of children.
- ▲ As this product do not have waterproof function, please take measures of water-proof in rainy or damp environment.
- △ Do not use or store the product if the ambient temperature reads over 40°C.
- ▲ Do not use the product in the presence of flammable gases, chemicals and other similar materials. In certain circumstance, please pay attention to the relevant warnings.




Do not look directly at the light source.

-11-

Product Structure

Light Body



- 1. Thermovent 1
- 2 Handle
- 3. Bracket Screw
- 4. Umbrella Input
- 5. Mount Fixing Pusher
- 6. Bowens Mount
- 7. LED Beads
- 8. Thermovent 2
- 9. U-type Bracket
- 10. Fixing Knob
- 11. LCD Display
- 12. CCT/FX Select Dial
- 13. FX Button
- 14, 2,4G Button
- 15. Bluetooth Button
- 16. DIM Select Dial
- 17. Fan Button
- 18. Power Switch
- 19. Power Input Socket

LCD Display



- 1. LED Liaht 2. Group
- 3. Channel
- 4. DIM Adjustment Ratio
- 5. CCT Value 6. FX Icon
- 7. FX Type 8. Bluetooth

What's Inside

SL150IIIBi









SL150IIIBi

LED Reflector (Bowens Mount)*1

Protection Cover

Power Cable

Instruction Manual

SL200IIIBi













SL200IIIBi

LED Reflector (Bowens Mount)*1

Protection Cover

Power Cable

Instruction Manual *1

Separately Sold Accessories

The product can be used in combination with the following accessories sold separately, so as to achieve best photography effects: RC-A6 remote control, Softbox, Photographic Umbrella, Light Stand etc.









Operation

1. Power Connection

Use the power cable to connect the LED light to an AC power source and turn on the power switch.

2. Silent mode

Short press the fan button to turn on or off the silent mode in the main interface. The fan button will be constant on when the silent mode is off, while turn off when the silent mode is on.

Note: The brightness range in silent mode is 0% to 50%.



3. Brightness Adjustment

The brightness can be adjusted by turning the DMX select dial from 0% to 100%. The brightness will decrease in turning left while increasing in turning right.





4. CCT Adjustment

When the "FX" icon disappears, turn the CCT/FX select dial to adjust color temperature from 2800K to 6500K. The CCT value will decrease in turning left while increasing in turning right.

Note: When the "FX" icon appears, short press the FX button can exit FX mode.





5. FX Mode

Short press the FX button to enter or exit the FX modes. When exiting the FX modes, FX icon will not be displayed. When entering the FX modes, FX icon will be displayed on the LCD panel, Then, turn the FX select dial to choose one mode from the 9 FX modes to achieve creative shooting.

Display	FX1	FX2	FX3	FX4	FX5	FX6	FX7	FX8	FX9
Scenes	Flash1	Flash2	Storm1	Storm2	TV	Broken Bulb	Candle	Fire	Firework

6. Strong Power Mode

Turn on the fan to enter strong power mode and the power will up to the maximum value in this mode.

7. 2.4GHz Setting

7.1 GR Setting: Short press the 2.4G button once to enter the group setting interface. When the group icon blinks, turn the CCT/FX select dial to choose group from A, B, C, D, E, F and 0 to 9. Finally, short press the FX button / fan button to exit or automatically exit after 10s of idle use.





7.2 CH Setting: Short press the 2.4G button twice to enter the channel setting interface. When the channel icon blinks, turn the CCT/FX select dial to choose channel from 1 to 32. Finally, short press the FX button/2.4G button /fan button to exit or automatically exit after 10s of idle use.





7.3 ID Setting: Long press the 2.4G button to enter the ID setting interface, turn the DIM select dial to choose ID from OF and 01 to 99. Finally, short press the FX button/2.4G button /fan button to exit or automatically exit after 10s of idle use.



8. Bluetooth Setting

- **8.1 Check Bluetooth MAC code:** Short press the Bluetooth button once then the MAC code will display.
- **8.2 Bluetooth Reset:** Long press the Bluetooth button to make the Bluetooth icon blinks in the main interface. When the Bluetooth icon stops blinking in 5 seconds, it means Bluetooth resetting is completed.

8.3 Connect to smartphone APP: Scan the QR code to download the "Godox Light" mobile APP (It can be used on both Android and Apple systems). For specific operations, please refer to the "Help" manual of the mobile APP, which contains detailed tutorials.

Note: the APP can be used directly on the firstly installed device (smartphone or tablet). When changing to other mobile device, the light shall be reset before the normal usage of APP.



Illuminance data

SL150IIIBi

CCT	Testing Condition	Unit	1m	2m	3m
2800K	Bare light	lux	4880	1270	606
		fc	453	118	56.3
	With reflector	lux	56200	13100	5500
	VVIII TOTICGGO	fc	5220	1220	511
	Bare light	lux	6340	1650	787
3200K	Dare light	fc	589	154	73.1
	With reflector	lux	76800	17800	7220
		fc	7130	1660	671
	Bare light	lux	7610	1990	938
4300K		fc	707	185	87.2
	With reflector	lux	90500	20800	8760
		fc	8400	1930	814
	Bare light	lux	6810	1730	830
5600K		fc	633	161	77.1
	With reflector	lux	80400	18400	7740
	VVIIII TETICOLOT	fc	7470	1710	719
	Bare light	lux	5530	1450	683
6500K	Daie light	fc	514	134	63.5
	With reflector	lux	67300	15200	6410
	with reflector	fc	6250	1410	595

SL200IIIBi

CCT	Testing Condition	Unit	1m	2m	3m
2800K	B 11.1.	lux	5960	1660	736
	Bare light	fc	554	154	68.4
	With reflector	lux	73500	16400	6700
	With reflector	fc	6830	1530	622
	Bare light	lux	7040	1920	845
3200K	bale light	fc	654	179	78.5
	With reflector	lux	83700	18900	7820
	VVIGITICALCO	fc	7780	1750	726
4300K	Bare light	lux	7980	2140	962
		fc	741	199	89.4
	With reflector	lux	94400	21300	8840
		fc	8770	1980	822
	Bare light	lux	8130	2180	979
5600K		fc	755	203	91
	With reflector	lux	95400	21600	8810
	VVIIII TOTICOCOT	fc	8860	2000	818
6500K	Bare light	lux	6690	1800	808
	Daile light	fc	621	167	75.1
	With reflector	lux	78200	17700	7210
	, , , , , , , , , , , , , , , , , , ,	fc	7260	1640	670

All the above tests are based on the condition of 100% brightness.

Technical Data

Model	SL150IIIBi	SL200IIIBi	
Power Supply	100V-240V~50/60Hz	100V-240V~50/60Hz	
Total Power	Max.160w	Max.215w	
ССТ	2800K-6500K		
TLCI	Average ≥97		
CRI	Average ≥96		

Brightness Range	0%-100%			
Channel	32 (1-32)			
Group	16 (A,B,C,D,E,0-9)			
ID	99 (01-99)			
Control Method	2.4GHz Control /Bluetooth APP Control /Light Body Control			
2.4GHz Control Distance	≈50m			
Bluetooth Control Distance	≈30m			
Working Environment Temperature	-10°C~40°C			
Dimension (excluding reflector)	199mm*285mm*288mm	199mm*311mm*295mm		
Net Weight	3.1kg	3.25kg		

Specification and data may subject to changes without notice.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Operating frequency:2412.99MHz = 2464.49MHz(2.4G only receive)/2402MHz = 2480MHz (BT)

Maximum EIRP Power: 5dBm

Declaration of Conformity

GODOX Photo Equipment Co.,Ltd. hereby declares that this equipment are in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states.For more information of DoC, Please click this web link:https://www.godox.com/DOC/Godox-SLIII Series DOC,pdf.

The device complies with RF specifications when the device used at 0mm from your body.

IC Warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device. This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Ce dispositif ne peut causer d'interférences ; et
- (2) Ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.
- Ce matériel est complété par une exposition de rayonnements IC pour un environnement naturel. Ce matériel doit être installé et se faire avec une distance minimale de 20cm entre les radiateurs et les autres Your body shop.

产品保修

尊敬的用户,本保修卡是申请保修服务的重要凭证,请您配合销售商填写并妥善保管、谢谢!

产品信息	型 号	产品条码			
用户信息	姓名	联系电话			
	通信地址				
销售商	名称				
信息	联系电话				
	通信地址				
	销售日期				
备注					

注: 此表应由销售商盖章确认。

适用产品

本文件适用于相关《产品保修信息》(见后面说明)所列产品,其他非属此范围的产品或部件(如促销品、赠品及其他出厂后附加的部件等)不在此保修承诺内。

保修期

产品及部件的相应保修期按相关的《产品保修信息》执行。保修期自产品首次购买日起算,购买日以购买产品时保修卡登记日期为准。

如何获得保修服务

您可直接与产品销售商或授权服务机构联系,也可拨打神牛产品售后服务电话,与我们联系,由我们的服务人员为您安排服务。申请保修时,您应提供有效的保修卡作为保修凭证,方可获得保修。如您不能提供有效的保修卡,则在我们确认产品或部件属于保修范围的情况下,也可以为您提供保修,但这不作为我们的义务。

不适用保修的情况

如产品存在下列情况,本文件项下的保证和服务将不适用 ①产品或部件超过相应保修期;②错误或不适当使用、维护或 保管导致的故障或损坏,如:不当搬运;非按产品合理预期用途使用;不当插拨外接设备;跌落或外力挤压;接触或暴露于不适当温度、溶剂、酸碱、水浸或潮湿环境;③由非神牛授权机构或人员安装、修理、更改、添加或拆卸造成的故障或损坏;④产品或部件原有识别信息被修改变更或除去;⑤无有效保修卡;⑥使用非合法授权、非标准或非公开发行的软件造成的故障或损坏;⑦因不可抗力或意外事件造成的故障或损坏;⑧其他非因产品本身质量问题导致的故障或损坏。遇上述情况,您应向相关责任方寻求解决,神牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件或软件导致产品不能正常使用的,不是保修范围内的故障。产品使用过程中正常的脱色,磨损和消耗,不是保修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保修信息》执行:

产品类别	选件名称	保修期 (月)	保修服务类型	
部件	电路板	12	客户送修	
	电池	3	客户送修	
	充电器等带电性能的部件。	12	客户送修	
其他	如闪光管、造型灯泡、外壳、 保护罩、锁紧装置、包装电源线, 同步线等。	无	无保修	

神牛产品售后服务电话:0755-29609320-8062

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number			
Customer Information	Name	Contact Number			
	Address				
Seller	Name				
Information	Contact Number				
	Address				
	Date of Sale				
Note:					

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day(purchase date) when the product is bought for the first time, And the purchase date is considered as the date registered on the warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ①. The product or accessory has expired its warranty period; ②. Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc; 3. Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment; 4. The original identifying information of product or accessory is modified, alternated, or removed; (5), No valid warranty card; (6), Breakage or damage caused by using illegally authorized, nonstandard or non-public released software; ①. Breakage or damage caused by force majeure or accident; 8. Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion and consumption are not the breakage within the maintenance scope.

Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information:

Product Type	Name	Maintenance Period(month)	Warranty Service Type
Parts Circuit Board		12	Customer sends the product to designated site
	Battery	3	Customer sends the product to designated site
	Electrical parts e.g.battery charger, etc.	12	Customer sends the product to designated site
Other Items	Flash tube, modeling lamp, lamp body, lamp cover, locking device, package, power cord, sync cable, etc.	NO	Without warranty

Godox After-sale Service Call 0755-29609320-8062





深圳市神牛摄影器材有限公司

地址: 深圳市宝安区福海街道塘尾社区耀川工业区厂房2栋 电话: 0755-29609320(8062) 传真: 0755-25723423 邮箱: godox@godox.com

GODOX Photo Equipment Co., Ltd.

 $Add: Building 2, Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao' \ an District, Shenzhen S18103, China Tel: +86-755-29609320(8062) Fax: +86-755-25723423 E-mail: godox@godox.com$

www.godox.com



