

Download and install the **Tellur Smart App** for either iOS or Android devices.





Once downloaded, the app will ask you to register your device. Enter your phone number or email which makes you feel comfortable and select the country you live in.

If phone number selected you will receive a text with a registration code. If you choose email you will then create a password.

Input the Registration Code you received via text if phone method has been used or create password if email method chosen.

Adding a New Device

- Turn on power of device being paired and make sure light is flashing quickly.
- Open App and Click "+" to add appropriate device.
- Select WiFi network and input password of WiFi then.
- Once connected the App will prompt the connection, then you can rename the device or just click "done".





Next step is to sync with Alexa or echo:

- 1.Go to Home menu on Alexa App
- 2.Select "Skills" in home menu of Amazon Alexa




4. Click on the App [Smart Life] and press Enable to activate "smart life".

5. Then you need to input your account and password that you registered in Tellur Smart . Now you finish the Alexa Link.



Why failed to add device?

1. Please check whether device is powered on;
2. Whether phone is connected via Wi-Fi;
3. Whether device is ready for configuration.

To get the device ready before configuration, normally you can manually press on the device to get it ready. Please refer to "Product Instructions" or Device Reset Instruction for details.

Notice Each time to add device, reset Wi-Fi to get device ready for configuration and make sure router is working properly.

4. Check routers or related: If router is dual-band router, select 2.4G network and add device. You also need to enable router's broadcasting function. Set up wireless router: Set encryption method as WPA2-PSK and authorization type as AES, or set both as auto.

Wireless mode cannot be 11n only. Don't use Chinese to name router Wi-Fi.To stay strong Wi-Fi signal, please keep device and router within certain distance.

Whether connected devices have reached the maximum number of router's connections. If so, please try by turning off the Wi-Fi connection of some device. Router's wireless MAC filtering function is enabled. Remove the device from the filter list and make sure that router is not prohibiting device from connection.

5. Make sure the password entered in App is correct when adding new device

EZ and AP connection modes:

Smart devices can be connected using two modes: EZ and AP.

EZ represents the easiest way of connecting and enabling a smart device. You will need to have the device, active wireless network through with login password and Tellur Smart APP installed on a smartphone / tablet.

AP mode can be used to configure and enable a smart device first with the smartphone / tablet and later on to the Wi-Fi network.

How to reset device?

1. Reset heater, oil heater etc. Long press reset button for 5 seconds until indicator light flashes, representing successful reset; Indicator light quickly flashes (2 times per second), representing quick connect mode;
- Indicator light slowly flashes (one time per 3 seconds), representing AP mode; Under EZ mode, long press reset button for 5 seconds until indicator light slowly flashes, representing switching to AP mode and vise versa.
2. Reset smart light•Turn off light first. Switch lightwith the steps: Switch on-off-on-off-on (time interval cannot exceed 10 seconds), flashing lights represents successful reset; if no light flashes, please repeat the steps above;
- Quick light flashes (4 times per second), represent EZ mode; Slow light flashes (2 times per 3 seconds) represent AP mode; Under EZ mode, turn off lights and then switch light with the steps: Switch on - off - on - off - on (time interval cannot exceed 10 seconds). Light begins to slowly flash, representing that it has switched to AP mode and vise versa.

How to add device under EZ mode?

1. Make sure that indicator light or light quickly flash;
2. Phone has connected to Wi-Fi router and been able to connect to Internet;
3. Tap "Add device" in app and enter correct Wi-Fi pass-word. Touch to search device around;
4. In the device list, select and add the device.

How to add device under AP mode?

1. Make sure that indicator light quickly flashes or light slowly flashes;
2. Tap "Add device" in App and then "AP mode" in the top right corner. Connect to device hotspot first and then Wi-Fi.
3. Tap "Next" to add device.

Can I control device with 2G/3G/4G network?

When adding device for the first time, it requires that device and phone need to be under the same Wi-Fi environment. After successfully adding device, you can remote control device with 2G/3G/4G network

How can I share my device with family?

Open App, go to "Profile" > "Device Sharing" > "Sharings Sent", tap "Add Sharing", then you can share the device with the added family members.

How can I manage the devices shared by others?

Open App, go to "Profile" > "Device Sharing" > "Sharings Received", then you can find the devices shared by other users. It also allows to add remarks to users or delete certain sharings by long pressing or swiping left.

Quick Guide of Using Google Home to Control Smart Devices

1. What you need to get started

Before using Google Home to control your devices, make sure you meet the following conditions.


- A Google Home device, or Android phone with Google Assistant.
- Latest Google Home app.
- Latest Google app (Android only)
- A Google account.
- The device display language must be set to English US.
- brightfun app and a related account.
- Smart devices.

Add devices in Tellur Smart App (Refer to App Instruction)

You can skip this part if you've already add some devices to your Tellur Smart account, and in the meantime the devices' name are easily recognized.

1. Download Tellur Smart App

You can scan the QR code below to download the Tellur Smart App:



You can also search Tellur Smart App in either App Store or Google Play to install the app.

2. Register a Tellur Smart account and sign in the app (Refer to App Instruction)


Open the Tellur Smart app, tap "Register" to register an account,then sign in the app.

3. Add device and change device's name (Refer to App Instruction)

Sign in with the Tellur Smart account, add the device, then change device name to a easily recognized word or phrase, like "bedroom light".

Link account in Home Control

- 1.Tap "Home Control" in the hamburger menu on the Google Home app's home page, then tap "+".



2. Find in the list. In the new window, select your Smart Life account's region,type your Tellur Smart account and password, then tap "Link Now".After you assign rooms for devices, your devices will be listed in the Home Control page.

Declaration of conformity

We, ABN SYSTEMS INTERNATIONAL S.R.L., Bucharest, Sector 1, Marinariilor street, nr. 31, we declare on own responsibility that the product below:

Product description	Brand	Product code
WiFi Smart Bulb E27, 2400W, 10A	Tellur	TLL331001
WiFi Smart Bulb E27, 10W, white/warm, dimmer	Tellur	TLL331011

It does not endanger life, health, work safety, does not have a negative impact on the environment and corresponds to the standards stated in the manufacturer's declaration of conformity.

The product is in compliance with the following standards and / or other normative documents:

RED – 2014/53/EU

Applied standards:

EN 62479 (Health)

EN 60950-1 (Safety)

EN 301 489-1/-17 (EMC)

EN 300 328 (Radio)

RoHS – 2011/65/EU

The product bears CE mark, applied in 2018

Name: George Barbu
Function: General manager

Place and date:
Bucharest, 02-05-2018
Signed:



Declaration of conformity

We, ABN SYSTEMS INTERNATIONAL S.R.L., Bucharest, Sector 1, Marinariilor street, nr. 31, we declare on own responsibility that the product below:

Product description	Brand	Product code
WiFi AC Plug, USB 1A, 2400W, 10A	Tellur	TLL331021
WiFi Power Strip, 3 Outlets, 4*USB 4A, 2200W, 10A, 1.8m	Tellur	TLL331031
WiFi switch, 1 port, 1800W, 10A	Tellur	TLL331041
WiFi switch, 2 ports, 1800W, 10A	Tellur	TLL331051

It does not endanger life, health, work safety, does not have a negative impact on the environment and corresponds to the standards stated in the manufacturer's declaration of conformity.

The product is in compliance with the following standards and / or other normative documents:

RED – 2014/53/EU

Applied standards:

EN 60950-1:2006+A2:2013 (Safety)

EN 62311:2008

EN 301 489-1 V2.2.0 [2017-03] (EMC)

EN 301 489-17 V3.2.0 [2017-03]

EN 300 328 V2.1.1 [2016-11] (Radio)

RoHS – 2011/65/EU

The product bears CE mark, applied in 2018

Name: George Barbu
Function: General manager

Place and date:
Bucharest, 02-05-2018
Signed:



Disposal and recycling information

The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, and/or improper recycling at the end of its life may be harmful for health and environment.

CE FC ♻️

Gracias por elegirnos! Descargue la aplicación Tellur Smart en su teléfono inteligente y siga los siguientes pasos de instalación.

Age Group	Gender	U.S. should take action (%)	U.S. should not take action (%)
18-29	Male	~85	~15
18-29	Female	~80	~20
30-49	Male	~75	~25
30-49	Female	~70	~30
50-69	Male	~65	~35
50-69	Female	~60	~40
70+	Male	~55	~45
70+	Female	~50	~50

my

Al utilizar el número de teléfono, recibirá un mensaje de texto con un código de registro. Por su dirección de correo electrónico, tendrá que establecer una contraseña también.

más ar	1
--	--

aplicaciones.

5

pregue los datos de registro para la aplicación
r Smart.
aplicación fue enseñada por Alexa. Ahora
es controlar los dispositivos añadidos con las
ones de Alexa. Se recomienda que el nombre de
dispositivos sea lo más simple posible para que
lo reconozca fácilmente.
ara controlar dispositivos inteligentes, los
roles deben ser simples.

Ejemplo:
Alexa, apaga la luz del dormitorio"
Alexa, enciende la luz del dormitorio"

También debe permitir la función de el enrutador. Configure un enrutador o: configure el método de encriptación 12-PSK y el tipo de autorización como AES automático. Para obtener una señal de Wi-Fi entenga el dispositivo y el enrutador a una ptima. Si los dispositivos conectados han el número máximo de conexiones del desactive la conexión Wi-Fi, de uno, de los S. Asegúrese de que la función de filtrado nes MAC del enrutador esté habilitada y dispositivo de la lista de filtros, ose de que el enrutador no prohíba la el dispositivo. se de que la contraseña ingresada en la sea correcta cuando agregue un nuevo

1. Asegúrese de que el LED
2. Seleccione "Agregar dispositivo" o "Modo AP". Conecte el dispositivo creado y luego a la red Wi-Fi.
3. Seleccione "Siguiente" para

rápidamente.
no inteligente /

la aplicación y
seleccione el
búsqueda.
do de la lista.

o AP:

lentamente.
la aplicación y
punto de acceso

er el dispositivo.

traves de
1. Antes de
asegúrese de
• Tienes
el sistema
• Tienes L
Google Ho
• Tienes L
• Tienes u
• El dispo
• Ha insta
• Tienes d

Agregue
Smart. Pu

Para iniciar sesión con Google+ en los dispositivos compatibles con el sistema operativo Android y Google+, asegúrese de tener la versión más reciente de la aplicación de Google+ en su dispositivo. La versión más reciente de Google+ está disponible en la cuenta de Google. Si su dispositivo no está configurado en inglés, asegúrese de que la aplicación Tellur Smart+ esté instalada en su dispositivo Smart. Si no desea instalar la aplicación Tellur Smart+ en su dispositivo, puede omitir esta parte si ya ha instalado la aplicación Tellur Smart+ en su dispositivo Smart.

me,
iciones:
oogle Home,
ssistant.
plicación
gle App.
és.
t.
Tellur
instalado los

Conecta, t
1. Selecció
presionan
seleccione

cuenta:
"Control de cas
o el menú de la a
+"



controla tus dispositivos como.
Para el dispositivo...
puede usar el siguiente...
Ok, Google, enciende...

positivos Smart, a través de un botón llamado "Luz de emergencia". Este es el siguiente escenario: "Encendido / apaga la luz".

...vés de Google
...dormitorio",
...del dormitorio

Nosotros, Bucarest, bajo nues
Descripc
Bombilla d 10W, luz bl ajustable
Bombilla d 10W, luz bl ajustable

ANB SYSTEMS INC. Sector 1, calle M la exclusiva resp	n del producto	luz Wi-Fi, E27, lanca / cálida,	+
		luz Wi-Fi, E27, lanca / cálida / RGB,	+

Marca	Código
Cellur	TLL3
Cellur	TLL3

L., declaramos producto:	
de producto	
1001	
1011	

Descripción del producto

Producto	Marca
3 1A,	Tellur
puertos, 1A,1,8 m	Tellur
	Tellur

	Código de producto
	TLL331021
	TLL331031
	TLL331041

Los	Los
:	pueden
to	impactar
	humanos
	Estos
	(2011)
	clasificación
	(DEE)
	Estos

Residuos de aparatos que no contienen sustancias peligrosas, si no se recoge el producto cumple con la Directiva 19 / EU y está en la categoría de residuos domésticos, representado por el código 17 01 01.

Los aparatos eléctricos y electrónicos deben estar etiquetados con un símbolo que indica que son peligrosos para el medio ambiente y deben ser gestionados por separado. Esto se debe a la Directiva DEEE, que requiere que los aparatos eléctricos y electrónicos estén etiquetados con un símbolo que indica que son peligrosos para el medio ambiente y deben ser gestionados por separado. Esto se debe a la Directiva DEEE, que requiere que los aparatos eléctricos y electrónicos estén etiquetados con un símbolo que indica que son peligrosos para el medio ambiente y deben ser gestionados por separado.

trónicos
e tengan un
a salud

EE de la EU
mbolo de
trónicos
imagen 

trónicos
e tengan un
a salud

EE de la EU
mbolo de
trónicos
imagen 

UG 195/2005,
 te y OUG
 os y
 en cuenta lo
 en la
 ales de alta
 r.
 mística u
 el reciclaje
 e será tomado
 locales para
 tros de
 económicos

CE   

