

How do I adjust the chain's tension?

1. Adjust tension with a screwdriver by turning the tensioning peg screw clockwise or counterclockwise to achieve proper tension.
2. The correct tension is achieved when the chain in the middle of the bar can only be lifted by approximately 3-4 mm.

How loud is my Saw Joe SWJ803E?

Your Saw Joe SWJ803E has a decibel rating of 100 dB.

What is the size of the end nut holding the bar cover on my unit?

The end nut beneath the end nut cover that holds the bar cover on to your unit is a size 13mm metric flange hex nut. Any 13mm socket or spanner wrench will be able to remove or tighten this end nut.

Should I wear safety goggles when using my unit?

Yes, safety glasses or goggles must be used when operating your Saw Joe. Also, use safety footwear, snug-fitting clothing, protective gloves, and hearing and head protection.

Wearing personal protective equipment reduces exposure to any hazards when using your pole chain saw.

What are the best uses for SWJ803E Pole Chain Saw?

- Cut hanging branches over walkways and entranceways
- Get rid of branches too close to your roof to protect your home in advance of weather hazards
- Safely trim limbs hanging in rain gutters to prevent clogging and damage
- Trim away overgrown branches on trees to beautify your property and create a cleaner, brighter and more spacious outdoor living space
- Cut branches that block sunlight from nourishing your garden and flower beds
- As a quicker and safer alternative to using a ladder and a hand saw
- Protect ground level amenities (e.g. clear space over your swing-set, remove hazards from above your carport, prevent debris from littering your pool, etc.)
- Instead of a traditional chainsaw to cut bundles of branches or clean up broken tree limbs

- No need for a smoke mask, ear protection, gas can, gasoline, 2-cycle oil, ethanol-shield fuel additive, carburetor clean-out, sparkplug replacement, and seasonal fuel preservatives and stabilizers (a one-time fuel savings alone of at least \$25)
- Avoid renting a bucket lift, scissor lift, or boom lift to safely reach tall limbs

What is the file size for sharpening the chain on my Saw Joe Pole Saw?

Your Saw Joe Pole Saw uses an Oregon 91PX chain that is sharpened with a 5/32" sized file. For further information about sharpening your Pole Saw chain, please see the table below: