




SILVERSTONE

Frost Knight Series

liquid cooling
user's manual



Contents

A



CASE SCREW x12

B



LGA 115X / 1200 / 1700 / 1851
SCREW x4

C



CLIP SCREW x4

D




THERMAL GREASE x1

E




AMD CLIP x2

F




INTEL CLIP x2

G




LGA 115X / 1200 / 1700 / 1851
BACK PLATE x1

H




3 IN 1 FAN CABLE x1





H




A



INTEL







Intel LGA 115X / 1200







Intel LGA 1700 / 1851


AMD



AMD Socket AM4/AM5



H



PLEASE CONFIRM THE CONNECTOR, THE DEFINITION AND DIRECTION OF YOUR PIN HEADER WHEN CONNECTING CABLES.

ENSURE ARGB CONTROLLER / MOTHERBOARD HAS SAME +5V PIN DEFINITION AS NOVAPEAK SERIES.

SilverStone Technology Co., Ltd.

www.silverstonetek.com

support@silverstonetek.com