

HC5 Series

24HC5QR

User Manual

AOPEN LCD Quick Start Guide (QSG)

Important safety instructions

Please read the following instructions carefully


- Cleaning the LCD monitor screen: First, make sure the power cord you are using meets the standards for your region.
 - Turn off the LCD monitor and unplug the power cord.
 - Spray a non-soluble cleaning solution onto a cloth and gently wipe the screen.
 - Never spill any liquid directly onto or into the screen or its case.**
 - Do not use any ammonia- or alcohol-based cleaners on the LCD monitor screen or case.**
 - AOPEN is not responsible for damage caused by the use of any ammonia or alcohol based cleaners.
- Do not place the LCD display near a window. Exposure to rain, moisture, or direct sunlight can cause serious damage to when the device.
- Do not press on the LCD screen. Excessively forceful pressing can cause permanent damage to the display.
- Do not remove the case or attempt to repair the machine by yourself. All maintenance tasks should be performed by an authorized technician.
- Store the LCD display in a room with a temperature between -20°C - 60°C (-4°F - 140°F). Permanent damage may result if the LCD display is stored outside of this range.
- If any of the following situations occur, unplug the monitor immediately and contact an authorized technician:
 - The signal cable between the monitor and the computer is worn or damaged.
 - Liquid spills onto the LCD display or the display is exposed to rain.
 - The LCD monitor or case is damaged.

Attaching the monitor base

- Unpack the monitor base and place the base on a smooth work surface.
- Unpack the monitor.
- Attach the monitor stand arm to the base.
 - Make sure the base snaps into the monitor stand arm. (Selected models only)
 - Turn the white screw with the included tool or a suitable coin to secure the base to the stand arm (select models only)


Connect the monitor to your computer

- Turn off your computer and unplug the power cord.
- 2-1 Connect Video Cable
 - Make sure both the monitor and computer are powered-OFF.
 - Connect the VGA cable to the computer. (Optional)
- 2-2 Connect HDMI Cable (Only HDMI-input model) (Optional)
 - Make sure both the monitor and computer are powered-OFF.
 - Connect the HDMI cable to the computer.
- 2-3 Connect DP Cable (Only DP-input model) (Optional)
 - Make sure both the monitor and computer are powered-OFF.
 - Connect the DP cable to the computer.
- Connect the Audio cable (only Audio input model) (optional)
- Connect the USB Type C Cable (only USB Type C input model) (Optional)
- Insert the monitor power cable into the power port at the back of the monitor.
- Plug the power cords of your computer and your monitor into a nearby electrical outlet.
- Select Power-off USB charge ON/OFF to enable/disable Power-off USB charge function. (Optional)



~	~	Note: The location and names of the sockets on the monitor may vary according to monitor model, and some sockets may not be available for some models.
HDMI (optional)	~ (optional)	
VGA IN (optional)	USB (optional)	
AUDIO IN (optional)	DP (optional)	
AUDIO OUT (optional)	USB Type C (optional)	

External control



No.	Item	Description
1	Menu/Nav/OK button	Power on/Long press to Power off. Enter the main menu, Select/Adjust menu options.

Regulatory and safety statements

FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is installed in a residential area. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with instructions, may cause interference to radio communications.

However, there is no guarantee that interference will not occur in a specific installation. If the device does cause interference to radio or television reception (which can be determined by the switchgear), it is recommended that the user take one or more of the following measures to eliminate the interference:

- Readjust the direction or position of the receiver antenna.
- Increase the distance between the device and the receiver.
- Connect the device power to a power outlet that is different from the circuit to which the receiver is connected.
- Contact your retailer or an experienced radio/TV technician for help.

Note

To prevent damage to the monitor, do not lift the monitor using the stand.

Note: shielded cable

All connections to other computing devices must be through shielded cables to comply with EMC regulations.

Note: peripherals

Only certified peripherals (input/output devices, terminals, printers, etc.) that meet Class B limits should be connected to the device. Using uncertified peripherals may cause interference to radio and television reception.

Note

Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this product.

Operating conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must be able to accept any interference received, including interference that may cause undesired operation.

Note: Canadian users

This Class B digital device complies with Canadian ICES-003 specifications.

Remarque à l'intention des utilisateurs canadiens

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

Explanatory note on "Regulations on the Management of Waste Electrical and Electronic Products Recycling and Disposal"

To better care for and protect our planet, when the user no longer needs this product or the product end of life, please comply with national laws and regulations on the recycling of electrical and electronic product waste, and recycle it through local manufacturers with nationally recognized recycling qualifications.

Abandonment of waste equipment for EU household users



This symbol on the product or on its packaging indicates that the product must not be disposed of with other household waste. When disposing of used devices, it is your responsibility to bring it to a collection point that recycles used electrical and electronic equipment. The separate collection and recycling of used devices at the time of disposal helps to conserve natural resources and ensures that they are recycled in a manner that protects human health and the environment. For more information about recycling points for used devices, please contact your local city office, household waste disposal service, or the shop where you purchased the product.

CE declaration of conformity

Hereby, AOPEN Smartview Inc., declares that this LCD monitor is in compliance with the essential requirements and other relevant provisions of EMC Directive 2014/30/EU, Low Voltage Directive 2014/35/EU, and RoHS Directive 2011/65/EU and Directive 2009/125/EC with regard to establishing a framework for the setting of ecodesign requirements for energy-related product.

AOPEN monitor is purposed for video and visual display of information obtained from electronic devices.

SPECIFICATION

LCD Panel	Driving System	TFT Color LCD	
	Size	23.6"W (60 cm)	
	Pixel Pitch	0.272mm (H) x 0.272mm (V)	
	Brightness	250 cd/m ² (Typical)	
	Contrast	10000000:1 Max (ACM)	
	Viewable Angle	178°(H), 178°(V) (CR=10)	
	Response Time	1ms(TVR)	
	Panel Type	VA	
	H-Frequency	HDMI: 31.469-192.692KHz DP: 31.469-192.692KHz	
	V-Frequency	HDMI: 48-165Hz DP: 48-165Hz	
Display Colors		16.7M Colors	
Dot Clock		HDMI: 393.092MHz DP: 393.092MHz	
Maximum Resolution		DP: 1920x1080 @165Hz HDMI: 1920x1080 @165Hz	
Plug & Play		VESA DDCCI/DDC2B	
Power Consumption	On Mode	21W(Typical)	
	Sleep mode	0.5W(Typical)	
	Off Mode	0.3W(Typical)	
Input Connector		HDMI (Only HDMI-Input Model) (Optional) DP(Only DP-Input Model) (Optional)	
Input Video Signal		HDMI (Only HDMI-Input Model) (Optional) DP(Only DP-Input Model) (Optional)	
Speakers		2 W x 2 (Only Audio-Input Model) (Optional)	
Maximum Screen Size		Horizontal: 521mm Vertical: 293mm	
Power Source		INPUT: 100-240 V~50/60 Hz	
Environmental Considerations		Operating Temp: 0° to 40°C Storage Temp: -20° to 60°C Operating Humidity: 20% to 80%	
Dimensions		539.8 (W) x 414.1 (H) x 203.0 (D) mm	
Weight (N. W.)		3.00kg (net)	
Mechanism Specifications		Tilt: -5°~20° Swivel: No Height Adjustment: No Pivot: No Detachable foot stand: Yes	
External Controls	Switch/Buttons	Menu/Navi/OK	
	Functions	Brightness Contrast Low Blue Light Black Boost ACM HDR Super Sharpness Gamma Color Temp. Modes Color Space Grayscale Mode 6-axis Hue 6-axis Saturate Volume Mute Over Drive FreeSync Premium TVR Refresh Rate Num Ultra-low latency Aim Point	Language OSD Timeout Transparency OSD Lock Input Auto Source DP Format Wide Mode DDC/CI HDMI Black Level Quick Start Mode Information Reset All Settings
Specifications vary depending on model and/or region.			

Find manuals and other documents for your AOPEN product on the official AOPEN support website.

AOPEN 液晶显示器快速入门指南 (QSG)

重要安全说明

请仔细阅读下列说明。


1. 清洁 LCD 显示器屏幕：首先确认使用的电源适配器符合你所使用的地区标准。
 - 关闭液晶显示器并拔下电源线。
 - 将非溶剂清洁剂喷洒到抹布上，轻轻擦拭屏幕。
 - **切勿将任何液体直接溅到或流入屏幕或机箱上。**
 - **请勿在 LCD 显示器屏幕或机箱上使用任何氨或酒精类清洁剂。**
 - 对于因使用氨水或酒精清洁剂造成的损坏，AOPEN 不承担责任。
2. 不要将 LCD 显示器放置在窗户附近。显示器遭受雨淋、受潮或阳光直接照射可能导致严重损坏。
3. 不要按压 LCD 屏幕。过分用力按压可能导致显示屏永久性损坏。
4. 不要卸下机盖或尝试自行维修本机器。应由经过授权的技术人员执行各种维修任务。
5. 将 LCD 显示器存放在温度为 -20°C 到 60°C (-4°F 到 140°F) 的房间内。在此范围之外存放 LCD 显示器时，可能导致永久性损坏。
6. 发生下列情形时，应立即拔下显示器的电源线并致电授权的技术人员：
 - 显示器与 PC 之间的信号线磨损或损坏。
 - 液体溅到 LCD 显示器上或者显示器遭受雨淋。
 - LCD 显示器或机壳损坏。

安装显示器底座

1. 拆开显示器底座包装，将底座放到平稳的工作台面上。
2. 拆开显示器包装。
3. 将显示器支架臂与底座锁紧。
 - 确保底座卡入到显示器支架臂上。（仅限部份型号）
 - 用随附的工具或合适的硬币转动白色螺钉，将基座固定到支架臂上（仅限部份型号）


将显示器连接计算机

1. 关闭计算机，并拔下电源线。
2. 2-1 连接视频线
 - a. 确保显示器和电脑均已关机。
 - b. 将 VGA 线连接到计算机。（选配）
- 2-2 连接 HDMI 线（仅限于 HDMI 输入型号）（选配）
 - a. 确保显示器和电脑均已关机。
 - b. 将 HDMI 线连接到计算机。
- 2-3 连接 DP 线（仅限于 DP 输入型号）（选配）
 - a. 确保显示器和电脑均已关机。
 - b. 将 DP 线连接到计算机。
3. 连接音频线（仅限于音频输入型号）（选配）
4. 连接 USB Type C 线缆（仅限 USB Type C 输入型号）（选配）
5. 将显示器电源线插入显示器背面的电源端口。
6. 将电脑和显示器的电源线插入附近的电源插座。
7. 选择关机 USB 充电开关，您可以开启或关闭此关机 USB 充电功能。（选配）



~		注意：显示器的插口位置和名称可能因显示器型号而不同，有些型号可能未配备某类插口。
HDMI（选配）	🎧（选配）	
VGA IN（选配）	USB（选配）	
AUDIO IN（选配）	DP（选配）	
AUDIO OUT（选配）	USB Type C（选配）	

外部控制



编号	项目	说明
1	菜单/导航/确认按钮	开机/长按关机。 进入主菜单，选择/调整菜单选项。

监管和安全声明

FCC 声明

经测试，本设备符合 FCC 规则第 15 部分对 B 类数字设备的限制规定。这些限制用于提供合理的保护措施，以防该设备在住宅区安装时产生有害干扰。本设备产生、使用并辐射射频能量，如果未遵照说明进行安装和使用，可能会对无线电通信产生干扰。

但也不能保证在特定的安装中不会产生干扰的问题。如果本设备确实对无线电或电视接收造成干扰（可以通过开关设备来确定），建议用户采取以下一种或多种措施排除干扰：

- 重新调整接收天线的方向或位置。
- 增大本设备与接收器的间距。
- 将设备电源连接到不同于接收器所连接到的电路的电源插座上。
- 咨询经销商或有经验的无线电 / 电视机技术人员以获取帮助。

注意

为防止对显示器造成损坏，请勿通过此底座抬起显示器。

注意：屏蔽电缆

所有到其它计算设备的连接都必须使用屏蔽电缆，以便符合 EMC 法规的要求。

注意：外设

只有经过认证，符合 B 类限制的外设（输入 / 输出设备、终端、打印机等）才可连接到本设备。使用未认证的外设可能会导致无线电和电视接收的干扰。

注意

任何未经制造商明确批准的改动或修改，都可能使用户丧失由联邦通讯委员会赋予的操作本产品之权利。

操作条件

本设备符合 FCC 规则第 15 部分。操作符合以下两个条件：（1）本设备不会造成有害干扰，（2）本设备必须能够承受收到的干扰，包括任何可能会造成操作异常的干扰。

注意：加拿大用户

本 B 类数字设备符合 Canadian ICES-003 的规范。

Remarque à l'intention des utilisateurs canadiens

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

《废弃电器电子产品回收处理管理条例》提示性说明

为了更好地关爱及保护地球，当用户不再需要此产品或产品寿命终止时，请遵守国家废弃电器电子产品回收处理相关法律法规，将其交给当地具有国家认可的回收处理资质的厂商进行回收处理。

欧盟地区家庭用户废旧设备的废弃



产品或其包装上的此符号表示该产品不得与其它家庭垃圾一起废弃。废弃废旧设备时，您有责任将其送交专门回收废旧电气和电子设备的回收点。废弃时分类收集和回收废旧设备有助于节省自然资源，确保以保护人类健康和环境的方式进行回收利用。有关废旧设备回收点的详细信息，请与您当地的市政机构、家庭垃圾处理服务机构或产品的销售店联系。

管制认证



依据中国《电器电子产品有害物质限制使用管理办法》，简称《管理办法》或《China RoHS》之规定，列出宏碁电子信息产品中可能含有的有害物质的名称及含量于以下表格中

显示器						
部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
金属机构件	X	○	○	○	○	○
塑料机构件	○	○	○	○	○	○
电路板组件*	X	○	○	○	○	○
液晶显示屏	X	○	○	○	○	○
电源模块	X	○	○	○	○	○
电源线	○	○	○	○	○	○
外部信号连接线	X	○	○	○	○	○
喇叭	X	○	○	○	○	○

本表格依据SJ/T 11364的规定编制

*：电路板组件包括印刷电路板及其构成的零部件，如电阻、电容、集成电路、连接器等

○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下

x：表示该有害物质至少存在于该部件的某一均质材料中，是因为目前业界还没有成熟的可替代技术，以致含量虽然超出GB/T 26572规定的限量要求；但仍然符合欧盟RoHS指令所容许的豁免条款及电池指令的要求

AOPEN LCD 快速入門指南（QSG）

重要安全指示

請詳閱下列說明


- 清潔液晶顯示器螢幕：首先，請確保您使用的電源線符合您所在地區的標準。
 - 關閉液晶顯示器，然後拔下電源線。
 - 在布料上噴灑不溶性清潔液，然後輕輕擦拭螢幕。
 - 切勿讓任何液體直接灑到螢幕或外殼的上面或裡面。**
 - 請勿在液晶顯示器螢幕或外殼上使用任何基於氨或酒精的清潔劑。**
 - 對於使用任何基於氨或酒精的清潔劑而造成的損壞，AOPEN 概不負責。
- 請勿將液晶顯示器放在窗戶附近。淋到雨、沾到濕氣或陽光直射會造成裝置嚴重損壞。
- 請勿在液晶螢幕上按壓。過度用力按壓會造成顯示器永久損壞。
- 請勿卸下外殼或嘗試自行修理機器。所有維護工作均應由經授權的技術人員進行。
- 將液晶顯示器存放在溫度介於 -20°C 至 60°C（-4°F 至 140°F）之間的房間裡。如果液晶顯示器存放在超出此範圍的地方，則可能導致永久損壞。
- 如果發生以下任何一種情況，請立即將顯示器插頭拔下並聯絡經授權的技術人員：
 - 顯示器與電腦之間的訊號線磨損或損壞。
 - 液體濺到液晶顯示器上或顯示器淋到雨。
 - 液晶顯示器或外殼受損。

安裝顯示器基座

- 打開顯示器基座的包裝，然後將基座放在光滑的工作表面上。
- 打開顯示器的包裝。
- 將顯示器支架臂接到基座。
 - 確保基座卡入顯示器支架臂。（僅限所選型號）
 - 用隨附的工具或合適的硬幣轉動白色螺絲，以將基座固定到支架臂（僅限選擇機型）


將顯示器連接到電腦

- 關閉電腦，然後拔下電源線。
- 2-1 連接視訊線
 - 請確定顯示器與電腦的電源皆已關閉。
 - 將 VGA 線連接至電腦。（選配）
- 2-2 連接 HDMI 纜線（僅限 HDMI 輸入機型）（選配）
 - 請確定顯示器與電腦的電源皆已關閉。
 - 將 HDMI 線連接至電腦。
- 2-3 連接 DP 線（僅限 DP 輸入機型）（選配）
 - 請確定顯示器與電腦的電源皆已關閉。
 - 將 DP 線連接至電腦。
- 連接音訊線（僅限音訊輸入機型）（選配）
- 連接 USB Type C 連接線（僅限 USB Type C 輸入機型）（選配）
- 將顯示器電源線插入顯示器背面的電源埠。
- 將電腦與顯示器的電源線插入附近的電源插座。
- 選擇關閉 USB 電源充電開啟/關閉以啟用/停用關閉 USB 電源充電功能。（選配）



~		注意：顯示器上插槽的位置和名稱可能會因顯示器機型而異，有些機型可能無法使用某些插槽。
HDMI (選配)	⌂ (選配)	
VGA IN (選配)	USB (選配)	
AUDIO IN (選配)	DP (選配)	
AUDIO OUT (選配)	USB Type C (選配)	

外部控制



編號	項目	說明
1	選單/導覽/確定按鈕	開啟電源/長按即可關閉電源。 進入主選單，選取/調整選單選項。

規範和安全聲明

FCC 聲明

依據 FCC 規定第 15 篇，本設備經過測試證明符合 B 類數位裝置的限制。這些限制旨在當設備安裝在住宅區時，提供合理保護以防有害干擾。本設備產生、使用並且會輻射射頻能量，而且如果未按照說明進行安裝和使用，可能對無線電通訊造成干擾。

然而，不保證特定安裝不會出現干擾。如果裝置的確對無線電或電視接收造成干擾（這可藉由關閉設備確定），則建議使用者採取以下一或多種措施將干擾排除：

- 重新調整接收器天線的方向或位置。
- 增加裝置與接收器之間的距離。
- 將裝置電源連接到有別於接收器所連接電路的電源插座。
- 如需幫助，請聯絡您的零售商或有經驗的無線電/電視技術人員。

注意

為避免損壞顯示器，請勿使用支架將顯示器升起。

注意：屏蔽線

與其他運算裝置的所有連接都必須透過屏蔽線，以符合 EMC 規範。

注意：週邊設備

只能將符合 B 類限制的認證週邊設備（輸入/輸出裝置、終端、印表機等）連接到裝置。使用未經認證的週邊設備可能對無線電和電視接收造成干擾。

注意

未經製造商明確核准的任何變更或修改都可能讓使用者喪失運作本產品的權限。

運作條件

本產品符合 FCC 規定第 15 篇。運作時可符合下列兩項條件：(1) 本裝置可能不會造成有害干擾，以及 (2) 本裝置必須能夠接受任何收到的干擾，包括可能造成非所欲運作的干擾。

注意：加拿大地區使用者

本 B 類數位裝置符合加拿大 ICES-003 規格。

Remarque à l' intention des utilisateurs canadiens

Cet appareil numrique de la classe B est conforme à la norme NMB-003 du Canada

關於「廢棄電氣和電子產品回收和棄置管理規範」的註記

為了更加照護和保護我們的星球，當使用者不再需要本產品或產品報廢時，請遵守有關電氣和電子產品廢棄物回收的國家法律和規範，並透過具有國家認可回收資格的當地製造商進行回收。

歐盟家庭使用者廢棄設備棄置



產品上或其包裝上的這種符號表示產品不得與其他家庭垃圾一起棄置。棄置用過的裝置時，您有責任將其帶到回收已用電氣和電子設備的收集點。已用裝置在棄置時的單獨收集和回收有助於節省自然資源，並且確保是以保護人類健康和環境的方式將其回收。如需有關已用裝置回收點的更多資訊，請聯絡您當地城市辦事處、家庭廢棄物棄置服務或您購買產品所在商店。

CE 符合性聲明

AOPEN Smartview Inc. 特此聲明，本款液晶顯示器就能源相關產品，符合 EMC 指令 2014/30/EU、低電壓指令 2014/35/EU 和 RoHS 指令 2011/65/EU，以及針對建立框架用於制定生態設計要求之指令 2009/125/EC 的基本要求和和其他相關規定。

AOPEN 顯示器專用於對得自電子裝置之資訊進行視訊和視覺化顯示。

規格

液晶面板	驅動系統		TFT 彩色液晶
	尺寸		23.6 吋寬 (60 公分)
	像素間距		0.272 公釐 (水平) × 0.272 公釐 (垂直)
	亮度		250 cd/m ² (標準值)
	對比		100000000:1 最大 (ACM)
	可視角		178° (水平) 178° (垂直) (CR=10)
	響應時間		1 毫秒 (TVR)
	面板類型		VA
	水平頻率		HDMI : 31.469 - 192.692 kHz DP : 31.469 - 192.692 kHz
垂直頻率		HDMI : 48 - 165 Hz DP : 48 - 165 Hz	
顯示色彩			1670 萬色
點時脈			HDMI : 393.092 MHz DP : 393.092 MHz
最大解析度			DP : 1920×1080 @ 165 Hz HDMI : 1920×1080 @ 165 Hz
隨插即用			VESA DDCI/DDC2B
功耗	開啟模式	21 W (標準值)	
	休眠模式	0.5 W (標準值)	
	關閉模式	0.3 W (標準值)	
輸入接頭			HDMI (限 HDMI 輸入型號) (選用) DP (限 DP 輸入型號) (選用)
輸入視訊訊號			HDMI (限 HDMI 輸入型號) (選用) DP (限 DP 輸入型號) (選用)
揚聲器			2 Wx2 (僅限音訊輸入機型) (選用)
最大螢幕尺寸			水平 : 521 公釐 垂直 : 293 公釐
電源			輸入 : 100 - 240 V~ 50/60 Hz
使用環境需知			運作溫度 : 0°C 至 40°C 儲存溫度 : -20°C 至 60°C 運作濕度 : 20% 至 80%
尺寸			539.8 (寬) × 414.1 (高) × 203.0 (深) 公釐
重量 (淨重)			3.00 公斤 (淨重)
機構規格			傾斜角度 : -5° 至 +20° 旋轉 : 無 高度調整 : 無 關節 : 無 分離式底座 : 有
外部控制	開關/按鈕	選單 / 導覽 / 確認	
	功能	亮度	語言
		對比	OSD 顯示時間設定
		低藍光	透明度
		黑色增豔	OSD 鎖定
		ACM	輸入
		HDR	自動訊號源
		超清晰度	DP 格式
		色差補正	寬螢幕模式
		色溫	DDC/CI
		模式	HDMI 黑階
		色彩空間	快速開啟模式
		灰階模式	資訊
		6 軸色調	重設所有設定
		6 軸飽和	
		音量	
		靜音	
		顯示反應速度	
FreeSync Premium			
TVR			
更新頻率數字			
超低延遲			
瞄準點			

規格視機型及/或地區而定。

請在 AOPEN 官方支援網站尋找 AOPEN 產品的手冊和其他文件。

單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁺⁶)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
塑膠外殼	○	○	○	○	○	○
五金結構件	○	○	○	○	○	○
面板	—	○	○	○	○	○
底座組件	○	○	○	○	○	○
電路板	—	○	○	○	○	○
電源供應器	—	○	○	○	○	○
其它線材	○	○	○	○	○	○

備考1. “超出0.1 wt %” 及 “超出0.01 wt %” 係指限用物質之百分比含量超出百分比含量基準值。

Note 1: “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.

備考2. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。

Note 2: “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

備考3. “—” 係指該項限用物質為排除項目。

Note 3: The “—” indicates that the restricted substance corresponds to the exemption.