
KINGONE iPad Pencil

English Manual



Indicator Light Status:

- 1.Green light: Normal operation.
- 2.Flashing green light: Indicates charging.
- 3. Flashing red light: Indicates the need for charging.



1. Press and hold for 3 seconds to power on. The indicator light will turn green, indicating normal

Power On State (Green Light)

1.Power-on status (green)

- 1. Press and hold for 3 seconds to power off. The
- 2.If inactive for 5 minutes, the device will automatically power off. The indicator light will



- 1.Attach to the iPad for wireless charging. The green light will breathe to indicate normal charging.
- 2.Use a Type-C adapter for wired charging. 3. The stylus will enter sleep mode, and the





Magnetic suction wireless charging



Type c wired charging

Bluetooth Connection:

- 1. Press and hold for 3 seconds to power on. Theindicator light will turn green, indicating it is turned on
- 2.On your iPad, go to Settings and navigate to theBluetooth menu.Enable Bluetooth and select"P12"to pair and establish a Bluetooth




Bluetooth Shortcuts:

When the stylus is powered on and connected to Bluetooth with the green indicator light working, you can use the following shortcuts:

- --Single click: Return to the home screen. -- Double click: Display multitasking view.
- -- Triple click: Take a screenshot of the cur
- rent page.


How to Display Stylus Battery Level on iPad:

1.Long press the "+" button in the top corner of the iPad screen to add a widget. 2. Select the battery widget from the available options. There are three modes to choose from



How to change the pen tip:

Rotate the pen tip to the left, remove the damaged pen tip, replace it with a new one. and rotate it to the right until it remains stationary. then it can be used normally



Troubleshooting Common Issues:

1. Stylus cannot connect to Bluetooth If the stylus can power on correctly with a green light and can be used for writing but cannot connect to Bluetooth, go to the Bluetooth settings page and check if there are more than 5 connected devices. If so, ignore all Bluetooth devices and restart the stylus to search and reconnect to "P12". The issue may be caused by too many conflicting

Bluetooth connections 2.Loose or rotating stylus tip

Replace the stylus tip with a new one. Tighten it properly to ensure normal usage

3.Stylus not working a. If the stylus powers on with a red light that quickly goes off, it indicates low battery and needs to be charged before normal operation. b. If the stylus powers on without light, it may be in

deep sleep mode. To activate the stylus from deep sleep mode using an iPad charger, plug the stylus directly into a Type-C adapter for wired charging. The indicator light will turn red and breathe, indicating normal charging. It needs to be charged for about 20 minutes before it can be used normally.

4. Green light is on but unable to write a. Check if you have used the original stylus before

If so, go to the Bluetooth settings and ignore the Bluetooth connection of the origina stylus. b. Try reinstalling the provided stylus tip and attempt writing again. 5. Green light is on but there is a disconnect a. Check if the stylus tip is properly tightened. A

broken stylus tip can also cause a disconnect b.Check if the iPad screen is clean and free from oil or water as this can also cause a disconnect c.Check the thickness of the iPad screen protector A thick screen protector can affect the connection.

Product Specifications:

Model: P12

Size: 165x8 9mm

Charging Method: Type-C wired fast charging/iPad magnetic wireless charging Charging Time: Approximately 1 hour (wireless charging),

approximately 20 minutes (wired charging) Stylus Tip Size: 1.7mm

Power Saving Mode: Automatically enters sleep mode after 5 minutes of inactivity

Compatible Devices:

iPad Pro 12.9"(3rd/4th/5th/6th) [A1876/A2014/A1895/A1983/A2229/A2233 A2069/A2232/A2378/A2461/A2379/A2462/ A2436/A2764/A2347/A27661 iPad Pro 11"(1st/2nd/3rd/4th) A2013/A1934/A1979/A1980/A2228/A2231 A2068/A2030/A2377/A2459/A2301/A2460 A2435 A2761A2762 A27591 iPad Air(4th/5th)[A2316/A2324/A2325 A2072/A2588/A2589/A2591 iPad Mini(6th)[A2567/A2568/A2569 It is also a model that supports wireless charging How to check your iPad model:iPad [Settings]->[General]->[About]

Important Note:

1.Only compatible with 2018/2019/2020/2021/ 2022 Apple iPad/iPad Pro/iPad Air/iPad mini models. Not compatible with iPhone, Android, Microsoft devices, and earlier versions of iPad. 2. There is no magnetic wireless charging function on iPad 7th, 8th, 9th, 10th generation.

Email: ind-support@kingoneglobal.com