How add camera to Bitvision app

This manual refers to Zintronic® 'B' & 'D' product series.



Table of Contents:

Section I – Adding camera to Bitvision app.


- Adding camera with serial number
- Adding camera to live view......

I. Adding camera to Bitvision app

- Adding camera with serial number.
- 1. Creat an account (IMPORTANT: EMAIL THAT WITH YOU REGISTER THE ACCOUNT MUST BE FROM GMAIL INBOX FOR EXAMPLE: XYZ@GMAIL.COM)
- 2. Login to newly created account.
- 3. Go to main menu of the app.



- 4. Press the icon of three lines in the top left corner (as marked on the picture above).
- 5. Press 'device manage' option from the list.




6. Press an icon depicting white plus symbol encircled by red background in the bottom right corner.



7. Choose 'SN add' option.

Add Device




8. After clicking that option you will be directed to a phone camera to scan the SN from a QR code placed on a camera sticker (you can also write it manually if you wish to do so, after pressing option in the top right corner of the screen). Image below depicts the mentioned both sticker and the QR code.




- 9. Then fill in parameters you're asked, they go as follow:
- SN: (already filled through scanning the QR code).
- Name: your own camera name (you can choose it by yourself).
- · Login: camera login (by default 'admin').
- Password: camera password (by default 'admin').
- Captcha code: code from the camera's sticker.
- Group: choose 'my devices'.


Picture below shows properly filled parameters.



10. After filling the parameters, choose 'add device' option.



11. If the camera has been added successfully it will show up on with the green dot indicating it's online.



- Adding camera to live view
- 1. To add the camera to live view, in main menu click on the plus on a empty screen and choose your camera, done!

