MiLi MiTag 英文说明书(Android)

80x80mm HD-P16 Android版本 105g双铜 单色正反面印刷 风琴折 (内销客制)



Product Overview

MiTag is a smart tracker device that uses Google's Find My Device service, paired with the "Google Find My Device" app on Android devices, to quickly and securely locate your personal items on Google Maps. All location information remains private, and even Google cannot access it.

Before You Start

- MiTag only supports the "Google Find My Device" app. Please make sure to download and install this app from the "Play Store" before use.
- The device is compatible only with Android devices running Android 9 or
- MiTag does not support Huawei devices.
- · Once MiTag is paired with a device, it will be locked and cannot be paired with

Button and Sound Instructions

Power On: Press the button once (a beep will sound).

Power Off: Press and hold the button for 5 seconds



(two short beeps will sound).

1: Open the "Google Find My Device" app, select your MiTag, tap the Settings button, then tap "Remove from Find My Device" and confirm.

2: After removing it, press the MiTag button 6 times rapidly, and when you hear a long beep, the device will be reset.

Note: Please power on the MiTag and remove the device from the "Google Find My Device" app before resetting.

Quick Start Guide

- 1.Make sure your phone's Bluetooth and network are turned on.
- 2.Press the button once to turn on MiTag (a beep will sound).
- 3. Bring MiTag close to your Android device and wait for the pop-up to show MiTag. (Remark: If no pop-up appears, please restart your phone and try again).
- 4.Tap "Connect", read and accept the prompts to complete the pairing.
- 5.In the "Google Find My Device" app, select "MiTag" to customize the device name and Category.

MiTag will automatically power off after 3 minutes of standby.

In the "Google Find My Device" app, select your MiTag and tap "Play Sound" to locate your device. Once found, tap Stop Sound to silence the device.

In the "Google Find My Device" app, select your MiTag, tap the device to view its

To navigate to the location, tap "Get Directions" to open map navigation.

In the "Google Find My Device" app, select your MiTag and tap "Mark as Lost".

-02-

Add your contact information and you will get a notified if the Find My Device

MiTag Location Sharing

In the "Google Find My Device" app, select your MiTag, then tap "Share Device".

After completing the reset process, then connect to another Android phone.

Batterv

MiTag contains a button battery. The battery may need to be replaced during the life of the product. Replace only with batteries of the same type (CR2032) and rating, observing correct polarity.

Battery Replacement

- 1. Disassemble the product into two parts through the gap between the upper cover and the lower cover
- Remove the battery.
- 3. Insert the CR2032 battery into the device with the positive (+) side facing up.
- 4. Connect the upper cover and the lower cover, and press tightly.





Safety and handling

Important safety information to handle MiTag with care. It contains sensitive electronic components, including batteries, and can be damaged, impair functionality, or cause injury if dropped, burned, punctured, crushed, disassembled, or exposed to excessive heat or liquid or to environments with high concentrations of industrial chemicals. Don't use a damaged MiTag.

MiLi 2 Years Limited Warranty

Hali-Power's warranty obligations for MiLi products are limited to the terms set forth below: Shenzhen Hali-Power Industrial Co., Ltd. ("MiLi") warrants MiLi products against defects in materials and workmanship for a period of 2 years from the date of original purchase("Warranty Period"). If a defect arises and a valid claim is received by MiLi within the warranty period, at an option, MiLi will:

- 1. Repair the product freely.
- 2. Exchange the product with another new product.
- 3. The freight rose from goods return will be shared by MiLi and Customer together. (customer will have to bear the freight to the factory while MiLi will bear the freight to the customer). For any maintenance and repairs out of service range, the customer will have to bear the freight.

Environmentally friendly disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.



Android Compatibility

Pairing requires an Android phone or tablet.

To use Google's Find My Device app on your Android phone or tablet to locate Smart Finder, the device must be running Android 9 or later with Google Play

Google's Find My Device helps you find your belongings quickly and safely – even when your devices are offline or far away. From your misplaced car keys to the tablet hiding beneath your couch cushions, it's easier than ever to keep track of your items. Plus, all of your location information remains private – even from Google.

Contact us!

Customer Service: cs@hali-power.com Online Store: mili-shop.com



