

DENON®

AVR-X520BT

AV SURROUND RECEIVER

Quick Start Guide

Kurzanleitung / Guide de démarrage rapide / Guida di Avvio Rapido /
Guía de inicio rápido / Snelhandleiding / Snabbstartsguide /
Краткое руководство пользователя / Skrócona instrukcja obsługi /
Hızlı Başlangıç Kılavuzu

Read Me First....

Bitte zuerst lesen... / Lisez-moi en premier.... / Nota preliminare.... /
Lea esto primero.... / Lees mij eerst... / Läs detta först... /
Прочитайте в первую очередь... / Przeczytaj to najpierw.... /
Önce Beni Oku...

ENGLISH

DEUTSCH

FRANÇAIS

ITALIANO

ESPAÑOL

NEDERLANDS

SVENSKA

РУССКИЙ

POLSKI

TÜRKÇE

Welcome

Thank you for choosing a Denon AV receiver. This guide provides step-by-step instructions for setting up your AV receiver.

Please do not return this unit to the store – call for assistance.






If you need help... :

If you need additional help in solving problems, contact Denon customer service in your area.

www.denon.com

Before You Begin












Required for Setup

 TV	 Speaker cables	 Speaker systems
 HDMI cable	 Subwoofer cable	



- When connecting this unit to a device that is compatible with the Deep Color and 4K, use a “High Speed HDMI cable with Ethernet” that displays the HDMI logo.
- These drawings are for illustrative purposes only and may not represent the actual product(s).

What's In the Box

Quick Start Guide		FM indoor antenna	
Owner's Manual		AM loop antenna	
Safety Instructions		Sound calibration microphone	
Notes on radio		Remote control unit	
Receiver		R03/AAA batteries	
Power cord			



Using your own tripod enables settings to be automatically configured to the optimum listening environment, providing exceptionally high performance.

Setup



There are three steps to the setup process.

1 Installing batteries in the remote control unit

2 Connecting the receiver


3 Following the On-Screen Setup Assistant

1 Installing batteries in the remote control unit




2 Connecting the receiver



2.1) Place the receiver near your TV and connect the power cord.



2.2) Connect the receiver to your TV with an HDMI cable.





2.3) Turn on the TV.



TV remote control unit


2.4) Select the appropriate HDMI input on your TV.



TV remote control unit


2.5) Turn on the receiver.

- Press  to turn on the receiver.



2.6) Verify the connection.



- Verify that you can see this screen on your TV.



If this screen is not displayed, please go back and retry the steps again in the recommended sequence.

3 Following the On-Screen Setup Assistant

The Setup Assistant will walk you through connecting and configuring your speakers and components to your Denon receiver. Please use the remote control and follow the on-screen instructions.



Owner's Manual

Please reference to the Owner's Manual for more details about the setup and operation of the receiver and its features.

❑ Online Version

Enter the following URL into your web browser:
manuals.denon.com/AVRX520BT/EU/EN/



Online Manual




❑ Printable Version

Access the print version of the owner's manual from the included CD-ROM or select the "PDF Download" link from the Online Version.

1

Insert the disc into your PC.



2

Follow the screen or double click on the PDF file.

DENON®
www.denon.com

Printed in Vietnam 5411 11286 00AD
Copyright © 2015 D&M Holdings Inc. All Rights Reserved.