# **TEAC**

# Mini Wireless BT Soundbar SB20204M



# **USER MANUAL**

### TEAC Warranty Service Hotline 1300 553 315

Call us between Monday to Friday - 8.30AM to 5PM AEST

\*Please have your purchase receipt and the product's serial number ready

For other enquiries and support please visit www.teac.com.au


#### **IMPORTANT SAFETY INSTRUCTIONS**

- Heed all warnings and follow all instructions.
- Do not use this mini soundbar near water.
- Clean the unit with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat.
- Use only attachments / accessories specified by the manufacturer.
- To reduce the risk of electric shock, do not remove cover (or back). There are no userserviceable parts inside.
- Do not expose the mini soundbar to dripping or splashing liquids.
  Do not place objects filled with liquids (such as vases) on the soundbar.

#### **PACKAGE CONTENTS**

- Mini Soundbar x1
- USB Power Cable x1
- Line-in Cable x1
- User Manual x1

#### **CONTROL PANEL**



### **USB POWER CABLE**

To recharge and power on the soundbar, use the provided USB cable and then connect to a power outlet or USB slot of a computer.

#### **FUNCTION MODE**

#### **Bluetooth Function**

Long press the MODE button to switch to Bluetooth mode. Turn on the Bluetooth feature on your audio device, locate the Bluetooth name "SB20204M", and pair the mini soundbar with your audio device.

#### **USB Function**

Insert the USB into the USB port, and then press the MODE button until it is in USB mode.

#### LINE IN

Use the provided LINE IN cable (3.5mm to 3.5mm) to directly connect smart phones, tablets, and other music devices. Its corresponding signal source is LINE IN in the soundbar MODES.

#### **LED INDICATOR LIGHTS**

FUNCTION/MODE	COLOUR
Bluetooth	Blue
USB	Blinking Green
Line-In	Blue and Green
Power charging	Red

## **PRODUCT SPECIFICATIONS**

Built-in Rechargeable Battery	1500mAh
Power Input	DC 5V
RMS Power	2 x 2.5W
Speaker Output Power	10W
Speaker Size & Number	2.0" Full range speaker x 2 + Passive speaker x 1
Bluetooth Version	5.0
Bluetooth Distance	10M
Frequency Response	160HZ - 18KHZ
Supported Profile	A2DP / AVRCP
Audio Input	Line-in / USB / Bluetooth
Soundbar Dimensions	43 x 6.5 x 5.5cm
Net Weight	730g

#### **TERMS AND CONDITIONS**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

- 1. TEAC warrants that this product is free from defects in material and workmanship under normal domestic use with reasonable care and skill. Maintenance and cleaning (i.e. laser head) is not covered by this warranty. The TEAC warranty only applies to TEAC products purchased NEW from a TEAC Authorised Retailer in Australia. This warranty only applies to the original purchaser and cannot be transferred.
- 2. The benefits to the consumer given by this Warranty are in addition to other rights and remedies of the consumer under a law in relation to goods or services to which the warranty relates, being the Australian Consumer Law.
- 3. Refund or replacement via your TEAC Authorised Retailer is available for a period of 14 days after purchase for goods that have been inspected and determined to have a major failure. Refund and exchange is not applicable for change of mind.
- 4. Subject to the terms herein, this warranty effectively covers TEAC products under the 12 Month Replacement Warranty Scheme, 12 months from the date of original purchase.
- 5. The warranty is void and warranty claims may be refused, subject to the Australian Consumer Law, if:
- a) The product was not transported, installed, operated or maintained according to manufacturer instruction, or
- b) The product was abused, damaged, tampered, altered or repaired by any unauthorised persons,

or

- c) Product failure is due to accidents during use, installation or transit, power surges, use of defective or incompatible external devices, exposure to abnormal conditions such as excessive temperatures or humidity, or entry of liquids, objects or creatures into the product, cockroach infestations, or
- d) The customer is unable to provide proof of purchase of the product for verification, or
- e) The serial number of the product is missing or has been tampered with.
- 6. No one is authorised to assume any liability on behalf of TEAC or impose any obligation on it, in connection with the sale of any equipment other than as stated in this warranty and outlined above.
- 7. TEAC and/or its Authorised Service Centres reserve the right to inspect and verify whether the product is exhibiting a major failure as claimed by customers/retailers.