























<div></div> <div>使用说明书</div>	<div>配件清单</div> <div>使用产品前请仔细阅读本说明书，并妥善保管。</div> <div></div> <div>01</div>	<div>产品介绍</div> <div></div> <div>02</div>	<div>产品使用</div> <div></div> <div>03</div>	<div>收音机模式：（需插上3.5mm音频线，做为天线） 音箱开机状态，短按开机键即可开启收音机模式。短按+/-音量加减键切换电台，短按暂停键搜索电台。</div> <div></div> <div>TF卡播放模式：插入TF卡后，自动进入TF卡播放模式，即可播放TF卡内容。</div> <div></div> <div>04</div>	<div>线输入模式：在AUX孔内插入双头音频线，另一端插入通用3.5mm接口，即可变身音箱，可为电脑、iPad、手机等智能设备做音箱。</div> <div>（注：线输入模式时，音箱不能进行上一曲/下一曲歌曲切换，可调节音量/暂停/播放。）</div> <div></div> <div>充电：</div> <div>开机和关机状态下均可进行充电，可通过USB线连接电脑充电。充电时红灯长亮，充满时熄灭。</div> <div>低电量提示：</div> <div>电量低时会有低电请充电，之后会听见关机提示音，音箱此时会自动关机。</div> <div></div> <div>05</div>	<div>产品规格</div> <div><ul style="list-style-type: none">● 工作电压：3.7V● 充电电压：USB 5V● 喇叭规格：52mm4Ω3瓦● 信噪比：80 db● 电池容量：400mAh● 频率响应：20-20k Hz● 产品尺寸：83mm*80mm*34mm● 信号距离：10m-15m</div> <div>复位作用：使用过程中机器出现按键失控或者其它导致无法操作时，请用针状物体或者非金属条对准复位孔内开关轻按一下，重新开机即可正常使用。</div> <div>安全信息</div> <div>在使用和操作设备前，请阅读并遵守下面的注意事项，以确保设备性能最佳，并避免出现危险或非法情况。</div> <div>听力保护</div> <div>● 当您使用音箱收听音乐或通话时，建议使用音乐或通话所需的最小音量，以免损伤听力。</div> <div>● 长时间接触高音量可能会导致永久性听力损伤。</div> <div>● 驾车时接触高音量可能会导致注意力分散，从而导致事故。</div> <div>操作环境</div> <div>● 请勿在多次、潮湿、肮脏或靠近磁场的地方使用设备，以免引起设备内部电路故障。</div> <div>● 安放设备时，请远离具有强磁场或强电场的电器，如微波炉、电冰箱等。</div> <div>● 请勿在雷雨天气使用本设备。雷雨天气可能会导致设备故障或电击危险。</div> <div>● 请在温度-10℃~+55℃范围内使用本设备，并在温度-40℃~+70℃范围内存放设备及其配件。当环境温度过高或过低时，可能会对引起设备故障。</div> <div>当温度低于5℃时，电池的性能会受限制。</div> <div>06</div>	<div>● 请勿将设备放置在阳光直射的地方，如汽车仪表盘或窗台处。</div> <div>● 请勿将设备靠近热源或裸露的火源，如电暖器、微波炉、烤箱、热水器、炉火、蜡烛或其他可能产生高温的地方。</div> <div>● 请勿将大头针等尖锐金属物品放置在设备听筒或者扬声器附近，以免金属物品附着，对您造成伤害。</div> <div>充电器安全</div> <div>● 设备充电时，电源插座应安装在设备附近并易于触及。</div> <div>● 当充满电或者不充电时，请断开充电器与设备的连接并从未电源插座上拔除充电器。</div> <div>电池安全</div> <div>● 请勿拆解或改装电池、插入异物、或浸入水或其它液体中，以免引起电击漏液、过热、起火或爆炸。</div> <div>● 请勿跌落、挤压或穿刺电池，避免让电池遭受外部的压力，从而可能导致电池内部短路和过热。</div> <div>● 设备配有不可拆卸的内置电池，请勿自行更换电池，以免损坏电池或设备。</div> <div>● 请按当地规定处理电池，不可将电池作为生活垃圾处理。若电池处置不当可能会导致电击爆炸。</div> <div>注意事项</div> <div>1. 音箱需存放在干燥通风环境下，避免与油、水汽、潮湿和灰尘等接触，以免影响产品性能。</div> <div>2. 避免使用刻痕的有机溶剂或含有这些成分的物品清洁音箱。</div> <div>3. 音箱需按照要求正确规范的使用，注意使用环境对耳机的影响，为保证连接顺畅，建议手机和音箱之间的距离在10米范围内。</div> <div>4. 如音箱有连接不上或通讯不畅等其他问题，请勿私自拆卸耳机本体及配件，否则不予保修。</div> <div>5. 检查箱充电，请选择标配的充电充电器本公司指定的符合要求要求的充电器。</div> <div>6. 为保证您正常使用音箱，请确保音箱的电量充足。并使用5V1A电源适配器给本产品充电。</div> <div>07</div>
---	---	---	---	--	--	---	--

<div></div> <div>User Manual</div>	<div>Accessories</div> <div>Please read this manual carefully before using.</div> <div></div> <div>01</div>	<div>Product Details</div> <div></div> <div>02</div>	<div>Product Usage</div> <div></div> <div>03</div>	<div>Radio mode: (Plug in a 3.5mm audio cable as an antenna) When the speaker power on, short press  to turn on the radio mode. Short press +/- to switch radio station, short press  to search for radio stations.</div> <div></div> <div>TF Card Play Mode: Insert TF card to start playing TF content auto matically.</div> <div></div> <div>04</div>	<div>Connecting to Other Devices</div> <div>Insert double ended audio cable into the AUX port and universal 3.5mm interface to connect speaker to your mobile devices. (Under this mode, the speaker cannot switch between last song and next song)</div> <div></div> <div>Charging:</div> <div>Use a USB cable to charge speaker under either "Power on" or "Power off" mode. Red light stays on when charging, and it goes out when full charged. (A beep will remind you to charge on time when the speaker in low power.)</div> <div></div> <div>05</div>	<div>Product Specification:</div> <div><ul style="list-style-type: none">● Operating Voltage: 3.7 V● Charging voltage: USB 5V● Loudspeaker: 52mm 4Ω 3W● SNR: 80db● Battery capacity: 400mAh● Frequency response: 20-20K Hz● Product size: 83mm*80mm*34mm● Transmission distance: 10m-15m</div> <div>Reset function: If the buttons of the speaker out of work, press the reset hole by a small needle-like object and then it will work after you reboot the speaker.</div> <div>Safety Information</div> <div>Before using and operating the speaker, please read and follow the below precautions to ensure the best performance of it and to avoid dangerous or illegal situations.</div> <div>Hearing Loss</div> <div>● Listening to sound at high volume may permanently damage your hearing. When you use speakers to listen to music or calls, it is recommended to use the minimum volume required for music or calls to avoid hurting your hearing.</div> <div>● Exposure to high-level volume while driving, driving attention may be distracted and cause accidents.</div> <div>Operating environment</div> <div>● Do not use the device in dusty, sharp, compact or near magnetic fields to avoid failure of the internal circuit of the device.</div> <div>● When installing the device, please keep away from strong magnetic fields or electrical appliances with strong magnetic fields, such as ovens and refrigerators.</div> <div>● Do not use the device in thunderstorm weather. Thunderstorm weather may cause equipment failure or electric shock hazard.</div> <div>● Please use the device within a temperature range of -10 °C ~ +55 °C, and store the device and its accessories within a temperature range of -40C ~ +70 °C. When the ambient temperature is too high or too low, it may cause device function failure. When the temperature is below 5 °C, the performance of the battery is limited.</div> <div>06</div>	<div>● Do not place the device in direct sunlight, such as the dashboard or window sill of a car.</div> <div>● Do not place the device near heating sources or exposed fire sources, such as electric heaters, ovens, water heaters, stoves, candles, or other places that may generate high temperatures.</div> <div>● Do not place sharp metal objects such as pins near the device's earpiece or speaker, otherwise the metal objects may adhere and cause injury to you.</div> <div>Charger safety</div> <div>● When charging the device, the power socket should be installed near the device and should be easily accessible.</div> <div>● When charging is completed or not charging, disconnect the charger from the device and unplug the charger from the power outlet.</div> <div>Battery safety</div> <div>● Do not disassemble or modify the battery, or immerse in water or other liquids, to avoid battery leakage, excessive, fire or explosion.</div> <div>● Do not drop, crush or puncture the battery. It can cause internal short circuits and overheating.</div> <div>● This device is equipped with a non-removable built-in battery.</div> <div>● Do not replace the battery yourself to avoid damage to the battery or device. The battery can only be replaced by Huawei Customer Service Center.</div> <div>Precautions</div> <div>1. The speakers should be stored in a dry/ventilated environment and avoid contacting with oil, water vapor, steam, moisture and dust to prevent the performance of the product.</div> <div>2. Avoid using harsh organic solvents or items containing these ingredients to clean the earphones.</div> <div>3. The speaker should be used correctly according to the requirements, and pay attention to the effect of the environment on the product. Make sure the connection is smooth and recommend a distance between them within 10 meters.</div> <div>4. If the speaker failed to connect or with poorly connection, please do not dismantle it or the accessories privately. Otherwise no warranty.</div> <div>5. When charging the speaker, please use the standard car charger or the charger specified by our company.</div> <div>6. To ensure the normal use of the speaker, please make sure it is fully charged.</div> <div>07</div>
--	---	---	--	---	--	---	---

深圳恩乐实业有限公司产品说明书			
物料名称	A60彩色音箱说明书	物料号码	
工 艺	彩色印刷，风琴折页	日 期	2022-02-16
材 质	材质：105g铜版纸（双铜）	设 计	
规 格	491mm*80mm	确 认	

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.