

1 Installing (initial setup)

Use the [room camera]

Step 1

Connect to a [room camera]



Step 3


Plug in an InstaShow Button



*Your PC will automatically switch the Wi-Fi connection to the VS20 receiver

Step 2

Connect to a corporate network



Step 4

Run the InstaShow VS Assist App



*Click the InstaShow Camera Preview to check if the [room camera] is being used

1 Installing (initial setup)

Use the [room camera]


Step 1

Connect to a [room camera]




Step 3

Run the InstaShow VS Assist App




Step 2

Connect to a corporate network



Step 4

Select the VS20 Host Receiver



*All devices must be connected to the same LAN

2 Installing

Use the [room camera] in a [VC meeting]


Step 1

Open your [VC APP]



Step 2

Set the camera to InstaShow Camera



You are now using the [room camera]

3 Installing Audio Setting in [VC APP]

There are 2 options to set up your microphone :

InstaShow button microphone :

App Free


A standalone mic to replace
the computer's built-in mic.

InstaShow Audio :



App Required


The mic system that turn on
all the microphones



4 Installing InstaShow VS Assist App

InstaShow Camera Preview

Click the button to check if the correct camera is being used




Click !

Local Screen



InstaShow Display Sharing

Click the button to capture what the presenter is casting on the local screen



Your Device

Presenter


5 Installing

Present via your Button

You are logged in to [VC APP]


Step 1

Use Win + P keyboard shortcut to extend your screen to external displays and projectors




Step 2

Click "InstaShow Display Sharing" in VS Assist App



Step 3

Share InstaShow Display in [VC APP] for remote attendees



You are not logged in to [VC APP]



Press the InstaShow Button to cast your screen

