

Sound Bars

Model: LK-S819-4 / LK-S707-6 / LK-S810-9

VEVOR
Support Center













Sound Bars

MODEL:



LK-S819-4



LK-S707-6



LK-S810-9

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.



Warning-To reduce the risk of injury, user must read instructions manual carefully.

\triangle

WARNING:

To reduce the risk of electric shock, do not dismantle the product and do not expose the product to rain or moisture.

No user- serviceable parts inside. Refer servicing to qualified personnel only.

- 1. Do not let water splash onto the surface of this product or enter the interior of the product.
- 2. This product is not suitable for people (including children) with decreased physical, sensory,or mental abilities or lack of experience and knowledge, unless they are supervised or guided by personnel responsible for their safety.
- 3. Children should be monitored to ensure that they do not play with the device.
- 4. If the surface of this product is damaged or there are mechanical or electrical faults, do not use the device.
- 5. Do not put this product into water.
- 6. Do not directly heat this product, it should be placed in a dry and ventilated place.
- 7. Do not place heavy objects on this product.

Remote Control Description

Using the remote control:

01. POWER

Press this button to power on or power off.

02. MODE


Press this button to switch the mode within Bluetooth, USB, Aux-in, HD-in(ARC-in).

03. VOL+

Press VOL+ to up the volume of the sound bar

04.

Under Bluetooth and USB mode, press this button will go to previous song.



05. MOVIE

Press this button will enter MOVIE mode sound effect.

06. PAIR


Under Bluetooth mode, press this button will disconnect the connection between sound bar and sound sourcing device (such as your mobile phone), press this button will reconnect the previous sourcing device again.

07. RESET

Press this button will resume the factory sound setting.

08. MUTE

Under work mode, press this button to turn off sound of sound bar, press it again to turn on the sound.



09. 淵

when playing music, press this button to pause playing, and repress to play continue

10. ▶

Under Bluetooth and USB mode, press this button will go to next song.

11. VOL-

press VOL-to down it.

12. MUSIC

Press this button will enter NUSIC mode sound effect.

13. NEWS

Press this button will enter NEWS mode sound effect.

14. 🗬

USB file loop.

Ultimate Advantage

1. Use the latest decoding chip, Bluetooth 5.0+, supporting fast connection.

- 2. Mobile design, ushering in a new era of Bluetooth speakers with excellent sound quality that stands out from the crowd.
- 3. Can be matched with personal computers MP3. And audio devices such as mobile phones equipped with a 3.5mm stereo audio input interface.
- 4. It can automatically remember the song number after shutting down.

Product features

- ·Wide frequency range
- ·Balanced sound field calibration
- Unit material upgrade
- ·Stable signal transmission
- ·High resolution sound quality
- ·Long term stable use
- ·Optimization of heat dissipation structure
- **Quick Connect**
- ·Low distortion performance
- ·Suitable for adapters
- Rich and complete functions
- ·High efficiency drive

Important safeguards

For Soundbars that are suitable for power supply, they are more inclined towards indoor activities such as home use, film and entertainment. Please connect the power adapter before indoor use to ensure that the machine can play and use normally indoors.

Soundbar Panels

O/M

Press this button to power on or power off.

2. 🌉

when playing music, press this button to pause playing, and repress to play continue.

3 ₩/-


Short press - previous song Long press - for volume down.

4 ₩/+


Short press + for next song Long press + for volume up.

5. USB Port

Plug in supported flash drive to play is USB mode.



(LK-S810-9)



Storage Device Music Playback Guide

TF card: Ensure that the metal contacts are facing downwards,gently push to the bottom of the card slot until the buckle is fixed USB flash drive: directly inserted into the USB interface

Supporting file systems: FAT32/exFAT (some older models only support FAT32).

Operating Instructions

You've successfully powered on when the power adapter is connected to the Speaker and the display glows with a prompt voice.

You can choose the required mode by short pressing the Power/Mode button on the side panel or the Mode button on the remote control.

Bluetooth Mode:

- 1.Press the 'MODE' button repeatedly till Bluetooth Mode is selected and Sound bars hows "BT" on its LED screen.
- 2.On Bluetooth enabled devices, select the Bluetooth model of the device. The display screen will flash, indicating that it is waking up.

After successful pairing, the indicator light will continue to light up, the display screen will show "BT" and stop flashing.

3. Now you can play music from your Bluetooth-enabled device on the sound bar.

Press | or | button on the remote control to play previous or next song.

AUX Input:

If using the AUX cable, connect the speaker to audio source and select 'AUX' by using the Mode key on the remote control or the Power/Mode key on the side panel. 'AUX' will be displayed on the display accompanied by 'AUX' prompt.

HD/ARC Input


If using an HD/ARC cable to connect the speaker, select 'HD' through the mode button on the remote control or the

Power/Mode key on the side panel. The screen will display 'ARC' accompanied by 'ARC' prompt.

USB Input:

Plug in supported flash drive to play is USB mode.

Connection schematic



Solutions to common problems

Trouble	Causes and Solutions
Bluetooth pairing	Cause 1: The speaker is not in Bluetooth mode.
failed	Cause 2: The speaker Bluetooth is automatically
	connected to other devices.
	Solution: Press the "M" key to select Bluetooth mode.
	If other devices automatically connect, long press "
	" to disconnect the Bluetooth connection, then turn on
	the phone's Bluetooth and reconnect.
Speaker sound is	Cause 1:The volume of the speaker is too low.
too small	Cause 2: The volume of the phone is too low.
	Solution: Please increase the speaker and phone
	volume.
Music playing	Cause 1: The Effective distance between the speaker
staccato	and the mobile phone may be more than 10 meters.
	Cause 2: There are obstacles between the speaker
	and the mobile phone
	Solution: If it is the above reasons, please shorten the
	effective distance between the speaker and the
	mobile phone. If not, please reconnect to Bluetooth.
Speaker doesn't work	Cause 1: The speaker may have run out of power.
	Cause 2: Bluetooth is not connected.
	Cause 3: The volume of the speaker may not be
	turned on ,or the volume of the mobile phone may not
	be turned on.
	Solution: Please turn on the speaker again after fully
	charged, reconnect Bluetooth, increase the volume of
	the speaker and the phone.

FCC Information:

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This product may cause harmful interference.
- 2)This product must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this product not expressly approved by the party.responsible for compliance could void the user's authority to operate the product.



Note: This product has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This product generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- · Reorient or relocate the receiving antenna.
- · Increase the distance between the product and receiver.
- · Connect the product to an outlet on a circuit different from that to which the receiver is connected.
- \cdot Consult the dealer or an experienced radio/TV technician for assistance.



This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheelie bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

GUANGDONG WANSHENG SCIENCE AND TECHNOLOGY CO.,LTD.

Address: BLOCK D NO.1 ECOLOGICAL INDUSTRIAL ZONE NEW DISTRICT FENGSHUN MEIZHOU CITY GUANGDONG PROVINCE CHINA Imported to AUS: SIHAO PTY LTD. 1 ROKEVA STREETEASTWOOD NSW

2122 Australia

Imported to USA: Sanven Technology Ltd. Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

EC REP

E-CrossStu GmbH

Mainzer Landstr.69, 60329 Frankfurt am Main.

UK REP

YH CONSULTING LIMITED.

C/O YH Consulting Limited Office 147, Centurion House, London Road, Staines-upon-Thames, Surrey, TW18 4AX

