

UK ENGLISH

●FEATURE

- | | |
|-------------------|------------------|
| 1 Cutting head | 6 guide comb |
| 2 body | 7 nose trimmer |
| 3 switch | 8 charger |
| 4 indicator light | 9 cleaning brush |
| 5 Shaver | |

●HOW TO CHANGE THE HEAD

1. One hand hold the machine, another hand pull out the head like the photo (10)
2. other heads same operation.

●HOW TO USE

SHAVER

1. Switch hands stretched upward nudge skin let the shaver at right angles to the skin in contact against the direction of beard slowly moves back and forth
2. Open the switch push up the sideburns knife the sideburns knife will be working.

HAIR CLIPPER

1. Flick the switch up let the knife forward to a certain angle moving close to the hair.
2. Adjust the guide comb up and down you can control the cutting length

NOSE TRIMMER

- Flick the switch up

●HOW TO CLEAN

1. SHAVER CLEAN



As shown press and hold both ends of the index finger and thumb as AB direction arrow can dial up Unplug the net and then use the brush to clean the residue board, whereas 2 down arrow to install the plug.

2. HAIR CLIPPER CLEAN

- 1) Figure A head pressing force along the direction of the arrow to remove the central head, you can clean it.

- 2) Figure B press 1 to insert a plastic tank the second alignment metal parts according to the pressure head center can be installed along the direction of the arrow tip.

- 3) Figure C press the comb along the direction of the arrow.

●HOW TO CHARGE

1. Be sure to use the original factory charging cable and at temperatures between 5-35°C you can not turn wet hands plug the power cord AC220-240V charging.
2. Before charging should ensure that the switch is closed do not charge in the sunlight.
3. The indicator will show when charging.
4. standard charging time is 8-12 hours.

●IMPORTANCE

1. this product can not be washed and should be placed in a dry, well ventilated place.
2. this product is for adults and should be away from children.



Kemei®

Model: KM-1506

3D



MAKE LIFE BETTER