




SMART BUTTON PLATE

SMART BUTTON SOLD SEPARATELY

RETROTOUCH.CO.UK/BUTTON-PLATE



Stick anywhere



Clean & dry the surface you wish to stick the switch too. Use the 3M sticky pads and locate on the back of the switch. Peel and Stick. Apply pressure for 10 seconds to get a firm fix.