




*Please read carefully and keep it properly before using the product.



*Based on data from the One-think Technology Lab, actual battery life depends on usage.

*The Google Play logo is a registered trademark of Google Inc.

4. Screw in the screws and assemble the entire cube.

3. For more questions, please visit one-think.com for technical support or contact us at service@one-think.com.

- 1) The product uses two 3V CR1632 non-rechargeable coin batteries;
- 2) The battery should be removed and installed correctly according to the polarity and voltage marks on the toy battery compartment, and the battery should not be short-circuited;
- 3) Non-rechargeable batteries cannot be charged;
- 4) Different types of batteries or old and new batteries cannot be mixed;
- 5) Only batteries that are the same or equivalent to the recommended battery can be used;
- 6) The exhausted battery should be removed from the toy. If it is not used for a long time, please remove the battery from the device;
- 7) The power terminal shall not be short-circuited;
- 8) It cannot be connected to more than the recommended number of power supplies.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

⚠ WARNING: This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any of the body, seek immediate medical attention.