


ZEGRAD RGB GAMING DESK

ADJUSTABLE RGB LIGHT BAR DESK



QUICK START GUIDE



Components

Please check you have all the pieces listed below



M4x14
Kx36



M8x16
Lx8




M8
Mx2




Nx4




6mm
Ox1



Ax2




C1x1




C2x1



Bx2




Dx1



Ex1



Fx1




Gx1



H1



H2



Ix2




J1




J2

Installation Guide

01




02




Installation Guide

03



04




Nx4




Kx6

Installation Guide

05




06




Installation Guide




07



08



Installation Guide



RGB LIGHT BAR INSTRUCTION

Power on/off: press (09) until all three modes have been switched on.

Switching mode: press (09)

Mode 1: Acoustic sensing mode.

Mode 2: Button (10) control mode.

Switching color: press (10)

NiTHO®

www.nitho.com

SERVICE & SUPPORT

If you have any questions or require support,
contact NITHO Team at support@nitho.com
or visit our website www.nitho.com

NiTHO GmbH - Victoriastrasse 3b - 86150 Augsburg - Germany



SUPPORT@NITHO.COM



WWW.NITHO.COM



[NITHOGAMES](#)



[NITHOGAMES](#)