

Skykey/Magickey Coding Instructions

1. Locate learn button on the receiver which will be attached to the motor.
2. Press and immediately release the learn button once and the led will illuminate.
3. Press and hold a button on the new remote for 2 seconds then release, this will cause the led on the receiver to either flash or go out.
4. Press and hold a button on the new remote for 2 seconds then release, this will cause the led on the receiver to either flash or go out.
5. After the receiver light has gone out. Test the remote.

www.remotepro.com.au

WARNING

To prevent possible SERIOUS INJURY or DEATH:

- Battery is hazardous: NEVER allow children near batteries.
- If battery is swallowed, immediately notify a doctor.

To reduce risk of fire, explosion or chemical burn:

- Replace ONLY with the same size and type battery
 - DO NOT recharge, disassemble, heat above 100° C or incinerate
- Battery will cause SEVERE or FATAL injuries in 2 hours or less if swallowed or placed inside any part of the body.

