



INSTALLATION & MAINTENANCE MANUAL

SN3P / SN4P

GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.


**These instructions should be used to aid installation of the following products:
SN3P / SN4P**

SAFETY


- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician
- Please isolate mains prior to installation or maintenance
- Please note the IP (Ingress Protection) rating of this product when deciding the location for installation
- Do not overload this accessory or subject it to conditions outside its rating
- This product is for indoor use only
- This product is IP20 rated

INSTALLATION

- Provide power to the required point of installation
- Squeezing the tab on the top of the connector to pull the two halves apart (see Fig. 1)



- Squeeze the sides of each half together to remove the cover (see Fig. 2)



- Ensuring correct polarity is observed, carefully wire the supply side of the connector as shown in Fig. 3



Fig. 3

- Connect the load side ensuring the correct polarity is observed (see Fig. 4)




Fig. 4

- Check all electrical connections are secure with all exposed copper within the terminal and no loose strands of cable
- Refit the covers ensuring that the cables are secured by the cord grip
- Push the two halves together until the tab clicks into place
- Switch on and check for correct operation

GENERAL

Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product.

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

WARRANTY

This product has a warranty of 1 year from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.

SUPPLIED BY:
(UK) MANUFACTURER ML ACCESSORIES LTD,
UNIT E CHILTERN PARK, BOSCOMBE ROAD,
DUNSTABLE LU5 4LT,
WWW.MLACCESSORIES.CO.UK

(EU) SLV LIGHTING GROUP,
DAIMLERSTRASSE 21-23,
52531 ÜBACH-PALENBERG, GERMANY
EMAIL: EPREL@GROUP.SLV.COM

MADE IN CHINA



ML
ACCESSORIES LTD



UK
CA

