



APP



Download the soundcore app to experience Adaptive Noise Cancelling, Find Earbuds, dual connections, firmware updates, and more exciting features. If your earbuds cannot connect with the soundcore app, re-install the app or update it to the latest version in your mobile app store. Click this link to download: <http://dl-soundcore.soundcore.com/qcdl?flow=soundcore>

WEARING




Choose the ear tips that fit your ears best and take a fit test in the soundcore app to ensure you get the best ANC performance. After wearing the earbuds, rotate until they lock into a position you find comfortable.

Note: Medium ear tips come attached to the earbuds.


* Dust, earwax, or other debris can accumulate in the earbuds. To maintain optimal sound quality, regularly clean your earbuds by using a cotton swab slightly moistened with rubbing alcohol to gently wipe the metal mesh filter under the rubber ear tips.

POWERING ON AND PAIRING




1. Peel off the protective films on the earbuds.
2. Return the earbuds to the charging case, then close the case. Pull to reopen the charging case.
3. Take out the earbuds. The earbuds will automatically power on and enter pairing mode. Select "soundcore A30i" from your device's Bluetooth list.

PAIRING WITH A NEW DEVICE




To pair with a new device, press and hold the touch areas of both earbuds simultaneously for 3 seconds to enter pairing mode.

CHARGING




- 1. Place the earbuds in the charging case and close it.
 - Fully dry off the earbuds and the USB-C charging port before charging.
 - 2. Connect the charging case to a power supply by using the provided USB-C charging cable.
- * A full battery recharge takes about 2 hours, and 10 minutes of charging offers 2 hours of playtime.

DUAL CONNECTIONS



To connect the earbuds with two Bluetooth devices at the same time, first open the soundcore app, go to settings, and select **Dual Connections > Enable Dual Connections > Connect New Device**.

CONTROLS



×2: Tap twice 2s: Tap and hold for 2 seconds
*You can also customize controls in the soundcore app.


		TWS mode	Mono mode
	Switch ambient sound modes (ANC / Transparency)	Tap and hold for 2 seconds (L/R)	Tap and hold for 2 seconds
	Play / Pause	Tap twice (R)	Tap twice
	Next track	Tap twice (L)	/
	Answer a call	Tap twice (L/R)	Tap twice
	Reject / end a call	Tap and hold for 2 seconds (L/R)	Tap and hold for 2 seconds

POWERING OFF




To power off, return the earbuds to the charging case.

RESET



Pull to open the charging case. Take out the earbuds, then press and hold the touch control areas of both earbuds simultaneously for 10 seconds to reset.

FIRMWARE UPDATE



You will be informed once a new firmware version is detected when you connect the earbuds to the app. Ensure the earbuds are outside the charging case until the firmware update is complete. During the update, avoid any usage.

SPECS

Specifications are subject to change without notice.

Input	5V ... 0.46A
Output	5V ... 0.2A (0.1A per port)
Battery capacity	310mAh/1.147Wh
Playtime (with ANC off)	7 hours / 24 hours
Playtime (with ANC on)	5 hours / 18 hours
Charging time	Full Charging Time for Earbuds: 1 hour Full Charging Time for Charging Case: 2 hours
Driver unit	6mm
Frequency response	20-20KHz
Impedance	16Ω
Bluetooth version	Bluetooth 5.4
Bluetooth range	10m

Customer Service



service@soundcore.com
support.mea@soundcore.com (For Middle East and Africa Only)
support@anker.com (日本)
+1 (800) 988 7973 (US/Canada)
+44 (0) 1604 936200 (UK)
+49 (0) 69 9579 7960 (DE)
03 4455 7823 (日本)
+86 400 0550 036 (中国)
+82 02-1661-9246 (한국)
+971 529750842 (Middle East & Africa)
+971 8000320817 (UAE)
+966 8008500030 (KSA)
+965 22069086 (Kuwait)
+20 8000000826 (Egypt)
+61 3 8331 4800 (Australia)
+90 (850) 460 14 14 (Türkiye)
+8 (800) 511-86-23 (Russia)
+91 18003138831 (India)



Note: The 'x' of SN Code: xxxxxxxxxxxxxx is a variable, see below table.

Variable 'x'	Range of variable	Content
Eighth	8,9,A,B,C...	Denotes the year, 8 means 2018, 9 means 2019, A means 2020, B means 2021, C means 2022, and so on.
Ninth and tenth	01,02,03...	Denotes weeks, 01 means the first week in this year, 02 means the secondary week in this year, and so on.
Eleventh	1-7	Denotes date, 1 means Monday, 2 means Tuesday..., 7 means Sunday and so on.
The last five	00001-99999	Denotes serial No.

Hereby, Anker Innovations Limited declares that this device is in compliance with The Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023.For the Statement of Compliance, visit the website: <https://uk.soundcore.com/pages/psti-related>.

