

WINGS PHANTOM 500

GODLIKE LIMITED EDITION

USER MANUAL



INTRODUCTION

Welcome to the Wings True Wireless Generation with the all new "Wings Phantom 500". We hope you are as excited as us to feel and flaunt your latest soundwear. But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. Once you are done reading the manual, we are sure you will be all set to

BE THE SICKEST IN THE GAME !

It's not just a tagline , it's **who we are** . Esports and Gaming has truly arrived in India and at Wings, we celebrate the modern Indian gamer with products that reflect the same drive and finesse that goes into the sport.

We are a community of passionate of gaming enthusiasts with the highest standards and the ambition to be the best. It is the same passion with which we add style and performance to every Wings product so you can elevate your game and enjoy the rush of that perfect headshot.

But more than anything - **We are PROUD to be gamers. Just like you.**

Let's Go!

WHAT'S IN THE BOX



PRODUCT LAYOUT




1. Charging Case
2. Type-C Input
3. Earbuds Touch Control
4. Microphone

HOW TO PAIR



Step 1: Make sure your charging case is charged up. Simply open the lid of the charging case and take out the earbuds. The earbuds will turn ON and will automatically enter the pairing mode.



Note: In case you do not connect to any device within 5 minutes of entering pairing mode, then both earbuds will be automatically power OFF. Please put the earbuds back into the case and repeat the process to pair

TOUCH CONTROL USAGE

Play/Pause **Double Tap** the sensor on any one earbud to pause music. **Double Tap** on any sensor again on any one earbud to resume playing music.

Changing Songs
Triple Tap on right earbud to go to next song.
Triple Tap on left earbud to go to previous song.

Adjusting Volume
Single Tap on right earbud to increase volume.
Single Tap on left earbud to decrease volume.

Siri/Google Assistant
Long press for 2 seconds on left earbud to activate voice assistant.

Gaming Mode: **Long press** for 2 seconds the right earbud to turn gaming mode ON, The earbuds will do breathing light effect. **Long press** for 2 sec the right earbud again to turn gaming mode OFF.

CALL CONTROLS

Answer Incoming Call: **Double Tap** the sensor on any earbud to answer incoming call.

Hang up Ongoing call: While on call, **Double Tap** the sensor on any earbud to hang up the call.

Reject Incoming Call: **Long press** on any earbud for 2 seconds to reject incoming call.

3rd Party Call: While ongoing call , if user receive a new incoming call, single tap on any earbud to put the ongoing call on hold and accept the new incoming call .

CHARGING THE CASE



Note: Please only use a 5V/1A adapter to charge the case as higher voltage adapters can destroy the battery of the case and earbuds.

Low Battery Indicator: When the charging case battery is low, the case light will start flashing quickly .

During Charging: The Flash light on the charging case will begin to flash, this indicates that the case is charging

Fully Charged: When the case is fully charged , the LED light will steady on.

CHARGING THE EARBUDS

Earbuds Low Battery: When the charging on earbuds is low, you will hear a low battery voice prompt and the flash light on the earbuds will flash after every 5 seconds




Earbuds charging: Place the earbuds inside the charging case to charge them, the flash light on earbuds will turn on , indicating that the earbuds are charging.

Earbuds completely charged: When the earbuds are completely charged , the flash light on the earbuds will turn OFF

RESETTING THE DEVICE

Please follow the below steps when you see 2 "Wings Phantom 500" in your Bluetooth device menu on your mobile or you can hear music through only 1 earbud. This means the left and right earbuds have not auto paired with each other:



Step 1: Disconnect the earbuds and remove "Wings Phantom 500" from the list of paired devices on your mobile.

Step 2: Tap the sensor on either of the earbuds for 5 times to clear the pairing data , light goes off



Step 3: Put them back into charging case and take out from the charging case, "Wings Phantom 500" is ready to use on auto ON & auto pairing.

Reset process is now complete and you will be able to hear music through both earbuds.

TECHNICAL SPECIFICATIONS

PARAMETERS	VALUES
Bluetooth Version:	V5.1
Effective Distance:	10m
Impedance:	32Ω
Product Weight:	49g
Speaker Size:	10mm
Total Play Time:	About 30+ Hours
Play Time In Single Charge:	About 8 Hours
Talk Time:	About 25 Hours
Standby Time:	About 250 Hours
Case Charging Time:	1.5 Hours
Earbuds Charging Time:	1 Hour
Rated Input:	5V/1A
Frequency:	20Hz~20KHz
Water and Sweat Resistant:	IPX5

*T&C Apply

SAFETY AND MAINTAINANCE

Please read below suggestions in order to helping prolong the product lifespan and clearly understand the warranty clauses:

- Keep the product dry, do not put it in humid conditions to avoid short circuit.
- Do not expose it to the peak sun or high heat for extended period of time as this will short lifespan of electronic components, damage battery and deform some plastic parts.
- Do not put it in cold circumstance to avoid damage to PCB board.
- Do not attempt to dismantle the product, as it maybe unsafe especially for non-professionals.
- Do not use chemical products, detergent, oily liquids to clean the item.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not charge the case for more than 5 hours to avoid loss in battery life.
- Avoid hearing music at maximum volume for long periods of time as this can affect your hearing and is not advisable.

Note: Any damage to the product that is not manufacturing defect will lead to warranty being rendered null and void. Therefore, please take utmost care of your product.