



BOOMCARD

Quick guide

Open or download the free Apple Find My app from the App Store.



Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.


Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

GB

How to use

open or download the free Apple Find My app from the App Store.

switch on:
press for 5 seconds.
open Apple Find My App.
tap: Items "+"
tap: Add Other Item ⓘ .
BOOMCARD will now show
tap: Connect.




to disconnect :
press 5 times quickly.
to factory reset :
first remove from Find My App,
press 2 times, then immediately press and hold for 8 seconds.



charging:

Place on wireless charging point with the logo facing down, as shown below.




LED

charging

NO LED

fully charged

NOT THIS WAY



battery capacity: 3.7V 120mah.
charge time: 1.5 hours.
waterproof: IPX7.
built in buzzer: 94 db sound.
working time: depending on buzzer usage 5-6 months per charge.

Please read instructions before use, and keep for future reference.

WARNING:
Do not ingest battery. Chemical burn hazard. lithium battery inside. Swallowing can cause severe internal burns in 2 hours, even death. Keep batteries away from children. If battery compartment doesn't close securely, stop using product. Keep away from children. If swallowed or inserted, seek immediate medical attention. Product not a toy or edible. Mobile device casings can weaken signal and reduce visibility. Avoid large metal objects near device and Boomtag. Interference with Bluetooth signal.
Caution: Lithium battery inside. Risk of explosion with incorrect use. Avoid direct heat and mechanical stress. Do not disassemble BOOMCARD. Risk of electric shock and voiding warranty.

Warranty- UK. & Europe
Your BOOMPODS product is guaranteed against any defects in material or workmanship for 2 years from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage.

Warranty- US & Canada
Your BOOMPODS product is guaranteed against any defects in material or workmanship for 1 years from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage.

The device must be used in accordance with the user manual. The warranty is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item.

Please check www.boompods.com for your local service centre


The Declaration of Conformity can be found at:
<https://www.boompods.com/product/BOOMCARD>
Hereby, Boompods declares that the radio equipment type [Tracker with Bluetooth] is in compliance with Directive 2014/53/EU.
FCC ID: RDR-BH20T13A

DE

Kurzanleitung:

Öffne die iOS App „Wo ist?“ oder downloade diese aus dem App Store.

Einschalten:
Für 5 Sekunden gedrückt halten
Öffne die Apple „Wo ist?“ App
Tipp: Geräte ⓘ
Tipp: Anderes Objekt hinzufügen
BOOMCARD wird nun angezeigt
Tipp: Verbinden




Ausschalten:
5 x kurz drücken
Reset: **BOOMCARD** in den Auslieferungszustand zu versetzen:
2 x kurz drücken, dann sofort für 8 Sekunden gedrückt halten



laden:

Auf die drahtlose Ladestation legen, mit dem Logo nach unten, wie unten gezeigt.




LED

laden

NO LED

vollständig geladen

NICHT SO.



Batteriekapazität: 3,7V 120mAh.
Ladezeit: 1,5 Stunden.
Wasserdicht: IPX7.
Eingebauter Summer: 94 dB Lautstärke.
Arbeitszeit: je nach Summernutzung 5-6 Monate pro Ladung..

Bitte lesen Sie die Anleitung vor der Verwendung und bewahren Sie sie zur späteren Referenz auf.

WARNUNG:
Batterie nicht verschlucken. Gefahr von chemischen Verbrennungen. Lithiumbatterie im Inneren. Verschlucken kann innerhalb von 2 Stunden schwere innere Verbrennungen verursachen, sogar tödlich. Batterien von Kindern fernhalten. Wenn das Batteriefach nicht sicher verschlossen werden kann, verwenden Sie das Produkt nicht weiter. Von Kindern fernhalten. Bei Verschlucken oder Einführen sofort medizinische Hilfe suchen. Produkt ist kein Spielzeug und nicht zum Verzehr geeignet. Handyhüllen können das Signal schwächen und die Sichtbarkeit verringern. Große Metallgegenstände in der Nähe des Geräts und des Boomtags vermeiden. Störungen des Bluetooth-Signals möglich.

Vorsicht: Lithiumbatterie im Inneren. Explosionsgefahr bei unsachgemäßer Verwendung. Direkte Hitze und mechanische Belastung vermeiden. Den BOOMCARD nicht zerlegen. Gefahr eines elektrischen Schlags und Verlust der Garantie.

Garantie - Vereinigtes Königreich & Europa.
Ihr BOOMPODS-Produkt ist für 2 Jahre ab dem Datum des ursprünglichen Kaufs gegen Material- oder Verarbeitungsfehler garantiert, sofern es nicht auseinandergenommen wurde und keine versehentlichen Schäden aufweist.

Das Gerät muss gemäß der Bedienungsanleitung verwendet werden. Die Garantie gilt nur bei Vorlage der Originalrechnung oder des Kassenbelegs vom Händler und gilt nicht für normalen Verschleiß oder Geräte, die falsch verwendet oder manipuliert wurden. Es sollte an das örtliche Servicezentrum zurückgesandt werden. Das Servicezentrum übernimmt keine Versandkosten für zurückgesandte Artikel.

Bitte prüfen Sie www.boompods.com für Ihr örtliches Servicezentrum.

Die Konformitätserklärung finden Sie unter:
<https://www.boompods.com/product/BOOMCARD>
Hiermit erklärt Boompods, dass das Funkgerät [Tracker mit Bluetooth] der Richtlinie 2014/53/EU entspricht.



Statment

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction.



Online manuals

www.boompods.com

BOOMPODS is a trademark of BOOMPODS LTD. BOOMPODS ©2024 All Rights.

BOOMPODS (EU), Granica, 05-806, PL.
info@boompods.com Registered No: 08147066. Made in China.

