

# User Manual

## Model:

8x21 kids binoculars

## Sport Type:

Hunting, Bird Watching, Spectator Sport,  
Camping & Hiking

**Manufacturer:** **Zinbo**

**Manufacturer recommended age:**  
3 years and up


**Please read these instructions  
before using the product.**

**Zinbo**

***Binoculars for kids***



# Product Function Introduction



# Specifications

Prism	BaK-4 & Fully multi-coated
Magnification	8 x
Twilight Index	12.96
Lens Coatings	MC
Min. Focal Length	5m- $\infty$
Relative Brightness	6.76
Exit Pupil Diameter	2.6 mm
Exit Pupil Distance	10.5 mm
Diopter Adjustment	$\pm 4$ DPT
Angular field of view	6.8°
Field of view (at 1000 m)	119 m
Field of view (at 1000 yards)	356 ft
Magnification X Object Lens	8x21

# **Quick** start with 3 steps

## **1. Adjust the collapsible binoculars for kids to fit the eye distance**

Hold the binoculars with both hands and looking at a distant object. Simply hold the binoculars in the normal viewing position and adjust the two barrels either farther apart or closer together until they reach a proper eye-to-eye distance.

## **2. Set the focus**

Cover the right objective lens with your hand and rotate the central independent focusing wheel until the image in the left eyepiece is sharp and clear.

## **3. Adjust the diopter**

Rotate the focus wheel of the right eyepiece to adjust the diopter of the right eye until the captured image is clear.

# Precautions

- 1.** Do not directly observe the sun with children's binoculars, as this will cause serious damage to the eyes or even blindness.
- 2.** Do not look at children's binoculars while walking to avoid personal injury caused by wrestling or bumping.
- 3.** Try to avoid kids binoculars falling, avoid vibration and shock, so as to avoid axis deviation and dizziness when observing.
- 4.** Do not expose the kids binoculars to sunlight for a long time to avoid damage to the rubber case.
- 5.** Do not immerse the binoculars for kids in water or other liquids.
- 6.** Please do not touch the lens with your hands, so as to prevent the lens from being contaminated with grease and fingerprints, which will affect the imaging clarity.
- 7.** Wipe off dirt with a soft, lint-free cloth. Never apply liquid directly to the binoculars for kids. If you need to use a cleaner, spray on a cloth and wipe the children's binoculars.
- 8.** When not in use for a long time, please store the kids binoculars in the included protective case or other soft case to protect the lens.
- 9.** Do not put the desiccant in the kids binoculars in a place where children can get it, so as to prevent children from swallowing the desiccant and causing harm.

# **Warranty** Service

**We Have Very Good Confidence In The Quality Of Zinbo Kids Binoculars, We Will Provide 2 Year Warranty. This Statement Is In Addition To Your Valid Rights And Is Without Prejudice To Your Statutory Rights. If You Have Any Product Problems, Please Feel Free To Contact Our Customer Service Team Through The Background, We Will Provide A Perfect Solution Within 24 Hours, And Look Forward To You Becoming Our Loyal Customers!**