

IMPORTANT
PLEASE DO NOT RETURN TO STORE
If You're Having Trouble, We're Here to Help!



Call us 24/7 at 1-855-292-4087
E-mail us at support@alteclansing.com or visit us at alteclansing.com



WELCOME 😊

Thank you for purchasing an Altec Lansing product. It's our goal to make sure you are happy. Share your happiness with our customer concierge.




JUST LISTEN.

HydraShock Everythingproof™
Wireless Speaker


IMW1500
QUICK START GUIDE

IMW1500U-230921


A Closer Look



**Powering On/
Bluetooth
Pairing**




**True Wireless
Pairing**



There are two modes:
Mode 1: Dual Stereo, both play stereo for parties etc.
Mode 2: Wide Stereo, one plays left and the other right.
Briefly press the Link button to switch between the modes.

**Light Change
Mode**



- To toggle between the different light modes:
1. Multicolor slow transition
 2. Single color pulse to music
 3. Multi color pulse to music
 4. Single color slow fade
 5. Single color
 6. Multicolor cycle changed
 7. Multicolor fast changed with background color
 8. Multicolor slow fade
 9. Four color slow fade
 10. Four color rotation with pulse to music
 11. Four color rotation
 12. Off

Press & Hold the Light Change button for 1-2 sec to change the Strobe light modes.
* off → Pulse to music → Blink → off *

REGISTER YOUR PRODUCT

To receive news, exclusive deals, OTA or firmware updates, warranty information and more please register your product at

alteclansingsupport.com



follow us
@alteclansingofficial



follow us
@alteclansing



follow us
@alteclansingofficial

12 Month Limited Warranty


All Altec Lansing products come with 12 month limited warranty from the date of its original purchase

24 Hour Customer Support


We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1-855-292-4087 or e-mail support@alteclansing.com

www.alteclansing.com


In the Box



IMW1500 HydraShock Everythingproof™
Wireless Speaker




Carry Strap



AC Adapter

Charging



Place a Qi compatible device on the wireless charging pad to charge it
* Make sure that your device is positioned correctly on your charging pad.
* Make sure that there are no other objects on the charging pad.
* Make sure to remove any phone covers before using the wireless charging.
* When using Qi charging if the volume is >50% it will be automatically reduced to 50% to conserve battery.



**Speaker Controls/
Voice Assistant/
Reset**



PRESS


- + Volume Up
- Volume Down
- Play/Pause
- Answer & End Call
- To activate Voice Assistant (Siri or Google Assistant) when connected to phone.

PRESS & HOLD (2 sec)


- ON /OFF
- Next Track
- Previous Track
- Reject Incoming Call

Reset- Press & Hold


Disconnect Bluetooth: Press and hold for five seconds and the speaker will beep.
Reset All connections: Press and hold for ten seconds and the speaker will power off. All pairing information is reset.



**Horizontal &
Vertical
Listening**



The speaker will automatically switch modes based on it's position (horizontal or vertical).



FOLLOW US ON



#myalteclansing

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Sakar International Inc.
195 Carter Drive
Edison, New Jersey 08817, USA
855-292-4087
www.alteclansing.com