



1

DESCRIPTION OF PARTS

- 1. OFF/ON
- 2. Charging port (DC 5V)
- 3. USB slot
- 4. Next track /VOL+ Previous track/VOL-
- 5. MODE button (Mode 1: BT-Connect; Mode 2: USB; Mode 3: FMMode) / Long press to connect TWS
- 6. ▶ || /SCAN:Auto scan in FM mode / Long press to connect or disconnect equipment

HOW TO CONNECT THE UNIT

Turn on the speaker unit and the Mobile or other devices, and search for the unit's model name "BT-SPEAKER" to pair the two devices.
Once paired before, it will automatically connect after the unit is turned on..

WIRELESS

Turn on the speaker and it will come into the wireless mode directly. After pairing the device, it can play the music. Press "▶ ||" button to Play/Pause. Short press "||=|/V-" or "||=|/V+" button to

2

be previous track or next track, long press "||=|/V+" or "||=|/V-" button to increase or decrease the Volume.

USB CARD

Insert the U flash memory into the USB slot, SPEAKER will read the MP3 format music automatically.Press "▶ ||" button to Play/Pause. Short press "||=|/V-" or "||=|/V+" button to be previous track or next track,long press "||=|/V-" or "||=|/V+" button to increase or decrease the Volume.

memory. The scan procedure will take several minutes and cannot be interrupted. Once completed, short press "||=|/V-" or "||=|/V+" button to be previous track or next track, long press "||=|/V+" button to increase or decrease the Volume.

TWS

Two the same model speakers can be connected to one wireless device at the same time. First, turn the speakers on, then choose

3

one unit and long press its "MODE" button for several seconds; then you will hear the sound of "Ding~" to indicate that the two units have paired successfully. Please ensure before pairing that the two units are not connected with other devices..

LED light mode:

Press the LED button to select between the Multiple lighting modes. Press and hold the LED button to off the LED light.

CHARGING

Plug the USB cable into the speaker's charging port and connect to the power source.
The red LED indicator on panel will be lit when the unit is charging..

ACCESSORIES

- Wireless speaker: 1PCS
- User manual: 1PCS
- USB cable: 1PCS

4

FCC Caution.

(1) § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2)

this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.