

CONTENTS		Product Introduction
		• Package list
English	01-12	 Model: H3-360L Outdoor Security Camera
Русский	13-24	
Español	25-36	
Portuguê	37-48	
日本語	49-60	 Power adapter
한국어	61-72	
繁體中文	73-84	
ภาษาไทย	85-96	
עברית	97-108	 Install accessories package
Français	109-120	
Italiano	121-132	
हिन्दी	133-144	
தமிழ்	145-156	 User Manual

- Ceiling mounting
 - 1. select the ceiling mounting position on the device installation location on the ceiling. Put the base plate on the ceiling in the position indicated on the diagram. (reference to the position of the device).
 - 2. select the ceiling mounting position on the ceiling. Put the base plate on the ceiling in the position indicated on the diagram. (reference to the position of the device).
- Pole mounting
 - 1. After installation, the p object must be fixed to a steel bar. (p. 116) (p. 116) in the image below.

[illegible][illegible]