

ther functions like skip track backward/gaming mode/


acial sound can be set in QCY APP.)



Overview

Charging case

QCY Crossky C30



How to Connect

2. Pick them up again.

Factory Reset

ouch nanel

ogo pins

Type-C cable


First-time connection:

push them back in case to activate.

1. Pick up both earbuds, remove the isolation films and

3. On phone search QCY Crossky C30 and tap to connect

Remove the film



Multi-Point Connection



How to Wear

Front