




YAKIMA **KayakStackers**

US


MINIMUM CROSSBAR SPREAD 30"



KAYAK STACKER (2X)




HEAVY DUTY STRAPS (2X)



CARRIAGE BOLTS (4X)

SNAP AROUNDS (4X)

HEX KEYS (4X)



BOW/STERN TIE DOWN (2X)

(Refer to bow/stern tie down instructions for correct assembly and installation.)













IMPORTANT WARNING




IT IS CRITICAL THAT ALL YAKIMA RACKS AND ACCESSORIES BE PROPERLY AND SECURELY ATTACHED TO YOUR VEHICLE. IMPROPER ATTACHMENT COULD RESULT IN AN AUTOMOBILE ACCIDENT, AND COULD CAUSE SERIOUS BODILY INJURY OR DEATH TO YOU OR TO OTHERS. YOU ARE RESPONSIBLE FOR SECURING THE RACKS AND ACCESSORIES TO YOUR CAR, CHECKING THE ATTACHMENTS PRIOR TO USE, AND PERIODICALLY INSPECTING THE PRODUCTS FOR ADJUSTMENT, WEAR, AND DAMAGE. THEREFORE, YOU MUST READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS SUPPLIED WITH YOUR YAKIMA PRODUCT PRIOR TO INSTALLATION OR USE. IF YOU DO NOT UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS, OR IF YOU HAVE NO MECHANICAL EXPERIENCE AND ARE NOT THOROUGHLY FAMILIAR WITH THE INSTALLATION PROCEDURES, YOU SHOULD HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL INSTALLER SUCH AS A QUALIFIED GARAGE OR AUTO BODY SHOP.





Part #1033394 Rev.A

DO YOU HAVE - SQUARE - ROUND - OR FACTORY CROSSBARS?

<p>1 SQUARE</p> 	<p>Loosen the tabs in the SnapArounds by bending them repeatedly.</p>  <p>Remove the tabs with scissors or pliers.</p> 
<p>1 ROUND</p> 	<p><i>(SQUARE continued)</i></p> <p>Attach two SnapArounds per bar.</p>  

<p>2</p> <p>Insert bolts through base and into SnapArounds.</p>  <p>Align SnapAround with fitted slots in the Stacker base.</p> 	<p>3</p> <ul style="list-style-type: none"> • Attach hex keys onto bolts. • Do not tighten yet.  <p>Support the KayakStacker so that car roof is protected.</p> 
--	---


<p>1 FACTORY BARS</p> 	<p>Attach two MightyMounts per bar.</p> <p><i>If your MightyMounts require bar caps, install them now.</i></p>  
--	---

<p>2</p> <p>Insert bolts through base and into MightyMounts.</p>  <p>Align MightyMounts with fitted slots in the Stacker base.</p> 	<p>3 Do not tighten yet.</p>  <p>Support the KayakStacker so that car roof is protected.</p> 
--	--

4

POSITION THE STACKERS ON THE CROSSBARS


Distance from the stacker to the tower should equal the width of your kayak (or kayaks) on edge.



5

COMPLETELY TIGHTEN THE STACKERS NOW.

- Tighten hex keys on SnapArounds.
- Tighten MightyMount bolts with wrench.




Additional straps may be required for more than 2 kayaks.

FOLLOW THESE THREE RULES WHEN STRAPPING KAYAK(S):


1

Distance of Stacker from crossbar tower is exactly the width of kayak(s) on edge.




2

Loop strap under crossbar at least once.



3

Loop strap inboard of crossbar tower.




6

LOAD THE BOAT— TIE IT DOWN WITH STRAPS


LOOP STRAP AROUND STACKER POST.

Cross lines and set aside.




LOAD BOAT.

- Bring straps up and over boat.
- Hang to the side.




- Hook the strap at the top of the stacker.
- Slide buckle up so that it hangs at top edge of boat.



ADDED SECURITY:


- Pass strap inboard under crossbar.
- Pass strap under boat around base of stacker.
- Pass under crossbar again and attach to buckle.



7


CONNECT AND TIGHTEN

- Insert end of strap into buckle as shown.
- Slide rubber cover back into place.




TIGHTEN STRAPS:

- To tighten straps, hold and pull.
- Secure extra strap.




8 Secure front and rear of boat to vehicle with bow/stern tie downs.

Refer to bow/stern tie down instructions for correct the assembly and installation.




Failure to secure front and rear of long loads to ends of vehicle can result in property damage, personal injury, or death.



9 BEFORE DRIVING AWAY

- Test movement by rocking boat.
- Tighten again if there is movement.



WEIGHT LIMITS

Follow the YAKIMA Fit List for your rack's weight limit. Do not exceed the weight limit of your vehicle's racks.

Maximum weight is 165 lbs. (75 kg) unless otherwise noted.


IF YOU REMOVE YOUR CARRIER, FOLLOW INSTRUCTIONS TO INSTALL AGAIN.

Follow safety checks in accessory instructions before every installation.

REAR HATCH

Some longer loads may prevent the rear hatch from fully opening.

ALWAYS USE CAUTION WHEN OPENING YOUR HATCH.



ANTENNA

Antenna on the roof may need to be removed to prevent interference with long loads.

WARNING: BE SURE ALL HARDWARE IS SECURED ACCORDING TO INSTRUCTIONS. ATTACHMENT HARDWARE CAN LOOSEN OVER TIME. CHECK BEFORE EACH USE, AND TIGHTEN IF NECESSARY.

MAINTENANCE: Use non-water soluble lubricant on screws. Use a soft cloth with water and mild detergent to clean plastic parts.

REMOVE ACCESSORY BEFORE ENTERING AN AUTOMATIC CAR WASH.

**TECHNICAL ASSISTANCE
OR REPLACEMENT PARTS**
Contact your dealer or call
(888)925-4621

Monday through Friday,
7:00 AM to 5:00 PM, PST



This product is covered by YAKIMA's "Love It Till You Leave It" Limited Lifetime Warranty
To obtain a copy of this warranty, go online to www.yakima.com or email us at yakwarranty@yakima.com or call (888) 925-4621

KEEP THESE INSTRUCTIONS!