



 **HYUNDAI**
GENUINE
PARTS & SERVICE

HYUNDAI SCHEDULED SERVICES				
Maintenance Items	Service			
	1	2	3	4
Replace engine oil and filter.	✓	✓	✓	✓
Inspect exterior lights.	✓	✓	✓	✓
Inspect tire pressures.	✓	✓	✓	✓
Check coolant, battery, brake and washer fluid levels.	✓	✓	✓	✓
Inspect and lubricate all latches, hinges and locks.	✓	✓	✓	✓
Inspect all drive belts.		✓	✓	✓
Inspect vacuum, crankcase ventilation hoses.		✓	✓	✓
Inspect driveshafts and boots.		✓	✓	✓
Rotate tires.		✓	✓	✓
Inspect front brake pads, rotors.		✓	✓	✓
Inspect rear brake drums/linings, parking brake (or rear discs/pads).		✓	✓	✓
Inspect brake fluid.		✓	✓	✓
Inspect suspension mounting bolts.		✓	✓	✓
Inspect steering gear box, linkage, boots and lower arm ball joint.		✓	✓	✓
Inspect engine coolant.			✓	✓
Inspect automatic transaxle fluid.			✓	✓
Inspect brake hoses and lines.			✓	✓
Inspect exhaust pipes and muffler (after manifold).			✓	✓
Inspect battery terminals.			✓	✓
Inspect fuel lines, fuel hoses and connections.				✓
Inspect vapor hose and fuel filler cap.				✓
Replace engine air cleaner filter.				✓

SCHEDULE INTERVALS		
Month	KM	Service
6	6000	1
12	12000	2
18	18000	1
24	24000	3
30	30000	1
36	36000	2
42	42000	1
48	48000	4
54	54000	1
60	60000	2
66	66000	1
72	72000	3
78	78000	1
84	84000	2
90	90000	1
96	96000	4
102	102000	1
108	108000	2
114	114000	1
120	120000	3
126	126000	1
132	132000	2
138	138000	1
144	144000	4
150	150000	1
156	156000	2
162	162000	1
168	168000	3
174	174000	1
180	180000	2
186	186000	1
192	192000	4

VEHICLE SPECIFIC MAINTENANCE ITEMS		
ITEM	INTERVAL	
Add Fuel Additive.	Every 12 mo/12000 km	
Replace Cabin Air/Pollen Filter.	Every 12 mo	
Replace Radiator Coolant.***	At 120 mo/192000 km	
Inspect valve clearances.	Every 48 mo/96000 km	
Replace Spark Plugs.	Every 84 mo/168000 km	

BRAKE SERVICES (ALL MODELS)	
Service Front and Rear Brakes.	
When combined with Service 3 and 4	
Separately	

[illegible]

- Service intervals are determined by the odometer reading or the time interval, whichever occurs first.
- Factory recommended oil change interval is based on severe driving conditions for Canadian climate. Please see your Vehicle Owner's Manual for a detailed list of normal and severe usage recommendations.
- Extra costs may be incurred for consequential parts associated with "inspection" items.

*** Initial coolant replacement at 120 mo/192000 km, then replace every 24 mo/48000 km.

- Shop supplies charge and/or environmental fees may apply