



尺寸: 105x148.5mm 折页方式: 骑马钉 100g铜版纸


C39 M0 Y90 K0











3) Put the keyboard close to the USB port of the device with a distance 3) Put the mouse close to the USB port of the device with a distance of of less than 20 centimeters


4) Insert the receiver fully into the USB ports within 20 seconds

5) And then the keyboard will be repair successfully with the USB received if you can not connect, please try to repeat the operation again.


How to Repair the Mouse with the Receiver:

1) Unplug the receiver, restart the mouse switch to "ON"





2) Press and hold the scroll wheel + right button at the same time for about 3-5 seconds to enter into pairing mode



4) Insert the receiver fully into the USB ports within 20 seconds

5) And then the mouse will be repair successfully with the USB receiver, if you can not connect, please try to repeat the operation

Buttons

Function

less than 20 centimeters

√×	Mute	₫,	Volume down		
८(١))	Volume up	И	Previous		
⊳II	Play&Stop	N	Next		
©	Browser	♡	Open setting		
-\ \ \	Decrease brightness	- <u>i</u>	Increase brightness		
*	Favorites	[[]]	Screen switching	-	
٥	Search • 1		Activates the voice service function	E	
NumLk	Number Lock	•	Open the "Connect" device interface	5	
Fn+ 📾	Press Fn + 🖻 to turn on/off the Fn function				

of inactivity

rking current ≤8mA			▶1
king range	Within 10m (33ft)		▶ 1
of the mouse	f the mouse 800-1200-1600 dpi		▶1
lifespan	3 million strokes		
teries	2 AAA batteries for the mouse (Battery not included)		FA
ep mode	ode Mouse will turn to sleep mode after 10 minutes		Kov

&Stop	⊳ı	Next		
wser	≎	Open setting	Working current	≤8mA
brightness	Ö.	Increase brightness	Working range	Within 10m (33ft)
orites	[[]]	Screen switching	Key lifespan	3 million strokes
arch	C	Activates the voice service function	Batteries	2 AAA batteries required for the keyboard (Battery not included)
er Lock		Open the "Connect" device interface	Sleep mode	Keyboard will turn to sleep mode after 5 seconds of inactivity

- ▶ 1 * Wireless Keyboard 1* Wireless Mouse
- 1* USB Receiver(Stored in the mouse's battery compartment)
- 1 * User Manual

functionality.

Keyboard & Mouse won't work properly

The keyboard and mouse are not working properly. A Heat Exposure: Avoid leaving the item in high-temperatureenvi-- Ensure that the batteries in the keyboard and mouse are not low. If ronments or in direct sunlight, which could result in a fire hazard. they are, replace them with new ones.

- Make sure that both the keyboard and mouse are turned on. Liquid Exposure: Keep the item away from water and liquids. Do - Confirm that the USB receiver is properly inserted into the computer. not use ifwet until thoroughly dried. Check if the computer recognizes the receiver. If not, try plugging the USB receiver into another USB port on the computer. If it still doesn't ▲ Damage and Leakage: Cease usage and consult customer service work, you can also test the receiver on a different device to check its if the item is damaged or the battery leaks.

▲ Correct Disposal: Follow local regulations for disposing of electron-

ic devices and batteries. Do not dispose of with household waste.

CAUTION: Non-compliance with the above warnings can lead to serious

To conserve battery life, the keyboard will enter sleep mode after 5 ▲ Radio Frequency Interference: This device may cause interference seconds of inactivity, and mouse will enter sleep mode after 10 minutes with other electronics. Keep a safe distance from sensitive devices. of inactivity. To wake them up, simply press any key on the keyboard and click the left or right button on the mouse, and they will be ready

injury or property damage.

⚠ Child Safety: Keep the item and its components out of reach of for use within 3 seconds. children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised. For any other issues while using, please do not hesitate to contact

our customer service for assistance.

How to wake up the keyboard and mouse from sleep mode

To conserve battery life, the keyboard will enter sleep mode after 5 seconds of inactivity, and the mouse will enter sleep mode after 10 minutes of inactivity. To wake them up, simply press any key on the keyboard and click the left or right button on the mouse, and they will be ready for use within 3 seconds.

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow thesesafety instructions.

E-mail:

usiness name: AMANTO INTERNATIONAL TRADE LIMITED iness address: The Imperial, 31-33 St Stephens Gardens, Notting Hill,

Managing Director

REALER CE ROHS S Z

Declared Object: 2.4G Wireless Keyboard and Mouse Combo

3V**≕**10mA

Manufacturer: Shenzhen Hangshi Electronic Technology Co., LTD

chen.zhao@bow.cn

Floor 2, Building A1, Zone G, Democratic West

Democratic Community, Shajing Street, Bao'an Shenzhen City, Guangdong Province, China, 518104

Business address: Bauernvogtkoppel, 55c, 22393, Hamburg, Germany Email: g.L.L.DE@outlook.com

It is our sole responsibility to declare that the above products are in full compliance with

Directive 2014/53/EU, 2011/65/EU (as amended)

Date of Sign:

EU agent name:

2022.1.5

Date of Sign:











