





GULLABERG



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.




NEVER open more than one drawer at a time.






DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






109048

2x



10087223

2x




10102070


2x

370172


1



26x



2x




28x



48x




8x




2x



4x




22x




4x




4x



4x




1x




6x




6x



5x




5x




2x

2




145718

32x



118331

32x




106603

8x



101345

32x




131361

64x



146114


48x








10095978

10096248


8x




1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17




18




19






20




21



22






5x





23




4x




24




25




26





2x




27




2x




28




29




30




31




32




33






34








35





36








www.IKEA.com/secure-it



www.IKEA.cn/secure-it




38

English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

A




Ø 8 mm (5/16") 


1




2



3




B




Ø 8 mm (5/16") 


1




2



3




C




Ø 3 mm (1/8") 



1




2




39




40








↓
41






42






43







↓
44




45




46




47




48



49



50



51

