

BLAUPUNKT
TRULY WIRELESS EARBUDS
BTW300 MOKSHA+



Enjoy it.

Please read this manual carefully before using

Congratulations and Willkommen! You are now part of the Blaupunkt family.
You have chosen German iconic brands premium earbuds and have become a part of an elite group that enjoys and appreciates the finest audio experience.


To get the best performance from your Blaupunkt audio product please read this manual carefully and follow the instructions. This will ensure you get the most out of your Blaupunkt product. Keep the manual safely and refer to it when in doubt.

**JUST ONE SCAN
CAN!**



One QR Code to access everything - Warranty, Blue Points, Manuals, Service and all you will ever need.

Earphone Wearing



Instructions for Use

Power on/off

Open the charging case and the earphones turn on automatically to turn off put headset back on charging case and close.

Bluetooth pairing

Open the charging case and search for Search for "BLAUPUNKT MOKSHA+". After the pairing record is established, the earplugs are put in the charging case. The charging case cover is open. The ear will reconnect automatically in 10 seconds. If the pairing fails after 5 minutes, the earphones automatically shut down.

Battery display

Earbuds $\geq 20\%$, the red light blinks three times every 30S
Charing case $\leq 20\%$, the battery indicator is on for 5 seconds and then off
Charing case $\geq 20\%$, The battery indicator is on for 5 seconds and then off


Earphone charging

Put the headphones back in the charging case
When charging, the red light is steady on
When fully charged, the red light goes off


Attention:

1. If the headset has no power for up to 6 months, it may the device cannot be used.
2. If there is sweat or liquid on the earplugs, please dry them before charging, otherwise damage may be caused.


Operation




Previous song
Triple earbud




Next track
Double tap



Music play/pause
Tap once




Gaming low latency on/off
Long press R for 5S




Double EQ switch
Four tap L/R


Operation




Voice assisant/SIRI function
Long press L for 2S



Answer call
Tap once L/R



Hang up/reject call
Double tap L/R



Factory reset
(prerequisite: device connected)
At the same time, long press both ears to touch 10S, clear the pairing record of TWS and the phone, and then power on. The earbuds flashes red for five times and then restarts.

Frequently Asked Questions

1. The charging box has power, but why can't the earbuds be charged?

A. Please confirm if the earbuds are correctly placed in the charging box, if the charging contact of the earbuds is not in full contact, it will cause the earbuds to fail to charge.

B. Wipe the charging contacts of the earbuds with a clean cotton cloth to ensure there is no foreign object interference earbuds charging.

If there is sweat or liquid on the charging contact of the charging box, the earbuds may appear corrosion, please clean it before inserting the earbuds into the charging box.

2. Place the earbuds in the charging box and close the charging box, why are the earbuds still in the connection status?

It should be that the earbuds were not properly placed in the charging box, and check point B.

3. Why does the earbuds suddenly stall when using it?

Due to the characteristics of Bluetooth earphones, electromagnetic interference in the area may cause temporary time lag, you can change the location of use.

Cautions

① Please use this product with safety guarantee.

② Please do not discard the product in the fire or the high temperature because the built-in battery will cause the explosion easily.

③ Please do not rough operation of the product such as wrestling collision, removal or modification of the earphone.

④ Please use original accessories. Accidents caused by other accessories will not be covered by the warranty.

⑤ Please charge the storage box with the charger of DC5V/1A to avoid burning the product.

⑥ Please pull out the charging line in time after charging is completed to avoid leaving the product in the state of charging for a long time.

⑦ Please stay away from large WIFI, routers or other high frequency transmitting devices, so as to avoid interference of other signals by the earphones, resulting in music stuck or disconnected.

⑧ Please use this product in an effective environment (10 meters). And there should be no physical barrier between the phone and the earphone (such as wall, etc.).

⑨ Please keep away from water.

⑩ It is recommended to use the product below 80% Volume in order to protect hearing.

Warranty

Warranty Information 1 Year

If you have issue with our product please contact our service center Authorized Service Centre Blaupunkt Speakers

Blaupunkt Authorized Service Center:

Envent World Wide Pvt Ltd.
Khasra, No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037

Email- wecare@blaupunktaudio.in

Whatsapp Chat Support: 8860 022 600

Please submit the following information while claiming product warranty:

-Serial Number

-Date of purchase

-A copy of proof of purchase in case of warranty

Note- Important Information

Please use the original packaging or other suitable packaging to protect the unit in transit.