# **DUET 50 PRO**



## USER MANUAL

## **Positioning**

Place the earphone in your ear with the logo facing out. Rotate the earbud until you find a comfortable position



## **Choose the Right Ear-Tip**

GREAT FIT = GREAT BASS









If you are having trouble putting on the tips, go to the site below for help: backbaybrand.com/eartips

#### 1-Year Warranty

Thank you for purchasing the Duet 50 Pro wireless earhuds!

You are covered by our 1-Year Warranty.

Register for your free warranty at: www.backbaybrand.com/warranty



If you have any issues please feel free to email: support@backbaybrand.com

Charging a Phone

Plug a USB-C charging cable directly into the

charging case

OR

Locate the charging adapter cable in your

accesories box. Plug it into the case, and plug your

standard USB charging cable into the open port

BACK BAY

Charging

Cable

Adapter

## Pairing for the First Time

- 1) Remove the protective plastic from the bottom of the earbuds
- 2) Place the earbuds in the charging case until you see a white light
- 3) Remove both earbuds from the charging case and they will automatically turn on and connect to each other
- 4) Go to the Bluetooth menu on your device and select "Duet 50 Pro"
- 5) If your phone shows a Bluetooth Pairing Request, press "Pair"

If the earbuds don't connect to each other. please follow the directions on the next page

### Fixing a Connection Issue

- 1) Go into your phone's bluetooth settings, find "Duet 50 Pro" and click "Forget This Device"
- 2) Place your earbuds in the charging
- 3) Press and hold the buttons on both earbuds for 5 full seconds until you see the lights on the earbuds double-flash
- 4) Remove the earbuds from the case
- 5) Turn your phone's Bluetooth off, then on again. Then you should see "Duet 50 Pro" as a discoverable device in your phone's Bluetooth menu



### Controls

Press Once

Press Twice

Press 3 Times

Hold 1 Sec

Hold 5 Sec



Left

►II

Pauca/Play

Volume Down

Voice Assistant

44

Previous Sona

ம

Power On/Off



didic

Bass Mode On/Off

 $\blacktriangleright \blacktriangleright$ 

Next Sona

Ф

Power On/Off



Phone

Controls

## **Enter Pairing Mode**

When the earbuds are not connected to any device, they will automatically go into pairing mode.

To connect to a new device for the first time, just disconnect your earbuds from your previous device and they will go into pairing mode. Then your new device will be able to discover the earbuds.

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- -Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from
- that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for

FCC ID: 2AQK8-D30

# How to Charge

#### Charging the Earbuds

- · Simply place the earbuds in the charging case
- · When the earbuds are charging, a white light will shine on the earbuds
- When the earbuds are fully charged, the light will turn off
- The case will recharge the earbuds 15 full times


#### Charging the Case

· Use the USB cable included with your earbuds to connect the USB port on the back of the charging case to a power source

Do not use a charger that exceeds 5V 1A. A higher-powered charger may damage the battery


case will shine to show the battery status when you plug in the case or place the earbuds in the case

Battery 100%-75%	4 Lights
Battery 75%-50%	3 Lights
Battery 50%-25%	2 Lights
Battery 25%-0%	1 Light



# **Charging Status**

The LED lights on the inside of the



## **Specifications**

- Bluetooth Version: 5.4
- Profiles Supported: HFP, HSP. AVRCP.
- Supports Cellphone Voice Assistants
- Wireless Range: 10m
- Battery Capacity: o Earphones: 50 mAh
- o Dock: 2600 mAh • Earphone Playtime: Up to 8 Hours
- Total Playtime with Charging Case:
- 130 Hours
- Charging Time: About 2 Hours • Frequency Range: 20 Hz - 20 kHz
- Radiation Exposure Statement: This equipment complies with the IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm

Énoncé d'exposition aux rayonnements: Cet équipement est conforme aux limites d'exposition aux rayonnements ioniques RSS-102 Pour un environnement incontrôlé. Cet équipement doit être installé et utilisé avec un Distance minimale de 20 cm entre le radiateur et votre coros.

etween the radiator and your body.





