

Annabelle Dollhouse

Assembly Instructions

Item #65079

Please retain this information for future reference

To order replacement parts, please visit www.kidkraft.com

HARDWARE

- A. Cross Dowel Bolt x 13 pcs

1 11/16 in / 43 mm
- B. Cross Dowel Nut x 13 pcs

- C. Hex Bolt x 4 pcs

1 9/16 in / 40 mm
- D. Screw x 52 pcs

13/16 in / 20 mm
- E. Cross Dowel Bolt x 2 pcs

3/8 in / 9 mm
- F. Insert Bolt x 2 pcs

1/2 in / 12 mm
- G. Screw x 6 pcs

5/16 in / 8 mm
- H. Screw x 1 pcs

13/16 in / 20 mm
- Allen Wrench x 1


The following tools (not included) are required for assembly:




Phillips® Screwdriver




Flathead Screwdriver

PARTS LIST:



FURNITURE PARTS LIST:



CAUTION: Adult Assembly Required.
Hardware contains small screws with sharp points. Keep unassembled parts out of reach of small children.

USE AND MAINTENANCE:
-Use on level surfaces only
-Please check assembly at regular intervals, and frequently tighten hardware if necessary. If maintenance is not carried out, the product could cease to function properly

WARNING: CHOKING HAZARD
Small parts and sharp points, not suitable for children under 3 years.

Customer Service
1-800-933-0771
www.kidkraft.com

Annabelle Dollhouse


Assembly Instructions

Item #65079


Please retain this information
for future reference

To order replacement parts,
please visit www.kidkraft.com

Bed Assembly



Dollhouse Assembly Step 1



Before calling customer service, please
locate the batch code number
(example: 2693/65006/04) found on the
bottom or back of your product.

Customer Service
1-800-933-0771
www.kidkraft.com

Annabelle Dollhouse


Assembly Instructions

Item #65079


Please retain this information
for future reference

To order replacement parts,
please visit www.kidkraft.com

Step 2



Step 3



Customer Service
1-800-933-0771
www.kidkraft.com

Annabelle Dollhouse


Assembly Instructions

Item #65079

Please retain this information
for future reference


To order replacement parts,
please visit www.kidkraft.com

Step 4



Wait to assemble part 10 until after elevator
is assembled to the track pieces.

Step 5



Customer Service
1-800-933-0771
www.kidkraft.com

Annabelle Dollhouse


Assembly Instructions

Item #65079


Please retain this information
for future reference

To order replacement parts,
please visit www.kidkraft.com

Step 6



Step 7



Customer Service
1-800-933-0771
www.kidkraft.com

Annabelle Dollhouse


Assembly Instructions

Item #65079


Please retain this information
for future reference

To order replacement parts,
please visit www.kidkraft.com

Step 8



Step 9



Customer Service
1-800-933-0771
www.kidkraft.com

Annabelle Dollhouse


Assembly Instructions

Item #65079


Please retain this information
for future reference

To order replacement parts,
please visit www.kidkraft.com



Step 10



*Repeat this step for
other part 24 and 25



Step 11



Customer Service
1-800-933-0771
www.kidkraft.com

Annabelle Dollhouse



Assembly Instructions

Item #65079


Please retain this information
for future reference

To order replacement parts,
please visit www.kidkraft.com


Step 12




*Assemble chandelier by
sliding the pieces together.



Step 13



*Hang chandelier on dowel



Customer Service
1-800-933-0771
www.kidkraft.com

**Parental supervision required.**

This toy is intended for children of a specific age or above. Parents should supervise the play area so that children younger than the intended age range do not interact with this toy. Use this toy on the floor. Do not allow children to climb on or around or in the toy.

IMPORTANT INFORMATION - PLEASE READ FIRST

ALL OF OUR WOODEN ITEMS ARE HANDCRAFTED, HAND ASSEMBLED, AND HAND PAINTED. EACH ONE IS UNIQUE. SLIGHT IMPERFECTIONS MAY OCCUR AND ARE NOT MANUFACTURING DEFECTS.

PLEASE NOTE THAT WE DO NOT WARRANTY AGAINST THE USE OF PERMANENT MARKERS, NON-WATER-BASED PAINTS, CRAYONS, OR WASHABLE MARKERS. SOME OF THESE ITEMS CONTAIN PERMANENT COLOR DYES THAT COULD DAMAGE THE SURFACE.

CLEANING INSTRUCTIONS

CLEAN THE SURFACE USING A SLIGHTLY DAMP CLOTH AND MILD DISH WASHING LIQUID IF NECESSARY. DO NOT USE ANY CLEANING PRODUCT CONTAINING ALCOHOL OR AMMONIA. THESE WILL DULL THE SHINY SURFACE OF THE PRODUCT. FURNITURE POLISH WILL ALSO WORK TO CLEAN AND DUST OFF THE SURFACE.

WE RECOMMEND THAT YOU TEST ALL CLEANING MATERIALS ON THE UNDERSIDE OF ANY SURFACE THAT WOULD NOT BE SEEN DURING NORMAL USE OF THE PRODUCT. IF YOU HAVE QUESTIONS REGARDING THE MAINTENANCE OF THIS PRODUCT PLEASE FEEL FREE TO CALL US.

SOLE AND LIMITED WARRANTY

THIS TOY IS WARRANTED SOLELY AGAINST MANUFACTURING DEFECTS FOR A PERIOD OF 90 DAYS FROM THE DATE OF PURCHASE, WHICH RUNS ONLY TO THE ORIGINAL USER OF THE TOY. IN THE EVENT OF A MANUFACTURING DEFECT, PARTS WILL BE REPLACED OR THE ENTIRE PRODUCT WILL BE REPLACED OR THE PURCHASE PRICE WILL BE REFUNDED, AT THE ELECTION OF THE MANUFACTURER. TO ACTIVATE AND PROTECT THIS WARRANTY, PRESERVE EVIDENCE OF ORIGINAL PURCHASE AND CAREFULLY INSPECT THE CONDITION OF THE TOY PRIOR TO AND AFTER ASSEMBLY, LOOKING FOR MISSING, DEGRADED, BROKEN OR HAZARDOUS PARTS, INCLUDING PARTS WHICH CAN BE SWALLOWED BY A CHILD, CAUSE A CHILD TO CHOKe, OR OTHERWISE CAUSE INJURY. SUCH PARTS MAY INCLUDE MAGNETS, WHEELS, HUBS, FASTENERS, AND CONNECTORS. SHOULD YOU OBSERVE ANY DEFECTS, DO NOT USE THE TOY AND IMMEDIATELY NOTIFY THE MANUFACTURER. FAILURE TO DO SO SHALL CONSTITUTE MISUSE. MISUSE, IMPROPER ASSEMBLY, FAILURE TO HONOR A WARNING, FAILURE TO SUPERVISE, INSPECT OR MAINTAIN THE TOY, OR DAMAGE TO THE TOY, WHETHER INTENTIONAL OR INADVERTENT, SHALL INVALIDATE THIS WARRANTY. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

TO SUBMIT A WARRANTY CLAIM PLEASE CONTACT KIDKRAFT CUSTOMER SERVICE AT 1-800-933-0771 FOR INSTRUCTIONS ON HOW TO PROVIDE PROOF OF PURCHASE AND HOW TO RETURN THE ITEM FREIGHT PRE-PAID.

CUSTOMER SERVICE 1-800-933-0771

www.kidkraft.com