



LENS50

INSTRUCTION MANUAL

MODEL: 15A



LIST OF ACCESSORIES

You will receive the following accessories (subject to the options available at the time of your order)



① Handheld light



② Silicone
Diffusion Dome



③ Mobile phone clip
(horizontal / vertical)




④ Type-C
charging cable



⑤ Camera bracket + Hand screw x 2 + Cold shoe mount

OPERATING INSTRUCTIONS

Product structure diagram.



❶ Type-C charging port

Charging voltage 5V2A

❷ knob

Turn the knob clockwise to adjust the brightness of the light, and the indicator light will light up according to the % ratio. When turned counterclockwise, the brightness will be dimmed, and the indicator light will display according to the % brightness ratio

❸ Indicator light

Turn on the blue light and flash the low battery red light

❹ Button

Long press to turn on/off,

Double click to enter special effects mode

Click to switch between cold/warm lighting



1: 0-100% adjustable brightness

Rotate clockwise by **1** to adjust the brightness of the light, and the indicator light will light up according to the percentage. Rotate counterclockwise to dim the brightness, and the indicator light will display according to the brightness%

2: 8 types of lighting effects

Double click **2** to enter special effects mode

3: Click to switch between cold/warm lighting

Click **3** to switch instantly

4: Detecting battery level

In the shutdown state, click **2** to check the battery level and display the current battery level% position. If none of the lights are on, please charge

 After turning on, the 4 indicator lights turn **blue**. If the **red** light flashes, please charge the device


When charging, the lights will turn on in percentage order, and the **blue light** will remain on when fully charged




Power on



Please recharge



Charging



Fully charged

FX MODE

8 different effects, press to switch, double click to exit after setting up



LIGHTNING MODE



TV MODE



BAD BULB MODE

SOS

SOS MODE




BURST MODE



CANDLELIGHT
MODE




PULSE FLASH MODE



HIGH AND LOW BEAM BULBS

BRACKET DESCRIPTION



- ❶ 1/4 screw hole, fits ❺ , locks bracket to light.
- ❷ The bracket can be bent and used in conjunction with the cold shoe holder to mount the light on top of the camera
- ❸ With ❻ hand screws, the camera can be mounted to the bracket with a locking mechanism.

! WARNING

- Keep this product out of the reach of children in a safe place.
- Please use the original parts correctly.
- Before each use, please be sure to check whether the installation is stable, to prevent accidents during use.
- Store in a cool, dry place, prohibit exposure to the sun, waterproof

Camera Usage



WARNING

- 1: Align the bracket to the bottom of the light first and tighten the screw by hand
- 2: The camera is set up on the bracket and screwed in by hand.
- 3: Can be expanded to install any equipment with 1/4 interface according to the use of demand

Before use, please carefully check whether the installation is stable or not.

Mobile phone usage

Adjustable horizontal/vertical racket



⚠ WARNING

- 1: Align the bracket to the bottom of the light first and tighten the screw by hand
- 2: The camera is set up on the bracket and screwed in by hand.
- 3: Can be expanded to install any equipment with 1/4 interface according to the use of demand

Before use, please carefully check whether the installation is stable or not.

Camera Usage



15A is a COB 15W, colour rendering index ≥ 96 , burst flash, along the vintage flash styling of the constant light, mobile phone / camera can be used!

- **WITH SILICONE SOFTBOX**

The soft light amplitude is suitable, the light is soft and not harsh

- **0%-100% BRIGHTNESS ADJUSTABLE**

Turning the adjustment knob, the brightness change range is 0-100%.

SPECIFICATION

MODEL:	15A
TYPE:	COB 15W
Colour temperature:	/
Jadeite thumb ring:	≥ 96
Batteries:	2 x 18650 14.8V (2600mAh)
Charging Voltage:	12V 2A
Duration of use:	Approx. 1 hour (when used at maximum brightness)
Adjustment range:	Brightness adjustment 0%-100%
Number of beads:	Total 192 pcs
Bead Voltage:	36 ~ 68V
Bead Current:	1100mA

This manual provides information on the proper use and storage of the product and accessories, and assists the user in dealing with questions about their use and in understanding the safety precautions to be taken.

PLEASE READ CAREFULLY

When handing the product over to another person, be sure to include this manual, heed all warnings and follow all instructions in the manual.

2 YEAR WARRANTY DESCRIPTION

The warranty, which applies to all purchasers from our authorised dealers, covers any defects caused by production, as well as failures in the course of normal use, excluding physical damage, natural disasters (fire, flood, earthquake lightning, etc.) and chemical corrosion, unauthorised repairs, replacement of components during handling, collisions at the site of the installation and other failures due to human or force majeure reasons. and damage, or the manual Any malfunction caused by acts expressly prohibited by the instruction manual

ACCESSORY DESCRIPTION

Mobile phone clip, camera frame, hand screws and other accessories are consumables (not in the 2-year warranty), after use, please confirm whether there is aging, damage and other conditions of this phenomenon is normal wear and tear, in order to use the convenience of please contact the dealer in time to buy new parts replacement!

MAINTENANCE METHODS

Please use a soft sponge, soft cloth, dry cloth to clean the product regularly, do not use bleach, wire ball wipe, wipe clean and keep the product dry.

For more information on LENS GO product features,
Please visit **WWW.lensgo.net**



WARNING

- Do not touch the COB lamp beads with your hands to prevent burning hands
- This product is a precision instrument, please avoid dropping it when using it.
- Contact authorised service personnel when repairs are required
- It is recommended to use the original LENS GO cables. Any damage to this product caused by the use of non-Longsong original accessories is not covered by our warranty. Any damage to this product is not covered by our warranty.
- Please clean the product with a soft, dry cloth.
- This specification is based on our rigorous testing. Design and specifications are subject to change without notice
- Please keep it in a safe place, read this instruction manual carefully, and observe all precautions
- Before use, please check whether the installation is stable, to prevent accidents during use.
- Please switch off the product after charging, in order to protect the safety and life of the battery, try not to use it during charging. use the product during charging.
- Do not cover the ventilation holes when using the silicone softbox.

CERTIFICATE OF CONFORMITY

PRODUCT NAME:: _____

MODEL : _____

INSPECTION DATE : _____

INSPECTOR: _____





LENSGO



 Lensgotech




 Lensgo.official



 www.lensgo.net

Use your phone's camera or browser to scan the QR code for product support and user guide.

OR PLEASE VISIT: <https://www.lensgo.net/> , and click on the
“ **User Guide** ” menu.



JIAZHIYING PHOTOGRAPHY EQUIPMENT CO., LTD.

Address: Room 201, Building C, No. 8 Fengqi Road, Fucheng'ao Community,
Pinghu Subdistrict, Longgang District, Shenzhen, China

Web: <https://www.lensgo.net/>

Executive Standard: Q/LYJ004-2018



Facebook: Lensgotech



Made in China