

CONTENTS AND BATTERY INSTALLATION

Contents

2 Motor Battles 2 Remote Controls



Battery Installation

Vehicle:

1. Disconnect the "try me" cable from the bottom of the vehicle and make sure the power switch located on the bottom of the vehicle is in the off position (o).
2. Use a Phillips-head screwdriver to loosen the screws in the battery cover on the bottom of the vehicle.
3. Remove the included 3 AA demo batteries and install 3 AA 1.5V alkaline batteries in the polarity shown.
4. Replace the cover.

Remote control:

1. Remove protective film from the remote control before first use.
2. Use a tool to press and hold the battery release button on the back of the remote control.
3. Slide down the battery cover and remove it.
4. Insert 3 AAA 1.5V batteries into each (not included).
5. Slide the battery cover back into place securely.



HOW TO PLAY


Get Ready

1. To pair, press the power button on a remote control and then flip the power switch on a vehicle to the on position. Wait for the lights to stop blinking. Power on the next vehicle and remote control. Repeat until all vehicles and remote controls are paired.
2. Press the team button repeatedly to choose your team color (red, blue, yellow, or green). The 3 tailpipe lights on your vehicle will light up in your team color.



Battle

1. Do a countdown to start each round. 3... 2... 1... Go!
2. Try to drive the ram bumper of your vehicle into the trigger bumpers of rival vehicles. Try not to let rivals ram the trigger bumpers on your vehicle.
3. Each time a trigger bumper is rammed successfully, a tailpipe light will go out on the rammed vehicle.
4. If a vehicle is rammed 3 times, the vehicle will be disabled until the next round – it's lights out.
5. Press the turbo button for quick boosts to help you ram rivals or dodge out of their way.
6. The last vehicle still moving wins.
7. Press the restart button to begin the next round!



Tip: For the best performance, drive on smooth surfaces, such as tile or wood floors.





Forward





Reverse



Left Turn



Right Turn



SAFETY PRECAUTIONS

- Do not sit, step, stand, or place objects on the vehicle. It is not designed to support extra weight.
- Adult supervision is recommended when operating the vehicle.
- Always drive responsibly and make sure driving paths are clear. Never drive towards or in close proximity to people or animals.
- Never submerge the vehicle in water and avoid driving the vehicle through water.
- Keep fingers, hair, and loose clothing away from tires and all moving parts while the vehicle is in motion.
- Do not expose to extreme temperatures.
- Do not leave vehicle or remote control near sources of heat or under direct sunlight for long periods of time.
- Thoroughly inspect products before every use. If the product appears worn, frayed, splintered, cracked, or broken in any manner, discontinue use and discard immediately.



BATTERY WARNINGS

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Alkaline batteries are recommended. Use only the specified voltage.
- Insert batteries using the correct polarity. Always use, replace, and recharge (if applicable) batteries under adult supervision.
- Do not attempt to charge non-rechargeable batteries.
- Do not short-circuit the battery supply terminals.
- Do not dispose of batteries in fire: batteries may explode or leak.
- Remove batteries before storing.
- Recycle or dispose of batteries according to federal, state, and local laws.
- Keep these instructions for future reference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Sharper Image® name and logos (including the 77 logo) are trademarks or registered trademarks. Distributed by and © 2023 MerchSource, LLC. Irvine, CA 92618. All rights reserved.

Model No.: 1017802



WARNING:

CHOKING HAZARD – Small Parts.
Not for children under 3 years of age.

KEEP THIS INSTRUCTION MANUAL AS IT CONTAINS IMPORTANT INFORMATION FOR FUTURE REFERENCE.

Due to continuous product improvements, the pictures on this manual may differ slightly from the actual product.

Printed in China

**FOR CUSTOMER SUPPORT,
PLEASE CALL**

1-800-374-2744