

[Skip to content](#)

## **Manuals+**

User Manuals Simplified.



# Braun XT5200 Beard Trimmer Shaver Instruction Guide

October 21, 2022October 21, 2022 ■ [Leave a comment on Braun XT5200 Beard Trimmer Shaver Instruction Guide](#)

[Home](#) » [Braun](#) » Braun XT5200 Beard Trimmer Shaver Instruction Guide 

Document

Contents [hide](#)

[1 Braun XT5200 Beard Trimmer Shaver](#)

[2 Specifications](#)

[3 Introduction](#)

[4 WHAT'S IN THE BOX](#)

[5 HOW TO USE](#)

[6 HOW TO CLEAN](#)

[7 HOW TO CHANGE THE BATTERY](#)

[8 Frequently Asked Questions](#)

[9 Related Posts](#)



## Braun XT5200 Beard Trimmer Shaver



## Specifications

- **BRAND:** Braun
- **RECOMMENDED USES FOR PRODUCT:** Shaving
- **MODEL NAME:** Men Grooming
- **INCLUDED COMPONENTS:** Cleaning Brush, Battery, Attachment, Charger
- **COLOR:** Black/Metallic Grey
- **BLADE MATERIAL:** Stainless Steel
- **PACKAGE DIMENSIONS:** 07 x 4.92 x 2.2 inches; 11.99 Ounces

## Introduction

A trimmer, body groomer, and electric razor are all included in the Braun Series XT5 for men. Its 4D-Blade offers a simple, comfortable, and skin-friendly shave. This trimmer and shaver is completely waterproof, may be used wet or dry, and its metal blade is designed to last up to 6 months\*. It is surprisingly simple to handle thanks to the thin design and non-slip grip. According to two full shaves every week, actual outcomes may differ.

## WHAT'S IN THE BOX

- 1 X Electric shaver
- 4 X Face combs (1 mm, 2 mm, 3 mm, 5 mm)
- 1 X Smart plug
- 2 X Body combs (0 mm SkinGuard, 3 mm)
- 1 X Travel pouch

## HOW TO USE

Shave counterclockwise to the direction your beard is growing while holding the razor at a straight angle (90°) to your skin. Also keep in mind that avoiding repeatedly applying to the same locations can lessen the likelihood of skin irritation. To get the greatest shave possible, maintain equal pressure.

## HOW TO CLEAN

Rinsing with hot water that is flowing. Rinsing under hot running water is quick and simple for almost all Braun shavers. The cleaning outcome can be enhanced by using a small amount of regular liquid soap. Another piece of advice is to occasionally apply a drop of oil to the cutter block of your shaver for optimum maintenance.

## HOW TO CHANGE THE BATTERY

- Take the trim head off. Fold the trim head down.
- The housing is being opened. The two screws at the front of the blade must be removed.
- The housing is opened.
- The watertight interior assembly is opened.
- changing the batteries.
- Replace the batteries with solder.
- batteries were replaced.

## HOW TO LOCK

To lock the appliance, press and hold the on/off button (4) for 3 seconds. The travel lock is confirmed to be engaged with a beep. Press the on/off button for three seconds to unlock.

## HOW TO UNLOCK

Press the on/off button on your shaver for three to five seconds to disengage the travel lock. Now try switching the shaver back on.

## HOW TO RESET

To reset the counter, press and hold the on/off button for 10 seconds. The shaving device must then be unlocked (see chapter "Travel lock"). After seven shavings, the replacement indication on some razor models will reset itself.

## Frequently Asked Questions

### how do you change the blade so what do you after 6 months of use ?

To change the blade, you'll have to remove the head (XT10) which is part 1 in the manual and get a replacement.

### What's difference between this xt5 and the xt3?

Great question! Our XT5 has 6 total attachments, and there are 3 attachments for the XT3000.

### Can I use it while charging?

Yes, I've noticed the clippers work a bit harder if you plug them in actually.

### How long does it take to charge

It takes 10 hours to fully charge this device.

### Is this made in Germany?

No, our XT5 is not made in Germany.

### What are the benefits and drawbacks of a Braun razor?

You'll notice two silver semicircles with the words "plus" and "minus" just below the power button. These are utilized

to switch between one of three speed settings, ranging from sensitive to intensive. There is a slight depression further down the handle, directly behind the Braun logo. This button resets the device.

### **What does the red light on my Braun razor mean?**

The battery has to be recharged if the light is red. You can get five shaves out of it if you plug it in for approximately an hour. Shaving is not possible while the razor is plugged in.

### **How can I tell what model of Braun I have?**

The model number is typically located on the front of your product; for example, on the Braun 3615, it is located under the LED, and you would type 3615 into the search box. Some manufacturers, like Braun, also include a Type number, which is frequently located on the back of the razor.

### **How is a Braun Series 5 shaver unlocked?**

To unlock the razor, press the on/off switch for three seconds.

### **What do the numbers on a Braun razor stand for?**

The most recent lineup of Braun Shavers is the Braun Series range. 1, 3, 5, 7 and 9 are arranged according to a recognizable Series numbering system, not too unlike from that of another well-known German (car) manufacturer. The feature list expands and the shave quality improves as you move up the Series number.

### **My Braun shaver is blaring; why?**

The presence of the shaver in the station is verified by a beep sound. The charging process will begin instantly.

### **Braun replacement heads can they be switched?**

While some models work with several shavers, some are distinctly different. As a result, we do not suggest exchanging them.

### **Why won't my electric shaver function?**

Check the battery and recharge it if it is low before checking the electrical cable if a shaver is completely unresponsive. Test the switches and motor as necessary (see the Appliance Controls Fix-It Guide). Cleaning and lubricating the heads will help an electric shaver run more quickly.


### **How long should my Braun shaver be charged?**

Typically, it takes two and a half hours for a shaver's battery to fully recharge. Our shavers include a USB charging cord, allowing you to use practically any USB port, battery pack, or wall adapter that produces 5 volts or less to recharge your device.

### **How much time does a Braun shaver require to charge?**

Up to 45 minutes of cordless shaving with a full recharge in an hour – Cordless shaving for up to 45 minutes with a full recharge in an hour. For a single cordless shave, a short five-minute charge is sufficient.

## **Related Posts**



### **[BRAUN BT5341 Beard Trimmer User Manual](#)**

BRAUN BT5341 Beard Trimmer INSTRUCTION Read these instructions completely, they contain safety information. Keep them for future reference.  
...

### **[BRAUN Series 8 8460cc Wet and Dry Foil shaver Trimmer User Guide](#)**

BRAUN Series 8 8460cc Wet and Dry Foil shaver Trimmer Read these instructions completely, they contain safety information....



### [BRAUN XT5100 Beard Trimmer Instruction Manual](#)

BRAUN XT5100 Beard Trimmer Overview Charge How to use Method Cleaning and washing Read these instructions completely,...



### [Panasonic ER217 Hair and Beard Trimmer User Manual](#)

Panasonic ER217 Hair and Beard Trimmer Please file and use this manual together with the service manual for...



## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

[Manuals+](#),

- [home](#)
- [privacy](#)