



| Original                                                                            | Replacement  |
|-------------------------------------------------------------------------------------|--------------|
|    | Standby      |
|    | Mute         |
|    | EPG          |
|    | Info         |
|    | TTX          |
|    | Audio        |
|    | Subtitle     |
|    | Menu         |
|    | Up / CH+     |
|   | Up / CH+     |
|  | Exit         |
|  | Left / Vol-  |
|  | Left / Vol-  |
|  | OK           |
|  | Right / Vol+ |
|  | Right / Vol+ |
|  | Favourite    |

| Original                                                                              | Replacement |
|---------------------------------------------------------------------------------------|-------------|
|    | Down / CH-  |
|    | Down / CH-  |
|    | TV/Radio    |
|    | 1           |
|    | 2           |
|    | 3           |
|    | Recall      |
|    | 4           |
|    | 5           |
|   | 6           |
|  | Goto        |
|  | 7           |
|  | 8           |
|  | 9           |
|  | 0           |
|  | Rev         |
|  | Fwd         |

| Replacement    |
|----------------|
| CH- / Page-    |
| Down           |
| TV/Radio /     |
| 1              |
| 2              |
| 3              |
| Back / Return  |
| 4              |
| 5              |
| 6              |
| Shift + Text / |
| 7              |
| 8              |
| 9              |
| 0              |
| << / Tune-     |
| >> / Tune+     |



[illegible]